
If you see device manager has one Unknown device (ACPI\VEN_INTC&DEV_1027)



This is because below 4 Intel (R) Serial IO I2C Controller 4B78/4B7A/4B7B/4B4B device has use wrong driver, become wrong device, especially Intel (R) Serial IO I2C Controller 4B7B

If you install new OS and then in the first is install chipset driver, you will can see has 4 Intel (R) Serial IO I2C Controller as below figure, you don't need install Serial IO driver for these 4 device again.

```
Intel(R) Serial IO I2C Controller #0 - 4878
Intel(R) Serial IO I2C Controller #2 - 487A
Intel(R) Serial IO I2C Controller #3 - 4878
Intel(R) Serial IO I2C Controller #4 - 4848
```

The serial IO driver is for below 2 device

```
Intel(R) Serial IO I2C Host Controller - 4844
Intel(R) Serial IO I2C Host Controller - 4845
```

If Intel (R) Serial IO I2C Controller 4B78/4B7A/4B7B/4B4B becomes Intel (R) Serial IO I2C Host Controller. They are incorrect device names.

Especially when Intel (R) Serial IO I2C Controller 4B7B becomes Intel (R) Serial IO I2C Host Controller-4B7B, one Unknown device (ACPI\VEN_INTC&DEV_1027) will be generated. This one device no driver.

```
Intel(R) Serial IO I2C Host Controller - 4B4B
Intel(R) Serial IO I2C Host Controller - 4B78
Intel(R) Serial IO I2C Host Controller - 4B7A
Intel(R) Serial IO I2C Host Controller - 4B7B
```

The correct device and the names need as like below figure

```
Intel(R) Serial IO I2C Controller #0 - 4B78
Intel(R) Serial IO I2C Controller #2 - 4B7A
Intel(R) Serial IO I2C Controller #3 - 4B7B
Intel(R) Serial IO I2C Controller #4 - 4B4B
Intel(R) Serial IO I2C Host Controller - 4B44
Intel(R) Serial IO I2C Host Controller - 4B45
```

How to solve?


1. Please use Update driver

Change Intel (R) Serial IO I2C Host Controller 4B78/4B7A/4B7B/4B4B to Intel (R) Serial IO I2C Controller 4B78/4B7A/4B7B/4B4B, Especially Intel (R) Serial IO I2C Controller 4B7B need become correct device.



2. Select "Browse my computer for drivers"

How do you want to search for driver software?



3. Select "Let me pick from a list of device drivers on my computer."



If you ever install chipset driver and SIO driver, you should be has two device one is Intel (R) Serial IO I2C Controller and other one is Intel (R) Serial IO I2C Host Controller


4. Please use Intel (R) Serial IO I2C Controller




If you can't see Intel (R) Serial IO I2C Controller.

5. Please select Have Disk






6. Choose \1-Chipset\DriverFiles\production\Windows10-x64\ElkhartLakeSystem



7. Choose to Use Intel (R) Serial IO I2C Controller – 4B7B



Notes: Others Intel (R) Serial IO I2C Host Controller 4B78/4B7A//4B4B are the same method