




IEI Technology Corp.



MODEL:

PICOe-PV-D4251/N4551/D5251

**Half-size PCIe CPU Card with Intel® Atom™ Processor
D425/N455/D525, 1 GB Onboard Memory, Dual Gigabit
Ethernet, Seven USB, Three RS-232, One RS-232/422/485,
Three SATA, Parallel Port, CompactFlash® Type II, VGA, LVDS,
RoHS Compliant**

User Manual

Rev. 1.10 – 17 August, 2011



Revision

Date	Version	Changes
17 August, 2011	1.10	On-board DRAM upgraded from 64MB x16 (1GB) to 128MB x8 (1GB), scalable to 256MB x8 (2GB)
14 January, 2011	1.00	Initial release

Copyright

COPYRIGHT NOTICE

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

TRADEMARKS

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Table of Contents

1 INTRODUCTION.....	1
1.1 INTRODUCTION.....	2
1.2 CONNECTORS	3
1.3 DIMENSIONS.....	4
1.4 DATA FLOW	5
1.5 TECHNICAL SPECIFICATIONS	5
2 UNPACKING	9
2.1 ANTI-STATIC PRECAUTIONS	10
2.2 UNPACKING PRECAUTIONS.....	10
2.3 UNPACKING CHECKLIST	11
2.3.1 Package Contents.....	11
2.3.2 Optional Items.....	12
3 CONNECTORS	13
3.1 PERIPHERAL INTERFACE CONNECTORS.....	14
3.1.1 PICOe-PV-D4251/N4551/D5251 Layout	14
3.1.2 Peripheral Interface Connectors	15
3.1.3 External Interface Panel Connectors.....	15
3.2 INTERNAL PERIPHERAL CONNECTORS	16
3.2.1 ATX Power Supply Enable Connector	16
3.2.2 Audio Connector (9-pin)	17
3.2.3 Backlight Inverter Connector	18
3.2.4 Battery Connector.....	18
3.2.5 CompactFlash® Socket.....	19
3.2.6 CPU Fan Connector (+12V, 4-pin).....	20
3.2.7 Digital Input/Output (DIO) Connector.....	21
3.2.8 Front Panel Connector (8-pin)	22
3.2.9 Infrared Interface Connector	23
3.2.10 Keyboard/Mouse Connector	24
3.2.11 LVDS LCD Connector.....	25

3.2.12 Parallel Port Connector	26
3.2.13 SATA Drive Connectors	27
3.2.14 Serial Port Connectors (COM 1, COM 2 and COM 4)	27
3.2.15 Serial Port Connector (RS-232/422/485)	28
3.2.16 SMBus Connector	29
3.2.17 SPI Flash Connector.....	30
3.2.18 USB Connectors (Internal)	31
3.3 EXTERNAL PERIPHERAL INTERFACE CONNECTOR PANEL	32
3.3.1 Keyboard/Mouse Connector	32
3.3.2 LAN Connectors.....	33
3.3.3 USB Connectors.....	34
3.3.4 VGA Connector	35
4 INSTALLATION	36
4.1 ANTI-STATIC PRECAUTIONS	37
4.2 INSTALLATION CONSIDERATIONS.....	38
4.2.1 Installation Notices	38
4.2.2 Installation Checklist	39
4.3 UNPACKING	40
4.4 SO-DIMM AND CF CARD INSTALLATION	40
4.4.1 SO-DIMM Installation	40
4.4.2 CF Card Installation.....	41
4.5 JUMPER SETTINGS	43
4.5.1 AT Power Select Jumper	44
4.5.2 CF Card Setup Jumper	45
4.5.3 CF Card Voltage Select Jumper	45
4.5.4 Clear CMOS Jumper.....	46
4.5.5 LVDS Voltage Select Jumper.....	47
4.5.6 PCIe Status Select Jumper	48
4.5.7 COM 3 Function Select Jumpers	49
4.5.8 COM 3 RS-422 and 485 Termination Select Jumpers	50
4.6 CHASSIS INSTALLATION.....	51
4.6.1 Airflow.....	51
4.6.2 Backplane Installation	51
4.6.3 CPU Card Installation	52

4.7 INTERNAL PERIPHERAL DEVICE CONNECTIONS.....	52
4.7.1 Peripheral Device Cables.....	52
4.7.2 Audio Kit Installation.....	53
4.7.3 SATA Drive Connection	54
4.7.4 USB Cable (Dual Port) with Slot Bracket	56
4.7.5 Parallel Port Cable without Bracket	57
4.7.6 Dual RS-232 Cable with Slot Bracket.....	59
4.8 EXTERNAL PERIPHERAL INTERFACE CONNECTION	60
4.8.1 LAN Connection.....	61
4.8.2 PS/2 Y-Cable Connection.....	61
4.8.3 USB Connection.....	62
4.8.4 VGA Monitor Connection	63
4.9 SOFTWARE INSTALLATION	64
5 BIOS SCREENS.....	67
5.1 INTRODUCTION.....	68
5.1.1 Starting Setup.....	68
5.1.2 Using Setup	68
5.1.3 Getting Help.....	69
5.1.4 Unable to Reboot After Configuration Changes.....	69
5.1.5 BIOS Menu Bar.....	69
5.2 MAIN.....	70
5.3 ADVANCED	71
5.3.1 ACPI Settings	71
5.3.2 Trusted Computing	72
5.3.3 CPU Configuration.....	73
5.3.4 SATA Configuration	75
5.3.5 USB Configuration.....	76
5.3.6 Super IO Configuration	77
5.3.6.1 Serial Port n Configuration	78
5.3.6.2 IrDA Configuration.....	81
5.3.6.3 Parallel Port Configuration	82
5.3.7 H/W Monitor	83
5.3.8 Serial Port Console Redirection	85
5.4 CHIPSET	86

5.4.1 Host Bridge Configuration	87
5.4.1.1 OnChip VGA Configuration	87
5.4.2 South Bridge Configuration.....	88
5.4.3 Intel IGD SWSCI OpRegion.....	90
5.5 BOOT.....	92
5.6 SECURITY	93
5.7 EXIT	94
A BIOS OPTIONS	96
B ONE KEY RECOVERY	99
B.1 ONE KEY RECOVERY INTRODUCTION	100
B.1.1 System Requirement.....	101
B.1.2 Supported Operating System	102
B.2 SETUP PROCEDURE FOR WINDOWS	103
B.2.1 Hardware and BIOS Setup	103
B.2.2 Create Partitions	104
B.2.3 Install Operating System, Drivers and Applications.....	107
B.2.4 Build-up Recovery Partition.....	108
B.2.5 Create Factory Default Image.....	110
B.3 SETUP PROCEDURE FOR LINUX	115
B.4 RECOVERY TOOL FUNCTIONS	118
B.4.1 Factory Restore	120
B.4.2 Backup System.....	121
B.4.3 Restore Your Last Backup.....	122
B.4.4 Manual.....	123
B.5 OTHER INFORMATION	124
B.5.1 Using AHCI Mode or ALi M5283 / VIA VT6421A Controller.....	124
B.5.2 System Memory Requirement	126
C TERMINOLOGY	127
D DIGITAL I/O INTERFACE	131
D.1 INTRODUCTION.....	132
D.2 DIO CONNECTOR PINOUTS	132
D.3 ASSEMBLY LANGUAGE SAMPLES.....	133
D.3.1 Enable the DIO Input Function	133



<i>D.3.2 Enable the DIO Output Function.....</i>	<i>133</i>
E WATCHDOG TIMER.....	134
F HAZARDOUS MATERIALS DISCLOSURE.....	137
F.1 HAZARDOUS MATERIALS DISCLOSURE TABLE FOR IPB PRODUCTS CERTIFIED AS ROHS COMPLIANT UNDER 2002/95/EC WITHOUT MERCURY	138

List of Figures

Figure 1-1: PIC0e-PV-D4251/N4551/D5251	2
Figure 1-2: Connectors	3
Figure 1-3: PIC0e-PV-D4251/N4551/D5251 Dimensions (mm).....	4
Figure 1-4: Data Flow Block Diagram	5
Figure 3-1: Connector and Jumper Locations [Front Side]	14
Figure 3-2: Connector and Jumper Locations [Solder Side]	14
Figure 3-3: ATX Power Supply Enable Connector Location	16
Figure 3-4: Audio Connector Location (9-pin).....	17
Figure 3-5: Backlight Inverter Connector Pinout Locations	18
Figure 3-6: Battery Connector Location.....	19
Figure 3-7: CF Card Socket Location	19
Figure 3-8: +12V Fan Connector Location	21
Figure 3-9: DIO Connector Locations.....	22
Figure 3-10: Front Panel Connector Pinout Locations (8-pin).....	23
Figure 3-11: Infrared Connector Pinout Locations	23
Figure 3-12: Keyboard/Mouse Connector Location	24
Figure 3-13: LVDS LCD Connector Pinout Location.....	25
Figure 3-14: Parallel Port Connector Location	26
Figure 3-15: SATA Drive Connector Locations	27
Figure 3-16: COM Connector Pinout Locations	28
Figure 3-17: Serial Port Connector Location	29
Figure 3-18: SMBus Connector Locations	30
Figure 3-19: SPI Flash Connector	30
Figure 3-20: USB Connector Pinout Locations	31
Figure 3-21: PIC0e-PV-D4251/N4551/D5251 External Peripheral Interface Connector	32
Figure 3-22: PS/2 Pinout and Configuration	32
Figure 3-23: RJ-45 Ethernet Connector.....	33
Figure 3-24: VGA Connector	35
Figure 4-1: SO-DIMM Installation	41
Figure 4-2: CF Card Installation	42

Figure 4-3: AT Power Select Jumper Location	44
Figure 4-4: CF Card Setup Jumper Location	45
Figure 4-5: CF Card Voltage Select Jumper Location	46
Figure 4-6: Clear CMOS Jumper	47
Figure 4-7: LVDS Voltage Selection Jumper Pinout Locations	48
Figure 4-8: PCIe Status Select Jumper Pinout Locations	49
Figure 4-9: COM 3 Function Select Jumpers Locations	50
Figure 4-10: COM 3 RS-485 and RS422 Termination Select Jumper Location	51
Figure 4-11: 7.1 Channel Audio Kit	54
Figure 4-12: SATA Drive Cable Connection	55
Figure 4-13: SATA Power Drive Connection	56
Figure 4-14: Dual USB Cable Connection	57
Figure 4-15: LPT Cable Connection	58
Figure 4-16: Connect the LPT Device	59
Figure 4-17: Dual RS-232 Cable Installation	60
Figure 4-18: LAN Connection	61
Figure 4-19: PS/2 Keyboard/Mouse Connector	62
Figure 4-20: USB Connector	63
Figure 4-21: VGA Connector	64
Figure 4-22: Introduction Screen	65
Figure 4-23: Available Drivers	66
Figure B-1: IEI One Key Recovery Tool Menu	100
Figure B-2: Launching the Recovery Tool	104
Figure B-3: Recovery Tool Setup Menu	105
Figure B-4: Command Mode	105
Figure B-5: Partition Creation Commands	106
Figure B-6: Launching the Recovery Tool	108
Figure B-7: System Configuration for Windows	108
Figure B-8: Build-up Recovery Partition	109
Figure B-9: Press any key to continue	109
Figure B-10: Press F3 to Boot into Recovery Mode	110
Figure B-11: Recovery Tool Menu	110
Figure B-12: About Symantec Ghost Window	111
Figure B-13: Symantec Ghost Path	111
Figure B-14: Select a Local Source Drive	112

Figure B-15: Select a Source Partition from Basic Drive	112
Figure B-16: File Name to Copy Image to	113
Figure B-17: Compress Image.....	113
Figure B-18: Image Creation Confirmation	114
Figure B-19: Image Creation Process.....	114
Figure B-20: Image Creation Complete	114
Figure B-21: Press Any Key to Continue	115
Figure B-22: Partitions for Linux.....	116
Figure B-23: System Configuration for Linux.....	117
Figure B-24: Access menu.lst in Linux (Text Mode)	117
Figure B-25: Recovery Tool Menu	118
Figure B-26: Recovery Tool Main Menu	119
Figure B-27: Restore Factory Default.....	120
Figure B-28: Recovery Complete Window	120
Figure B-29: Backup System.....	121
Figure B-30: System Backup Complete Window	121
Figure B-31: Restore Backup	122
Figure B-32: Restore System Backup Complete Window	122
Figure B-33: Symantec Ghost Window	123

List of Tables

Table 1-1: Technical Specifications.....	8
Table 3-1: Peripheral Interface Connectors.....	15
Table 3-2: Rear Panel Connectors	16
Table 3-3: ATX Power Supply Enable Connector Pinouts	17
Table 3-4: Audio Connector Pinouts (9-pin)	17
Table 3-5: Panel Backlight Connector Pinouts.....	18
Table 3-6: Battery Connector Pinouts	19
Table 3-7: CF Card Socket Pinouts.....	20
Table 3-8: +12V Fan Connector Pinouts.....	21
Table 3-9: DIO Connector Connector Pinouts	22
Table 3-10: Front Panel Connector Pinouts (8-pin).....	23
Table 3-11: Infrared Connector Pinouts	24
Table 3-12: Keyboard/Mouse Connector Pinouts	24
Table 3-13: TFT LCD LVDS Port Connector Pinouts.....	25
Table 3-14: Parallel Port Connector Pinouts	26
Table 3-15: SATA Drive Connector Pinouts.....	27
Table 3-16: COM Connector Pinouts	28
Table 3-17: Serial Port Connector Pinouts	29
Table 3-18: SMBus Connector Pinouts	30
Table 3-19: SPI Flash Connector.....	31
Table 3-20: USB Port Connector Pinouts.....	31
Table 3-21: Keyboard Connector Pinouts.....	33
Table 3-22: LAN Pinouts	33
Table 3-23: RJ-45 Ethernet Connector LEDs	34
Table 3-24: USB Port Pinouts.....	34
Table 3-25: VGA Connector Pinouts.....	35
Table 4-1: Jumpers	43
Table 4-2: AT Power Select Jumper Settings	44
Table 4-3: CF Card Setup Jumper Settings	45
Table 4-4: CF Card Voltage Select Jumper Settings.....	45

PIC0e-PV-D4251/N4551/D5251 User Manual

Table 4-5: Clear CMOS Jumper Settings.....	47
Table 4-6: LVDS Voltage Selection Jumper Settings.....	48
Table 4-7: PCIe Status Select Jumper Settings.....	48
Table 4-8: COM 3 Function Select Jumpers Settings	49
Table 4-9: COM 3 Function Select Jumpers Settings	49
Table 4-10: COM 3 RS-485 Termination Select Jumper Settings	50
Table 4-11: COM 3 RS-422 Termination Select Jumper Settings	50
Table 4-12: IEI Provided Cables	52
Table 5-1: BIOS Navigation Keys	69

BIOS Menus

BIOS Menu 1: Main	70
BIOS Menu 2: Advanced	71
BIOS Menu 3: ACPI Settings	72
BIOS Menu 4: TPM Configuration	73
BIOS Menu 5: CPU Configuration	74
BIOS Menu 6: IDE Configuration	75
BIOS Menu 7: USB Configuration	76
BIOS Menu 8: Super IO Configuration	77
BIOS Menu 9: Serial Port n Configuration Menu	78
BIOS Menu 10: IrDA Configuration Menu	81
BIOS Menu 11: Parallel Port Configuration Menu	82
BIOS Menu 12: Hardware Health Configuration	84
BIOS Menu 13: Serial Port Console Redirection	85
BIOS Menu 14: Chipset	86
BIOS Menu 15: Host Bridge Chipset Configuration	87
BIOS Menu 16: OnChip VGA Configuration	87
BIOS Menu 17: South Bridge Chipset Configuration	88
BIOS Menu 18: South Bridge Chipset Configuration	90
BIOS Menu 19: Boot	92
BIOS Menu 20: Security	93
BIOS Menu 21: Exit	94

Chapter

1

Introduction

1.1 Introduction




Figure 1-1: PICOe-PV-D4251/N4551/D5251

The PICOe-PV-D4251/N4551/D5251 half-size PCIe CPU card is an embedded 45 nm Intel® Atom™ processor D525, D425 or N455 platform. The PICOe-PV-D4251/N4551/D5251 has 1 GB 800 MHz DDR3 memory onboard and supports one 204-pin 667/800 MHz 2.0 GB (max.) DDR3 SDRAM SO-DIMM. The board includes one LVDS connector (supports an 18-bit single-channel LVDS screen), one VGA connector, and supports a dual-display configuration.

The PICOe-PV-D4251/N4551/D5251 also comes with two Gigabit Ethernet (GbE) connectors, three SATA connectors, seven USB 2.0 connectors, and one CompactFlash® Type II slot. Serial device connectivity is provided by three internal RS-232 and one internal RS-232/422/485 connectors.

1.2 Connectors

The connectors on the PIC0e-PV-D4251/N4551/D5251 are shown in the figure below.




Figure 1-2: Connectors

1.3 Dimensions

The dimensions of the board are listed below:

- **Length:** 122 mm
- **Width:** 185 mm




Figure 1-3: PIC0e-PV-D4251/N4551/D5251 Dimensions (mm)

1.4 Data Flow

Figure 1-4 shows the data flow between the two on-board chipsets and other components installed on the motherboard and described in the following sections of this chapter.




Figure 1-4: Data Flow Block Diagram

1.5 Technical Specifications

PICOe-PV-D4251/N4551/D5251 technical specifications are listed in table below.

Specification	PIC0e-PV-D4251/N4551/D5251
Form Factor	Half-size PCIe CPU Card

Specification	PIC0e-PV-D4251/N4551/D5251
CPU Options	Intel® Atom™ processor D525, 1.8 GHz/1 MB L2 cache Intel® Atom™ processor D425, 1.8 GHz/512 KB L2 cache Intel® Atom™ processor D455, 1.66 GHz/512 KB L2 cache
System Chipset	Intel® ICH8M
Graphics Engine	GMA3150 Gen3.5 DX9, 400MHz for D525/D425 Gen3.5 DX9, 200MHz for N455
Memory	Onboard 1 GB DDR3 800 MHz memory One 204-pin SO-DIMM socket supports one 800 MHz DDR3 SDRAM SO-DIMM (up to 2 GB) Note: Supports 128 MB x8 (1GB) or 256 MB x8 for (2GB) SO-DIMM configuration
LAN	Dual Realtek RTL8111E PCIe GbE controllers, LAN1 supports ASF 2.0
BIOS	UEFI BIOS
Super I/O	Fintek F81865
Watchdog Timer	Software programmable supports 1~255 sec. system reset
Infrared	One Infrared connector via internal pin header
TPM	Onboard INFINEON SLB9635TT1.2 (option on PIC0e-PV-D4251T/N4551T/D5251T)
Expansion	
PCI	Four PCI slots via golden finger
PCIe	Four PCI Express x1 or One PCI Express x4 via golden finger
I/O Interface Connectors	
Display	One VGA port (supports up to 2048x1536 resolution for D525/D425 or 1400x1050 for N455) One 18-bit single-channel LVDS via internal connector (supports up to 1024x768 (XGA) and 1366x768 (WXGA) resolution)
Ethernet	Two RJ-45 GbE ports

PIC0e-PV-D4251/N4551/D5251 User Manual

Specification	PIC0e-PV-D4251/N4551/D5251
Audio	Supports 7.1 channel HD audio via optional IEI AC-KIT883HD kit
Keyboard/Mouse	One PS/2 KB/MS port One KB/MS via internal header
Parallel Port	One Parallel (LPT) port connector
Serial Ports	Three RS-232 serial ports via internal box header One RS-232/422/485 serial ports via internal box header
USB 2.0/1.1 ports	One USB port Six USB via internal pin headers
Storage	
CompactFlash®	One CompactFlash® Type II
Serial ATA	Three independent Serial ATA (SATA) channels with 3.0 Gb/s data transfer rates
Environmental and Power Specifications	
Power Supply	5 V / 12 V, AT/ATX power support
Power Consumption	5V@3.38A, 12V@0.54A (Intel® Atom™ Dual Core D525 1.80GHz with 1GB DDR3 800MHz Memory on board) 5V@3.28A, 12V@0.43A (Intel® Atom™ Dual Core D425 1.80GHz with 1GB DDR3 800MHz Memory on board) 5V@3.13A, 12V@0.32A (Intel® Atom™ Single Core N455 1.66GHz with 1GB DDR3 800MHz Memory on board)
Operating temperature	-20°C~60°C without cooler, -20°C~70°C with forced air for D525 processor -20°C~65°C without cooler, -20°C~70°C with forced air for D425 processor -20°C~70°C without cooler, -20°C~75°C with forced air for N455 processor
Humidity	5% ~ 95% (non-condensing)
Physical Specifications	
Dimensions	185 mm x 122 mm

Specification	PIC0e-PV-D4251/N4551/D5251
Weight GW/NW	1000g/250g

Table 1-1: Technical Specifications

Chapter

2

Unpacking

2.1 Anti-static Precautions



WARNING!

Static electricity can destroy certain electronics. Make sure to follow the ESD precautions to prevent damage to the product, and injury to the user.

Make sure to adhere to the following guidelines:

- ***Wear an anti-static wristband:*** Wearing an anti-static wristband can prevent electrostatic discharge.
- ***Self-grounding:*** Touch a grounded conductor every few minutes to discharge any excess static buildup.
- ***Use an anti-static pad:*** When configuring any circuit board, place it on an anti-static mat.
- ***Only handle the edges of the PCB:*** Don't touch the surface of the motherboard. Hold the motherboard by the edges when handling.

2.2 Unpacking Precautions

When the PICOe-PV-D4251/N4551/D5251 is unpacked, please do the following:

- Follow the antistatic guidelines above.
- Make sure the packing box is facing upwards when opening.
- Make sure all the packing list items are present.

2.3 Unpacking Checklist




NOTE:

If any of the components listed in the checklist below are missing, do not proceed with the installation. Contact the IEI reseller or vendor the PIC0e-PV-D4251/N4551/D5251 was purchased from or contact an IEI sales representative directly by sending an email to sales@iei.com.tw.

2.3.1 Package Contents

The PIC0e-PV-D4251/N4551/D5251 is shipped with the following components:

Quantity	Item and Part Number	Image
1	PIC0e-PV-D4251/N4551/D5251, or PIC0e-PV-D4251T/N4551T/D5251T	
3	SATA cable (P/N: 32000-062800-RS)	
1	KB/MS PS/2 Y-cable (P/N: 32000-133200-RS)	
1	Dual RS-232 cable (P/N: 19800-000112-RS)	
1	Dual USB cable (w bracket) (P/N: CB-USB02-RS)	
1	Mini jumper pack (P/N: 33101-000657-RS)	

1	Utility CD	
1	Quick Installation Guide	

2.3.2 Optional Items

The PICOe-PV-D4251/N4551/D5251 is shipped with the following components:

Item and Part Number	Image
CPU fan (P/N: 19FTS00032100-000001-RS)	
SATA power cable P/N: 32102-000100-200-RS	
LPT cable (w/o bracket) (P/N: 32200-015100-RS)	
KB/MS cable (with bracket) (P/N: 19800-000075-RS)	
Audio kit_ 7.1 Channel (P/N: AC-KIT-883HD-R10)	

Chapter

3

Connectors

3.1 Peripheral Interface Connectors

Section 3.1.1 shows peripheral interface connector locations. Section 3.2 lists all the peripheral interface connectors seen in Section 3.1.1.

3.1.1 PIC0e-PV-D4251/N4551/D5251 Layout

Figure 3-1 shows the on-board peripheral connectors, rear panel peripheral connectors and on-board jumpers.




Figure 3-1: Connector and Jumper Locations [Front Side]

Figure 3-2 shows the solder side of the PIC0e-PV-D4251/N4551/D5251.




Figure 3-2: Connector and Jumper Locations [Solder Side]

3.1.2 Peripheral Interface Connectors

Table 3-1 shows a list of the peripheral interface connectors on the PIC0e-PV-D4251/N4551/D5251. Detailed descriptions of these connectors can be found below.

Connector	Type	Label
Audio connector	9-pin header	J_AUDIO1
ATX power control connector	3-pin wafer	ATXCTL1
Backlight inverter connector	5-pin wafer	INV1
Battery connector	2-pin wafer	BAT1
CompactFlash® socket	50-pin CF socket	CF1
CPU Fan connector	4-pin wafer	CPU_FAN1
Digital input/output (DIO) connector	10-pin header	DIO1
Front panel connector	8-pin header	F_PANEL1
LPC connector	20-pin	CN1
Infrared interface (IrDA) connector	5-pin header	IR1
Keyboard connector	6-pin wafer	KB/MS1
LVDS LCD connector	20-pin crimp	LVDS1
Parallel port connector	26-pin header	LPT1
Serial ATA (SATA) drive connectors	7-pin SATA	SATA1, SATA2, SATA3
Serial port connectors (RS-232)	10-pin header	COM1, COM2, COM4
Serial port connectors (RS-232/422-485)	14-pin header	COM3
SMBus connector	4-pin wafer	CN1
USB 2.0 connectors	8-pin header	USB0_1, USB2_3, USB4_5

Table 3-1: Peripheral Interface Connectors

3.1.3 External Interface Panel Connectors

Table 3-2 lists the rear panel connectors on the PIC0e-PV-D4251/N4551/D5251. Detailed descriptions of these connectors can be found in **Section 3.3** on **page 32**.

Connector	Type	Label
Ethernet connector	RJ-45	LAN1
Ethernet connector	RJ-45	LAN2
Keyboard/mouse	PS/2	PT1
USB port	USB port	USB6
VGA port connector	15-pin female	VGA1

Table 3-2: Rear Panel Connectors

3.2 Internal Peripheral Connectors

Internal peripheral connectors are found on the CPU card and are only accessible when the CPU card is outside of the chassis. This section has complete descriptions of all the internal, peripheral connectors on the PIC0e-PV-D4251/N4551/D5251.

3.2.1 ATX Power Supply Enable Connector

- CN Label:** ATXCTL1
- CN Type:** 3-pin wafer (1x3)
- CN Location:** See Figure 3-3
- CN Pinouts:** See Table 3-3

The ATX power supply enable connector enables the PIC0e-PV-D4251/N4551/D5251 to be connected to an ATX power supply. In default mode, the PIC0e-PV-D4251/N4551/D5251 can only use an AT power supply. To enable an ATX power supply the AT Power Select jumper must also be configured. Please refer to **Section 4.5.1** for more details.




Figure 3-3: ATX Power Supply Enable Connector Location

Pin	Description
1	+5 Standby
2	GND
3	PS-ON

Table 3-3: ATX Power Supply Enable Connector Pinouts

3.2.2 Audio Connector (9-pin)

CN Label: J_AUDIO1

CN Type: 9-pin header (2x5)

CN Location: See Figure 3-4

CN Pinouts: See Table 3-4

The 9-pin audio connector is connected to external audio devices including speakers and microphones for the input and output of audio signals to and from the system.




Figure 3-4: Audio Connector Location (9-pin)

Pin	Description	Pin	Description
1	HDA_SYNC	2	HDA_BITCLK
3	HDA_SDOUT	4	SB_SPKR
5	HDA_SDIN0	6	HDA_RST#
7	VCC	8	GND
9	+12V	10	GND

Table 3-4: Audio Connector Pinouts (9-pin)

3.2.3 Backlight Inverter Connector

CN Label: INV1

CN Type: 5-pin wafer (1x5)

CN Location: See Figure 3-5

CN Pinouts: See Table 3-5

The backlight inverter connector provides the backlight on the LCD display connected to the PIC0e-PV-D4251/N4551/D5251 with +12V of power.




Figure 3-5: Backlight Inverter Connector Pinout Locations

Pin	Description
1	LCD Backlight Control
2	GROUND
3	+ 12V
4	GROUND
5	BACKLIGHT Enable

Table 3-5: Panel Backlight Connector Pinouts

3.2.4 Battery Connector

CN Label: BAT1

CN Type: 2-pin wafer (1x2)

CN Location: See Figure 3-6

CN Pinouts: See Table 3-6

This is connected to the system battery. The battery provides power to the system clock to retain the time when power is turned off.




Figure 3-6: Battery Connector Location

Pin	Description
1	Battery +
2	Ground

Table 3-6: Battery Connector Pinouts

3.2.5 CompactFlash® Socket

- CN Label:** CF1 (solder side)
- CN Type:** 50-pin header (2x25)
- CN Location:** See Figure 3-7
- CN Pinouts:** See Table 3-7

A CF Type I or Type II memory card is inserted to the CF socket on the solder side of the PIC0e-PV-D4251/N4551/D5251.




Figure 3-7: CF Card Socket Location

Pin	Description	Pin	Description
1	GROUND	26	VCC-IN CHECK1

Pin	Description	Pin	Description
2	DATA 3	27	DATA 11
3	DATA 4	28	DATA 12
4	DATA 5	29	DATA 13
5	DATA 6	30	DATA 14
6	DATA 7	31	DATA 15
7	HDC_CS0#	32	HDC_CS1
8	GROUND	33	N/C
9	GROUND	34	IOR#
10	GROUND	35	IOW#
11	GROUND	36	VCC_COM
12	GROUND	37	IRQ15
13	VCC_COM	38	VCC_COM
14	GROUND	39	CSEL
15	GROUND	40	N/C
16	GROUND	41	HDD_RESET
17	GROUND	42	IORDY
18	SA2	43	SDREQ
19	SA1	44	SDACK#
20	SA0	45	HDD_ACTIVE#
21	DATA 0	46	66DET
22	DATA 1	47	DATA 8
23	DATA 2	48	DATA 9
24	N/C	49	DATA 10
25	VCC-IN CHECK2	50	GROUND

Table 3-7: CF Card Socket Pinouts

3.2.6 CPU Fan Connector (+12V, 4-pin)

CN Label: CPU_FAN1
CN Type: 4-pin header
CN Location: See Figure 3-8
CN Pinouts: See Table 3-8

The cooling fan connector provides a 12V, 500mA current to the cooling fan. The connector has a "rotation" pin to get rotation signals from fans and notify the system so the system BIOS can recognize the fan speed. Please note that only specified fans can issue the rotation signals.




Figure 3-8: +12V Fan Connector Location

Pin	Description
1	GND
2	+12V
3	FANIO1
4	FANPWM1

Table 3-8: +12V Fan Connector Pinouts

3.2.7 Digital Input/Output (DIO) Connector

CN Label:	DIO1
CN Type:	10-pin header (2x5)
CN Location:	See Figure 3-9
CN Pinouts:	See Table 3-9

The digital input/output connector is managed through a Super I/O chip. The DIO connector pins are user programmable.




Figure 3-9: DIO Connector Locations

Pin	Description	Pin	Description
1	GND	2	+5V
3	Output 3	4	Output 2
5	Output 1	6	Output 0
7	Input 3	8	Input 2
9	Input 1	10	Input 0

Table 3-9: DIO Connector Connector Pinouts

3.2.8 Front Panel Connector (8-pin)

CN Label: F_PANEL1
CN Type: 8-pin header (2x4)
CN Location: See Figure 3-10
CN Pinouts: See Table 3-10

The front panel connector connects to external switches and indicators to monitor and controls the CPU card. These indicators and switches include:

- Power button
- Reset
- Power LED
- HDD LED




Figure 3-10: Front Panel Connector Pinout Locations (8-pin)

FUNCTION	PIN	DESCRIPTION	FUNCTION	PIN	DESCRIPTION
Power Button	1	PWR_BTN+	Power LED	2	PWR_LED+
	3	PWR_BTN-		4	PWR_LED-
HDD LED	5	HDD_LED+	Reset	6	RESET+
	7	HDD_LED-		8	RESET-

Table 3-10: Front Panel Connector Pinouts (8-pin)

3.2.9 Infrared Interface Connector

CN Label: IR1

CN Type: 5-pin header (1x5)

CN Location: See Figure 3-11

CN Pinouts: See Table 3-11

The infrared interface connector supports both Serial Infrared (SIR) and Amplitude Shift Key Infrared (ASKIR) interfaces.




Figure 3-11: Infrared Connector Pinout Locations

Pin	Description
1	VCC
2	NC
3	IR-RX
4	GND
5	IR-TX

Table 3-11: Infrared Connector Pinouts

3.2.10 Keyboard/Mouse Connector

- CN Label:** KB/MS1
- CN Type:** 6-pin header (1x6)
- CN Location:** See Figure 3-12
- CN Pinouts:** See Table 3-12

The keyboard and mouse connector can be connected to a standard PS/2 cable or PS/2 Y-cable to add keyboard and mouse functionality to the system.




Figure 3-12: Keyboard/Mouse Connector Location

Pin	Description
1	VCC5_KBMS
2	MS DATA
3	MS CLK
4	KB DATA
5	KB CLK
6	GROUND

Table 3-12: Keyboard/Mouse Connector Pinouts

3.2.11 LVDS LCD Connector

CN Label: LVDS1

CN Type: 20-pin crimp (2x10)

CN Location: See Figure 3-13

CN Pinouts: See 790H Table 3-13

The 20-pin LVDS LCD connector can be connected to a single channel, 18-bit LVDS panel.




Figure 3-13: LVDS LCD Connector Pinout Location

Pin	Description	Pin	Description
1	GND	2	GND
3	LVDSA_DATA0	4	LVDSA_DATA#0
5	LVDSA_DATA1	6	LVDSA_DATA#1
7	LVDSA_DATA2	8	LVDSA_DATA#2
9	LVDSA_CLK	10	LVDSA_CLK#
11	NC	12	NC
13	GND	14	GND
15	L_DDC_DATA	16	L_DDC_CLK
17	VCC_LCD	18	VCC_LCD
19	VCC_LCD	20	VCC_LCD

Table 3-13: TFT LCD LVDS Port Connector Pinouts

3.2.12 Parallel Port Connector

CN Label: LPT1

CN Type: 26-pin header

CN Location: See Figure 3-14

CN Pinouts: See Table 3-14

The 26-pin parallel port connector connects to a parallel port connector interface or some other parallel port device such as a printer.




Figure 3-14: Parallel Port Connector Location

Pin	Description	Pin	Description
1	STB	2	AFD
3	PTD0	4	ERROR#
5	PTD1	6	INITIALIZE
7	PTD 2	8	SLIN
9	PTD3	10	GROUND
11	PTD 4	12	GROUND
13	PTD 5	14	GROUND
15	PTD 6	16	GROUND
17	PTD7	18	GROUND
19	ACK	20	GROUND
21	BUSY	22	GROUND
23	PE	24	GROUND
25	SLCT	26	NC

Table 3-14: Parallel Port Connector Pinouts

3.2.13 SATA Drive Connectors

- CN Label:** SATA1, SATA2, SATA3
- CN Type:** 7-pin SATA drive connectors
- CN Location:** See Figure 3-15
- CN Pinouts:** See Table 3-15

The SATA connectors connect to SATA hard drives or optical drives with data transfer speeds as high as 3 Gb/s.




Figure 3-15: SATA Drive Connector Locations

Pin	Description
1	GND
2	TX +
3	TX -
4	GND
5	RX -
6	RX +
7	GND

Table 3-15: SATA Drive Connector Pinouts

3.2.14 Serial Port Connectors (COM 1, COM 2 and COM 4)

- CN Label:** COM1, COM2 and COM4
- CN Type:** 10-pin header (2x5)

CN Location: See Figure 3-16

CN Pinouts: See Table 3-16

The 10-pin serial port connectors provide three RS-232 serial communications channels. The COM serial port connectors can be connected to external RS-232 serial port devices.




Figure 3-16: COM Connector Pinout Locations

Pin	Description	Pin	Description
1	DCD #	2	DSR #
3	RXD #	4	RTS #
5	TXD #	6	CTS #
7	DTR #	8	RI #
9	GND	10	N/A

Table 3-16: COM Connector Pinouts

3.2.15 Serial Port Connector (RS-232/422/485)

CN Label: COM3

CN Type: 14-pin header (2x7)

CN Location: See **Figure 3-17**

CN Pinouts: See **Table 3-17**

Used for RS-232/422/485 communications.




Figure 3-17: Serial Port Connector Location

Pin	Description	Pin	Description
1	DCD	2	DSR2
3	RXD	4	RTS2
5	TXD	6	CTS2
7	DTR	8	RI2
9	GND	10	N/A
11	RS422 TX2/485+	12	RS422 TX2/485-
13	RS422 RX2+	14	RS422 RX2-

Table 3-17: Serial Port Connector Pinouts

3.2.16 SMBus Connector

CN Label:	CN1
CN Type:	4-pin wafer (1x4)
CN Location:	See Figure 3-18
CN Pinouts:	See Table 3-18

The SMBus Connector provides a connection to a SMBus (System Management Bus) device.




Figure 3-18: SMBus Connector Locations

Pin	Description
1	GND
2	SMBDATA
3	SMBCLK
4	VCC5S

Table 3-18: SMBus Connector Pinouts

3.2.17 SPI Flash Connector

CN Label: SPI1

CN Type: 8-pin header (2x3)

CN Location: See Figure 3-19

CN Pinouts: See Table 3-19

The 8-pin SPI Flash connector is used to flash the BIOS.




Figure 3-19: SPI Flash Connector

Pin	Description	Pin	Description
1	SPI_VCC	2	GND
3	SPI_CS	4	SPI_CLK
5	SPI_SO	6	SPI_SI
7	NC	8	NC

Table 3-19: SPI Flash Connector

3.2.18 USB Connectors (Internal)

CN Label: USB0_1, USB2_3 and USB4_5

CN Type: 8-pin header (2x4)

CN Location: See Figure 3-20

CN Pinouts: See Table 3-20

The 2x4 USB pin connectors each provide connectivity to two USB 1.1 or two USB 2.0 ports. Each USB connector can support two USB devices. Additional external USB ports are found on the rear panel. The USB ports are used for I/O bus expansion.




Figure 3-20: USB Connector Pinout Locations

Pin	Description	Pin	Description
1	VCC	2	GND
3	DATA-	4	DATA+
5	DATA+	6	DATA-
7	GND	8	VCC

Table 3-20: USB Port Connector Pinouts

3.3 External Peripheral Interface Connector Panel

Figure 3-21 shows the PIC0e-PV-D4251/N4551/D5251 external peripheral interface connector (EPIC) panel. The PIC0e-PV-D4251/N4551/D5251 EPIC panel consists of the following:

- 2 x RJ-45 LAN connectors
- 1 x PS/2 connector
- 1 x USB connector
- 1 x VGA connector




Figure 3-21: PIC0e-PV-D4251/N4551/D5251 External Peripheral Interface Connector

3.3.1 Keyboard/Mouse Connector

CN Label:	PT1
CN Type:	PS/2
CN Location:	See Figure 3-21
CN Pinouts:	See Figure 3-22, Table 3-21

The PIC0e-PV-D4251/N4551/D5251 keyboard and mouse connector is a standard PS/2 connector.




Figure 3-22: PS/2 Pinout and Configuration

Pin	Description
1	KB DATA
2	MS DATA
3	GND
4	VCC
5	KB CLOCK
6	MS CLOCK

Table 3-21: Keyboard Connector Pinouts

3.3.2 LAN Connectors

CN Label: LAN1 and LAN2

CN Type: RJ-45

CN Location: See Figure 3-21

CN Pinouts: See Table 3-22

The PIC0e-PV-D4251/N4551/D5251 is equipped with two built-in RJ-45 Ethernet controllers. The controllers can connect to the LAN through two RJ-45 LAN connectors. There are two LEDs on the connector indicating the status of LAN. The pin assignments are listed in the following table:

Pin	Description	Pin	Description
1	MDIA3-	5	MDIA1+
2	MDIA3+	6	MDIA2+
3	MDIA2-	7	MDIA0-
4	MDIA1-	8	MDIA0+

Table 3-22: LAN Pinouts




Figure 3-23: RJ-45 Ethernet Connector

The RJ-45 Ethernet connector has two status LEDs, one yellow (activity/link) and one green/orange (speed). The yellow LED indicates activity/link on the port and the green/orange LED indicates the connection speed. See **Table 3-23**.

ACT/LINK LED		SPEED LED	
STATUS	DESCRIPTION	STATUS	DESCRIPTION
OFF	No Link	OFF	10 Mbps connection
YELLOW	Link	GREEN	100 Mbps connection
BLINKING	Data activity	ORANGE	1000 Mbps connection

Table 3-23: RJ-45 Ethernet Connector LEDs

3.3.3 USB Connectors

CN Label: USB6

CN Type: USB port

CN Location: See Figure 3-21

CN Pinouts: See Table 3-24

The PIC0e-PV-D4251/N4551/D5251 has two external USB 2.0 ports. The ports connect to both USB 2.0 and USB 1.1 devices.

Pin	Description
1	VCC
2	DATA-
3	DATA+
4	GND
5	GND
6	GND
7	GND
8	GND

Table 3-24: USB Port Pinouts

3.3.4 VGA Connector

- CN Label:** VGA1
- CN Type:** 15-pin Female
- CN Location:** See Figure 3-21
- CN Pinouts:** See Figure 3-24 and Table 3-25

The PIC0e-PV-D4251/N4551/D5251 has a single 15-pin female connector for connectivity to standard display devices.




Figure 3-24: VGA Connector

Pin	Description	Pin	Description
1	RED	2	GREEN
3	BLUE	4	NC
5	GND	6	CRT_PLUG-
7	GND	8	GND
9	VCC	10	GND
11	NC	12	DDC DAT
13	HSYNC	14	VSYSNC
15	DDCCLK		

Table 3-25: VGA Connector Pinouts



Chapter

4

Installation

4.1 Anti-static Precautions



WARNING:

Failure to take ESD precautions during the installation of the PICOe-PV-D4251/N4551/D5251 may result in permanent damage to the PICOe-PV-D4251/N4551/D5251 and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the PICOe-PV-D4251/N4551/D5251. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the PICOe-PV-D4251/N4551/D5251 or any other electrical component is handled, the following anti-static precautions are strictly adhered to.

- ***Wear an anti-static wristband:*** Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- ***Self-grounding:*** Before handling the board, touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- ***Use an anti-static pad:*** When configuring the PICOe-PV-D4251/N4551/D5251, place it on an anti-static pad. This reduces the possibility of ESD damaging the PICOe-PV-D4251/N4551/D5251.
- ***Only handle the edges of the PCB:*** When handling the PCB, hold the PCB by the edges.

4.2 Installation Considerations



NOTE:

The following installation notices and installation considerations should be read and understood before the PICOe-PV-D4251/N4551/D5251 is installed. All installation notices pertaining to the installation of the PICOe-PV-D4251/N4551/D5251 should be strictly adhered to. Failing to adhere to these precautions may lead to severe damage of the PICOe-PV-D4251/N4551/D5251 and injury to the person installing the CPU card.

4.2.1 Installation Notices



WARNING:

The installation instructions described in this manual should be carefully followed in order to prevent damage to the PICOe-PV-D4251/N4551/D5251, PICOe-PV-D4251/N4551/D5251 components and injury to the user.

Before and during the installation please **DO** the following:

- Read the user manual:
 - The user manual provides a complete description of the PICOe-PV-D4251/N4551/D5251 installation instructions and configuration options.
- Wear an electrostatic discharge cuff (ESD):
 - Electronic components are easily damaged by ESD. Wearing an ESD cuff removes ESD from the body and helps prevent ESD damage.
- Place the PICOe-PV-D4251/N4551/D5251 on an antistatic pad:
 - When installing or configuring the CPU card, place it on an antistatic pad. This helps to prevent potential ESD damage.

- Turn all power to the PIC0e-PV-D4251/N4551/D5251 off:
 - When working with the PIC0e-PV-D4251/N4551/D5251, make sure that it is disconnected from all power supplies and that no electricity is being fed into the system.

Before and during the installation of the PIC0e-PV-D4251/N4551/D5251 **DO NOT:**

- Remove any of the stickers on the PCB board. These stickers are required for warranty validation.
- Use the product before verifying all the cables and power connectors are properly connected.
- Allow screws to come in contact with the PCB circuit, connector pins, or its components.

4.2.2 Installation Checklist

The following checklist is provided to ensure the PIC0e-PV-D4251/N4551/D5251 is properly installed.

- All the items in the packing list are present
- A compatible memory module is properly inserted into the slot
- The CF Type I or CF Type II card is properly installed into the CF socket
- The jumpers have been properly configured
- The PIC0e-PV-D4251/N4551/D5251 is inserted into a chassis with adequate ventilation
- The correct power supply is being used
- The following devices are properly connected
 - Primary and secondary IDE device
 - SATA drives
 - Power supply
 - USB cable
 - Serial port cable
- The following external peripheral devices are properly connected to the chassis:
 - VGA screen
 - Keyboard

- ☐ Mouse
- ☐ RS-232 serial communications device
- ☐ USB devices

4.3 Unpacking

When the PIC0e-PV-D4251/N4551/D5251 is unpacked, please check all the unpacking list items listed in Chapter 3 are indeed present. If any of the unpacking list items are not available please contact the PIC0e-PV-D4251/N4551/D5251 vendor reseller/vendor where the PIC0e-PV-D4251/N4551/D5251 was purchased or contact an IEI sales representative.

4.4 SO-DIMM and CF Card Installation

4.4.1 SO-DIMM Installation



WARNING:

Using incorrectly specified SO-DIMM may cause permanently damage the PIC0e-PV-D4251/N4551/D5251. Please make sure the purchased SO-DIMM complies with the memory specifications of the PIC0e-PV-D4251/N4551/D5251. SO-DIMM specifications compliant with the PIC0e-PV-D4251/N4551/D5251 are listed in the specification table of Chapter 1.

It is required that when adding additional memory that the SO-DIMM match the DRAM organization of the onboard memory which is 128 MB x8 (or 256 MB x8 for maximum 2GB). The system will not boot if a SO-DIMM module that does not match this DRAM organization is installed.

To install a SO-DIMM into a SO-DIMM socket, please follow the steps below and refer to **Figure 4-1**.




Figure 4-1: SO-DIMM Installation

- Step 1:** Locate the **SO-DIMM** socket. Place the PICOe-PV-D4251/N4551/D5251 on an anti-static pad with the solder side facing up.
- Step 2:** Align the **SO-DIMM** with the socket. The SO-DIMM must be oriented in such a way that the notch in the middle of the SO-DIMM must be aligned with the plastic bridge in the socket.
- Step 3:** Insert the **SO-DIMM**. Push the SO-DIMM chip into the socket at an angle. (See **Figure 4-1**)
- Step 4:** Open the **SO-DIMM** socket arms. Gently pull the arms of the SO-DIMM socket out and push the rear of the SO-DIMM down. (See **Figure 4-1**)
- Step 5:** Secure the **SO-DIMM**. Release the arms on the SO-DIMM socket. They clip into place and secure the SO-DIMM in the socket.

4.4.2 CF Card Installation



NOTE:

The PICOe-PV-D4251/N4551/D5251 can support both CF Type I cards and CF Type II cards. For the complete specifications of the supported CF cards please refer to Chapter 2.

To install a CF card (Type I or Type II) onto the PICOe-PV-D4251/N4551/D5251, please follow the steps below:

- Step 1:** **Locate the CF card socket.** Place the PICOe-PV-D4251/N4551/D5251 on an anti-static pad with the solder side facing up. Locate the CF card.
- Step 2:** **Align the CF card.** Make sure the CF card is properly aligned with the CF socket.
- Step 3:** **Insert the CF card.** Gently insert the CF card into the socket making sure the socket pins are properly inserted into the socket. See **Figure 4-2**.





Figure 4-2: CF Card Installation

4.5 Jumper Settings



NOTE:

A jumper is a metal bridge used to close an electrical circuit. It consists of two or three metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To CLOSE/SHORT a jumper means connecting the pins of the jumper with the plastic clip and to OPEN a jumper means removing the plastic clip from a jumper.



Before the PIC0e-PV-D4251/N4551/D5251 is installed in the system, the jumpers must be set in accordance with the desired configuration. The jumpers on the PIC0e-PV-D4251/N4551/D5251 are listed in **Table 4-1**.

Description	Label	Type
AT Power Mode Setting	ATXCTL1	2-pin header
CF Card Setting	JCF1	2-pin header
CF Card Voltage Select	J_VCF1	3-pin header
Clear CMOS	J_CMOS1	3-pin header
LVDS Voltage Select	J_VLVDS1	3-pin header
PCIe Status Select	JP1	2-pin header
RS-232/422/485 Select	J1	6-pin header
RS-422/485 Select	J2	6-pin header
RS-422 Termination Select	J4	2-pin header
RS-485 Termination Select	J3	2-pin header

Table 4-1: Jumpers

4.5.1 AT Power Select Jumper

**NOTE:**

The AT Power Select Jumper is the same as the ATX Enable connector.

Jumper Label:	ATXCTL1
Jumper Type:	3-pin wafer
Jumper Settings:	See Table 4-2
Jumper Location:	See Figure 4-3

The AT Power Select jumper specifies the systems power mode as AT or ATX. Use a jumper cap to short pin 2 and 3 on the ATXCTL1 connector to enable the AT Power mode. In the ATX mode use the PS_ON- and 5VSB cable to connect to the ATX control connector on the backplane. AT Power Select jumper settings are shown in **Table 4-2**.

AT Power Select	Description	
Short 2 – 3	Use AT power	Default
Open	Use ATX power	

Table 4-2: AT Power Select Jumper Settings

The location of the AT Power Select jumper is shown in **Figure 4-3** below.




Figure 4-3: AT Power Select Jumper Location

4.5.2 CF Card Setup Jumper

Jumper Label:	JCF1
Jumper Type:	2-pin header
Jumper Settings:	See Table 4-3
Jumper Location:	See Figure 4-4

The CF Card Setup jumper sets the CF Type I card or CF Type II cards as either the slave device or the master device. CF Card Setup jumper settings are shown in **Table 4-3**.

CF Card Setup	Description	
Open	Slave	Default
Closed	Master	

Table 4-3: CF Card Setup Jumper Settings




Figure 4-4: CF Card Setup Jumper Location

4.5.3 CF Card Voltage Select Jumper

Jumper Label:	J_VCF1
Jumper Type:	3-pin header
Jumper Settings:	See Table 4-4
Jumper Location:	See Figure 4-5

The CF Card Voltage Setup jumper sets the CF Card Voltage.

CF Card Voltage Setup	Description	
1-2	5V	
2-3	3.3V	Default

Table 4-4: CF Card Voltage Select Jumper Settings

The CF Card Setup jumper location is shown in **Figure 4-5**.




Figure 4-5: CF Card Voltage Select Jumper Location

4.5.4 Clear CMOS Jumper

Jumper Label:	J_CMOS1
Jumper Type:	3-pin header
Jumper Settings:	See Table 4-5
Jumper Location:	See Figure 4-6

If the PIC0e-PV-D4251/N4551/D5251 fails to boot due to improper BIOS settings, the clear CMOS jumper clears the CMOS data and resets the system BIOS information. To do this, use the jumper cap to close pins 2 and 3 for a few seconds then reinstall the jumper clip back to pins 1 and 2.

If the “CMOS Settings Wrong” message is displayed during the boot up process, the fault may be corrected by pressing the F1 to enter the CMOS Setup menu. Do one of the following:

- Enter the correct CMOS setting
- Load Optimal Defaults
- Load Failsafe Defaults.

After having done one of the above, save the changes and exit the CMOS Setup menu.

The clear CMOS jumper settings are shown in **Table 4-5**.

Clear CMOS	Description	
Short 1 - 2	Keep CMOS Setup	Default
Short 2 - 3	Clear CMOS Setup	

Table 4-5: Clear CMOS Jumper Settings

The location of the clear CMOS jumper is shown in **Figure 4-6** below.




Figure 4-6: Clear CMOS Jumper

4.5.5 LVDS Voltage Select Jumper



WARNING:

Permanent damage to the screen and PICOe-PV-D4251/N4551/D5251 may occur if the wrong voltage is selected with this jumper. Please refer to the user guide that came with the monitor to select the correct voltage.


Jumper Label:	J_VLVDS1
Jumper Type:	6-pin header
Jumper Settings:	See Table 4-6
Jumper Location:	See Figure 4-7

The **LVDS Voltage Selection** jumpers allow the LVDS screen voltages to be set. J_VLVDS1 sets the voltage connected to LVDS1. The **LVDS Voltage Selection** jumper settings are shown in **Table 4-6**.

LCD Voltage Select	Description	
Short 1-2	+3.3V	Default
Short 3-4	+5V	
Short 5-6	+12V	

Table 4-6: LVDS Voltage Selection Jumper Settings

The LVDS Voltage Selection jumper location is shown in **Figure 4-7**.


Figure 4-7: LVDS Voltage Selection Jumper Pinout Locations

4.5.6 PCIe Status Select Jumper

Jumper Label:	JP1
Jumper Type:	2-pin header
Jumper Settings:	See Table 4-7
Jumper Location:	See Figure 4-8

The **PCIe Status Select** jumper allows the PCIe status to be configured. The **PCIe Status Select** jumper settings are shown in **Table 4-6**.

PCIe Status Select	Description	
Open	One PCIe x4	
Short	Four PCIe x1	Default

Table 4-7: PCIe Status Select Jumper Settings

The PCIe Status Select jumper location is shown in **Figure 4-7**.




Figure 4-8: PCIe Status Select Jumper Pinout Locations

4.5.7 COM 3 Function Select Jumpers

Jumper Label:	J1 and J2
Jumper Type:	6-pin headers
Jumper Settings:	See Table 4-8 and Table 4-9
Jumper Location:	See Figure 4-9

The COM 3 Function Select jumpers set the communication protocol used by the COM 3 serial communications port as RS-232, RS-422 or RS-485. The COM 3 Function Select settings are shown in **Table 4-9**.

J1 Setting	Description
1-2	RS-232 (Default)
3-4	RS-422
5-6	RS-485
Table 4-8: COM 3 Function Select Jumpers Settings	

J2 Setting	Description
1-3, 2-4	RS-422 (Default)
3-5, 4-6	RS-485

Table 4-9: COM 3 Function Select Jumpers Settings




Figure 4-9: COM 3 Function Select Jumpers Locations

4.5.8 COM 3 RS-422 and 485 Termination Select Jumpers

Jumper Label:	J3 and J4
Jumper Type:	2-pin header
Jumper Settings:	See Table 4-10 and Table 4-11
Jumper Location:	See Figure 4-10

The COM 3 RS-485 and RS422 Termination Select jumpers enable or disable the termination used by the serial COM 3 communications port as 120 ohm. The COM 3 RS-485 and RS-422 Termination Select settings are shown in **Table 4-10** and **Table 4-11**.

RS-485 (J3) Setting	Description
Short	120 ohm termination
Open	No 120 ohm termination

Table 4-10: COM 3 RS-485 Termination Select Jumper Settings

RS-422 (J4) Setting	Description
Short	120 ohm termination
Open	No 120 ohm termination

Table 4-11: COM 3 RS-422 Termination Select Jumper Settings




Figure 4-10: COM 3 RS-485 and RS422 Termination Select Jumper Location

4.6 Chassis Installation

4.6.1 Airflow



WARNING:

Airflow is critical to the cooling of the CPU and other onboard components. The chassis in which the PICOe-PV-D4251/N4551/D5251 must have air vents to allow cool air to move into the system and hot air to move out.

The PICOe-PV-D4251/N4551/D5251 must be installed in a chassis with ventilation holes on the sides allowing airflow to travel through the heat sink surface. In a system with an individual power supply unit, the cooling fan of a power supply can also help generate airflow through the board surface.

4.6.2 Backplane Installation

Before the PICOe-PV-D4251/N4551/D5251 can be installed into the chassis, a backplane must first be installed. Please refer to the installation instructions that came with the backplane and the chassis to see how to install the backplane into the chassis.


NOTE:

IEI has a wide range of backplanes available. Please contact your PIC0e-PV-D4251/N4551/D5251 vendor, reseller or an IEI sales representative at sales@iei.com.tw or visit the IEI website (<http://www.ieiworld.com.tw>) to find out more about the available chassis.

4.6.3 CPU Card Installation

To install the PIC0e-PV-D4251/N4551/D5251 CPU card onto the backplane, carefully align the CPU card interface connectors with the corresponding socket on the backplane. To do this, please refer to the reference material that came with the backplane. Next, secure the CPU card to the chassis. To do this, please refer to the reference material that came with the chassis.

4.7 Internal Peripheral Device Connections

4.7.1 Peripheral Device Cables

The cables listed in **Table 4-12** are shipped with the PIC0e-PV-D4251/N4551/D5251.

Quantity	Type
1	Keyboard and Mouse Y cable
3	SATA drive cable
1	Dual port USB cable
1	Dual RS-232 cable

Table 4-12: IEI Provided Cables

Some optional items that can be purchased separately and installed on the PIC0e-PV-D4251/N4551/D5251 include:

- SATA power cable
- Parallel port cable
- 7.1 channel audio kit

4.7.2 Audio Kit Installation

**NOTE:**

This is an optional item that must be ordered separately. For further information please contact the nearest PICOe-PV-D4251/N4551/D5251 distributor, reseller or vendor or contact an iEi sales representative directly. Send any queries to sales@iei.com.tw.

The optional 7.1 channel audio kit connects to the 10-pin audio connector on the PICOe-PV-D4251/N4551/D5251. The audio kit consists of five audio jacks. One audio jack, Mic In, connects to a microphone. The remaining four audio jacks, Line-In, Front-Out, Rear-Out, and Center Subwoofer, connect to speakers. To install the audio kit, please refer to the steps below:

- Step 1: Connect the audio kit cable.** The audio kit is shipped with a cable that connects the audio kit to the PICOe-PV-D4251/N4551/D5251. Connect the cable to the connector on the back of the audio kit. Make sure the pins are properly aligned (i.e. pin 1 connects to pin 1).
- Step 2: Locate the audio connector.** The location of the 10-pin audio connector is shown in **Chapter 3**.
- Step 3: Align pin 1.** Align pin 1 on the on-board connector with pin 1 on the audio kit cable connector. Pin 1 on the audio kit cable connector is indicated with a white dot. See Figure 4-11.




Figure 4-11: 7.1 Channel Audio Kit

Step 4: **Mount the audio kit onto the chassis.** Once the audio kit is connected to the PICOe-PV-D4251/N4551/D5251, secure the audio kit bracket to the system chassis.

Step 5: **Connect the audio devices.** Connect one speaker to the line-in audio jack, one speaker to the line-out audio jack and a microphone to the mic-in audio jack.

Step 6: **Install the driver.** If the 7.1 channel audio kit is used, the ALC883 Realtek codec driver must be installed. Refer to **Section 4.9** for driver installation instructions.

4.7.3 SATA Drive Connection

The PICOe-PV-D4251/N4551/D5251 is shipped with two SATA drive cables and one SATA drive power cable. To connect the SATA drives to the connectors, please follow the steps below.

Step 1: **Locate the connectors.** The locations of the SATA drive connectors are shown in **Chapter 3**.

Step 2: **Insert the cable connector.** Press the clip on the connector at the end of the

SATA cable and insert the cable connector into the onboard SATA drive connector. See **Figure 4-12**.




Figure 4-12: SATA Drive Cable Connection

- Step 3:** Connect the cable to the SATA disk. Connect the connector on the other end of the cable to the connector at the back of the SATA drive. See **Figure 4-13**.
- Step 4:** Connect the SATA power cable. Connect the SATA power connector to the back of the SATA drive. See **Figure 4-13**.



Figure 4-13: SATA Power Drive Connection

4.7.4 USB Cable (Dual Port) with Slot Bracket

The PICOe-PV-D4251/N4551/D5251 is shipped with a dual port USB 2.0 cable. To connect the USB cable connector, please follow the steps below.

Step 1: Locate the connectors. The locations of the USB connectors are shown in Chapter 3.



WARNING:

If the USB pins are not properly aligned, the USB device can burn out.

Step 2: Align the connectors. The cable has two connectors. Correctly align pin 1 on each cable connector with pin 1 on the PICOe-PV-D4251/N4551/D5251 USB connector.

Step 3: Insert the cable connectors Once the cable connectors are properly aligned with the USB connectors on the PICOe-PV-D4251/N4551/D5251, connect the cable connectors to the on-board connectors. See **Figure 4-14**.




Figure 4-14: Dual USB Cable Connection

Step 4: **Attach the bracket to the chassis.** The USB 2.0 connectors are attached to a bracket. To secure the bracket to the chassis please refer to the installation instructions that came with the chassis.

4.7.5 Parallel Port Cable without Bracket

The optional parallel port (LPT) cable respectively connects the on-board LPT 26-pin box header to an external LPT device (like a printer). The cable comprises a 26-pin female header, to be connected to the on-board LPT box-header, on one side and on the other side a standard external LPT connector. To connect the LPT cable, please follow the steps below.

Step 1: **Locate the connector.** The LPT connector location is shown in **Chapter 4**.

Step 2: **Align the connectors.** Correctly align pin 1 on the cable connector with pin 1 on

the PICOe-PV-D4251/N4551/D5251 LPT box-header connector. See Figure 4-15.

Step 3: Insert the cable connectors Once the cable connector is properly aligned with the 26-pin box-header connector on the PICOe-PV-D4251/N4551/D5251, connect the cable connector to the on-board connector. See **Figure 4-15**.




Figure 4-15: LPT Cable Connection

Step 4: Attach the LPT connector to the chassis. To secure the LPT interface connector to the chassis please refer to the installation instructions that came with the chassis.

Step 5: Connect LPT device. Once the LPT interface connector is connected to the chassis, the LPT device can be connected to the LPT interface connector. See **Figure 4-16**




Figure 4-16: Connect the LPT Device

4.7.6 Dual RS-232 Cable with Slot Bracket

The dual RS-232 cable slot connector consists of two connectors attached to two independent cables. Each cable is then attached to a D-sub 9 male connector that is mounted onto a slot. To install the dual RS-232 cable, please follow the steps below.

Step 1: **Locate the connectors.** The locations of the RS-232 connectors are shown in Chapter 3.

Step 2: **Insert the cable connectors.** Insert one connector into each serial port box headers. See **Figure 4-17**. A key on the front of the cable connectors ensures the connector can only be installed in one direction.




Figure 4-17: Dual RS-232 Cable Installation

Step 3: Secure the bracket. The dual RS-232 connector has two D-sub 9 male connectors secured on a bracket. To secure the bracket to the chassis please refer to the reference material that came with the chassis

4.8 External Peripheral Interface Connection

The following external peripheral devices can be connected to the external peripheral interface connectors.

- RJ-45 Ethernet cable connectors
- PS/2 devices
- USB devices
- VGA monitors

To install these devices, connect the corresponding cable connector from the actual device to the corresponding PICOe-PV-D4251/N4551/D5251 external peripheral interface connector making sure the pins are properly aligned.

4.8.1 LAN Connection

There are two external RJ-45 LAN connectors. The RJ-45 connectors enable connection to an external network. To connect a LAN cable with an RJ-45 connector, please follow the instructions below.

Step 1: **Locate the RJ-45 connectors.** The locations of the USB connectors are shown in **Chapter 4**.

Step 2: **Align the connectors.** Align the RJ-45 connector on the LAN cable with one of the RJ-45 connectors on the PICOe-PV-D4251/N4551/D5251. See **Figure 4-18**.




Figure 4-18: LAN Connection

Step 3: **Insert the LAN cable RJ-45 connector.** Once aligned, gently insert the LAN cable RJ-45 connector into the onboard RJ-45 connector.

4.8.2 PS/2 Y-Cable Connection

The PICOe-PV-D4251/N4551/D5251 has a PS/2 connector on the external peripheral interface panel. The dual PS/2 connector is connected to the PS/2 Y-cable that came with the PICOe-PV-D4251/N4551/D5251. One of the PS/2 cables is connected to a keyboard and the other to a mouse to the system. Follow the steps below to connect a keyboard and mouse to the PICOe-PV-D4251/N4551/D5251.

Step 1: Locate the dual PS/2 connector. The location of the PS/2 connector is shown in **Chapter 3**.

Step 2: Insert the keyboard/mouse connector. Insert the PS/2 connector on the end of the PS/2 y-cable into the external PS/2 connector. See **Figure 4-19**.




Figure 4-19: PS/2 Keyboard/Mouse Connector

Step 3: Connect the keyboard and mouse. Connect the keyboard and mouse to the appropriate connector. The keyboard and mouse connectors can be distinguished from each other by looking at the small graphic at the top of the connector.

4.8.3 USB Connection

The external USB Series "A" receptacle connector provides easier and quicker access to external USB devices. Follow the steps below to connect USB devices to the PICOe-PV-D4251/N4551/D5251.

Step 1: Locate the USB Series "A" receptacle connectors. The location of the USB

Series "A" receptacle connectors are shown in **Chapter 3**.

Step 2: **Insert a USB Series "A" plug.** Insert the USB Series "A" plug of a device into the USB Series "A" receptacle on the external peripheral interface. See **Figure 4-20**.




Figure 4-20: USB Connector

4.8.4 VGA Monitor Connection

The PICOe-PV-D4251/N4551/D5251 has a single female DB-15 connector on the external peripheral interface panel. The DB-15 connector is connected to a CRT or VGA monitor. To connect a monitor to the PICOe-PV-D4251/N4551/D5251, please follow the instructions below.

Step 1: **Locate the female DB-15 connector.** The location of the female DB-15 connector is shown in **Chapter 3**.

Step 2: **Align the VGA connector.** Align the male DB-15 connector on the VGA screen cable with the female DB-15 connector on the external peripheral interface.

Step 3: Insert the **VGA connector**. Once the connectors are properly aligned with the insert the male connector from the VGA screen into the female connector on the PICOe-PV-D4251/N4551/D5251. See **Figure 4-21**.




Figure 4-21: VGA Connector

Step 4: **Secure the connector**. Secure the DB-15 VGA connector from the VGA monitor to the external interface by tightening the two retention screws on either side of the connector.

4.9 Software Installation

All the drivers for the PICOe-PV-D4251/N4551/D5251 are on the CD that came with the system. To install the drivers, please follow the steps below.

Step 1: Insert the CD into a CD drive connected to the system.



NOTE:

If the installation program doesn't start automatically:
Click "Start->My Computer->CD Drive->autorun.exe"

PIC0e-PV-D4251/N4551/D5251 User Manual

Step 2: The driver main menu appears (**Figure 4-22**).




Figure 4-22: Introduction Screen

Step 3: Click **PIC0e-PV-D4251/N4551/D5251**.

Step 4: A new screen with a list of available drivers appears (**Figure 4-23**).




Figure 4-23: Available Drivers

Step 5: Install all of the necessary drivers in this menu.

Chapter

5

BIOS Screens

5.1 Introduction

The BIOS is programmed onto the BIOS chip. The BIOS setup program allows changes to certain system settings. This chapter outlines the options that can be changed.

5.1.1 Starting Setup

The AMI BIOS is activated when the computer is turned on. The setup program can be activated in one of two ways.

1. Press the **DELETE** key as soon as the system is turned on or
2. Press the **DELETE** key when the “**Press Del to enter SETUP**” message appears on the screen.

If the message disappears before the **DELETE** key is pressed, restart the computer and try again.

5.1.2 Using Setup

Use the arrow keys to highlight items, press **ENTER** to select, use the PageUp and PageDown keys to change entries, press **F1** for help and press **Esc** to quit. Navigation keys are shown in.

Key	Function
Up arrow	Move to previous item
Down arrow	Move to next item
Left arrow	Move to the item on the left hand side
Right arrow	Move to the item on the right hand side
F1 key	General help, only for Status Page Setup Menu and Option Page Setup Menu
F2 key	Load previous values.
F3 key	Load optimized defaults

Key	Function
F4 key	Save all the CMOS changes
Esc key	Main Menu – Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu

Table 5-1: BIOS Navigation Keys

5.1.3 Getting Help

When **F1** is pressed a small help window describing the appropriate keys to use and the possible selections for the highlighted item appears. To exit the Help Window press **Esc** or the **F1** key again.

5.1.4 Unable to Reboot After Configuration Changes

If the computer cannot boot after changes to the system configuration is made, CMOS defaults. Use the jumper described in Chapter 4.

5.1.5 BIOS Menu Bar

The **menu bar** on top of the BIOS screen has the following main items:

- Main – Changes the basic system configuration.
- Advanced – Changes the advanced system settings.
- Chipset – Changes the chipset settings.
- Boot – Changes the system boot configuration.
- Security – Sets User and Supervisor Passwords.
- Save & Exit – Selects exit options and loads default settings

The following sections completely describe the configuration options found in the menu items at the top of the BIOS screen and listed above.

5.2 Main

The **Main** BIOS menu (**BIOS Menu 1**) appears when the **BIOS Setup** program is entered.

The **Main** menu gives an overview of the basic system information.

Aptio Setup Utility - Copyright (C) 2010 American Megatrends, Inc.		
Advanced Chipset Boot Security Save & Exit		
BIOS Information		
BIOS Vendor	American Megatrends	
Core Version	4.6.4.0 0.20	
Compliance	UEFI 2.0	
Project Version	SA26AR11.ROM	
Build Date	09/13/2010 20:20:59	
System Date	[Tue 09/23/2010]	
System Time	[14:20:27]	
Access Level	Administrator	
		←→: Select Screen ↑ ↓: Select Item Enter: Select F1 General Help F2 Previous Values F3 Optimized Defaults F4 Save ESC Exit
Version 2.02.1205. Copyright (C) 2010 American Megatrends, Inc.		

BIOS Menu 1: Main

→ BIOS Information

The **BIOS Information** lists a brief summary of the BIOS. The fields in **BIOS Information** cannot be changed. The items shown in the system overview include:

- **BIOS Vendor:** Installed BIOS vendor
- **Core Version:** Current BIOS version
- **Project Version:** the board version
- **Build Date:** Date the current BIOS version was made

The System Overview field also has two user configurable fields:

→ System Date [xx/xx/xx]

Use the **System Date** option to set the system date. Manually enter the day, month and year.

PIC0e-PV-D4251/N4551/D5251 User Manual

→ System Time [xx:xx:xx]

Use the **System Time** option to set the system time. Manually enter the hours, minutes and seconds.


5.3 Advanced

Use the **Advanced** menu (**BIOS Menu 2**) to configure the CPU and peripheral devices through the following sub-menus:



WARNING!


Setting the wrong values in the sections below may cause the system to malfunction. Make sure that the settings made are compatible with the hardware.



BIOS Menu 2: Advanced

5.3.1 ACPI Settings

The **ACPI Settings** menu (**BIOS Menu 3**) configures the Advanced Configuration and Power Interface (ACPI) options.



BIOS Menu 3: ACPI Settings

→ ACPI Sleep State [S3 (Suspend to RAM)]

Use the **ACPI Sleep State** option to specify the sleep state the system enters when it is not being used.

→ Suspend Disabled

→ S1 (CPU Stop Clock)

The system enters S1(POS) sleep state. The system appears off. The CPU is stopped; RAM is refreshed; the system is running in a low power mode.


→ S3 (Suspend to DEFAULT RAM)

The caches are flushed and the CPU is powered off. Power to the RAM is maintained. The computer returns slower to a working state, but more power is saved.

5.3.2 Trusted Computing

Use the **Trusted Computing** menu (**BIOS Menu 4**) to configure settings related to the Trusted Computing Group (TCG) Trusted Platform Module (TPM).

PICOe-PV-D4251/N4551/D5251 User Manual



BIOS Menu 4: TPM Configuration


→ TPM Support [Disable]

Use the **TPM Support** option to configure support for the TPM.

- **Disable** **DEFAULT** TPM support is disabled.
- **Enable** TPM support is enabled.

5.3.3 CPU Configuration

Use the **CPU Configuration** menu (**BIOS Menu 5**) to view detailed CPU specifications and configure the CPU.




BIOS Menu 5: CPU Configuration

The CPU Configuration menu (**BIOS Menu 5**) lists the following CPU details:

- Processor Type: Lists the brand name of the CPU being used
- EMT64: Indicates if the EM64T is supported by the CPU.
- Processor Speed: Lists the CPU processing speed
- System Bus: Lists the system bus
- Ratio Status: List the maximum FSB divisor
- Actual Ratio: Lists current FSB divisor
- Processor Stepping: Lists the CPU processing stepping
- Microcode Revision: Lists the microcode revision
- L1 Cache RAM: Lists the CPU L1 cache size
- L2 Cache RAM: Lists the CPU L2 cache size
- Processor Core: Lists the number of the processor core
- Hyper-Threading: Indicates if the Intel Hyper-Threading Technology is supported by the CPU.

5.3.4 SATA Configuration

Use the **SATA Configuration** menu (**BIOS Menu 6**) to change and/or set the configuration of the SATA devices installed in the system.



BIOS Menu 6: IDE Configuration

→ ATA/IDE Configurations [Enhanced]

Use the **ATA/IDE Configurations** option to configure the ATA/IDE controller.

- **Disabled** Disables the on-board ATA/IDE controller.
- **Compatible** Configures the on-board ATA/IDE controller to be in compatible mode. In this mode, a SATA channel will replace one of the IDE channels. This mode supports up to 4 storage devices.
- **Enhanced** **DEFAULT** Configures the on-board ATA/IDE controller to be in Enhanced mode. In this mode, IDE channels and SATA channels are separated. This mode supports up to 6 storage devices. Some legacy OS do not support this mode.


➔ **Configure SATA as [IDE]**

Use the **Configure SATA as** option to configure SATA devices as normal IDE devices.

- ➔ **IDE** **DEFAULT** Configures SATA devices as normal IDE device.
- ➔ **AHCI** Configures SATA devices as AHCI device.

5.3.5 USB Configuration

Use the **USB Configuration** menu (**BIOS Menu 7**) to read USB configuration information and configure the USB settings.



BIOS Menu 7: USB Configuration

➔ **USB Devices**

The **USB Devices Enabled** field lists the USB devices that are enabled on the system

➔ **Legacy USB Support [Enabled]**


Use the **Legacy USB Support** BIOS option to enable USB mouse and USB keyboard support. Normally if this option is not enabled, any attached USB mouse or USB keyboard does not become available until a USB compatible operating system is fully booted with all USB drivers loaded. When this option is enabled, any attached USB mouse or USB keyboard can control the system even when there is no USB driver loaded onto the system.

PIC0e-PV-D4251/N4551/D5251 User Manual

- | | | | |
|---|-----------------|----------------|---|
| ➔ | Enabled | DEFAULT | Legacy USB support enabled |
| ➔ | Disabled | | Legacy USB support disabled |
| ➔ | Auto | | Legacy USB support disabled if no USB devices are connected |

5.3.6 Super IO Configuration


Use the **Super IO Configuration** menu (**BIOS Menu 8**) to set or change the configurations for the FDD controllers, parallel ports and serial ports.



BIOS Menu 8: Super IO Configuration

5.3.6.1 Serial Port n Configuration

Use the **Serial Port n Configuration** menu (**BIOS Menu 9**) to configure the serial port n.



BIOS Menu 9: Serial Port n Configuration Menu

5.3.6.1.1 Serial Port 0 Configuration

➔ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled** Disable the serial port
- ➔ **Enabled** **DEFAULT** Enable the serial port

➔ Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.
- ➔ **IO=3F8h;**
IRQ=4 Serial Port I/O port address is 3F8h and the interrupt address is IRQ4

- ➔ **IO=3F8h;**
IRQ=3, 4 Serial Port I/O port address is 3F8h and the interrupt address is IRQ3 and IRQ4
- ➔ **IO=2F8h;**
IRQ=3, 4 Serial Port I/O port address is 2F8h and the interrupt address is IRQ3 and IRQ4

5.3.6.1.2 Serial Port 1 Configuration

➔ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled** Disable the serial port
- ➔ **Enabled** **DEFAULT** Enable the serial port

➔ Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.
- ➔ **IO=2F8h;**
IRQ=3 Serial Port I/O port address is 2F8h and the interrupt address is IRQ3
- ➔ **IO=3F8h;**
IRQ=3, 4 Serial Port I/O port address is 3F8h and the interrupt address is IRQ3 and IRQ4
- ➔ **IO=2F8h;**
IRQ=3, 4 Serial Port I/O port address is 2F8h and the interrupt address is IRQ3 and IRQ4

5.3.6.1.3 Serial Port 2 Configuration

➔ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled** Disable the serial port

➔ **Enabled** **DEFAULT** Enable the serial port

➔ **Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- | | | | |
|---|--------------------------------|----------------|---|
| ➔ | Auto | DEFAULT | The serial port IO port address and interrupt address are automatically detected. |
| ➔ | IO=3E8h;
IRQ=11 | | Serial Port I/O port address is 3E8h and the interrupt address is IRQ11 |
| ➔ | IO=3E8h;
IRQ=10, 11 | | Serial Port I/O port address is 3E8h and the interrupt address is IRQ10, 11 |
| ➔ | IO=2E8h;
IRQ=10, 11 | | Serial Port I/O port address is 2E8h and the interrupt address is IRQ10, 11 |

5.3.6.1.4 Serial Port 3 Configuration

➔ **Serial Port [Enabled]**

Use the **Serial Port** option to enable or disable the serial port.

- | | | | |
|---|-----------------|----------------|-------------------------|
| ➔ | Disabled | | Disable the serial port |
| ➔ | Enabled | DEFAULT | Enable the serial port |

➔ **Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.


- | | | | |
|---|-------------|----------------|---|
| ➔ | Auto | DEFAULT | The serial port IO port address and interrupt address are automatically detected. |
|---|-------------|----------------|---|

PIC0e-PV-D4251/N4551/D5251 User Manual

- ➔ **IO=2E8h;**
IRQ=10 Serial Port I/O port address is 2E8h and the interrupt address is IRQ10
- ➔ **IO=3E8h;**
IRQ=10, 11 Serial Port I/O port address is 3E8h and the interrupt address is IRQ10, 11
- ➔ **IO=2E8h;**
IRQ=10, 11 Serial Port I/O port address is 2E8h and the interrupt address is IRQ10, 11

5.3.6.2 IrDA Configuration

Use the **IrDA Configuration** menu (**BIOS Menu 9**) to configure the serial port n.



BIOS Menu 10: IrDA Configuration Menu


➔ **IrDA [Enabled]**

Use the **IrDA** option to enable or disable the infrared function.

- ➔ **Disabled** Disable the infrared function
- ➔ **Enabled** **DEFAULT** Enable the infrared function

5.3.6.3 Parallel Port Configuration

Use the **Parallel Port Configuration** menu (**BIOS Menu 9**) to configure the serial port n.



BIOS Menu 11: Parallel Port Configuration Menu

➔ Parallel Port [Enabled]

Use the **Parallel Port** option to enable or disable the parallel port.

- ➔ **Disabled** Disable the parallel port
- ➔ **Enabled** **DEFAULT** Enable the parallel port

➔ Change Settings [Auto]

Use the **Change Settings** option to change the parallel port IO port address and interrupt address.

- ➔ **Auto** **DEFAULT** The parallel port IO port address and interrupt address are automatically detected.
- ➔ **IO=378h; IRQ=7** Parallel Port I/O port address is 378h and the interrupt address is IRQ7
- ➔ **IO=278h; IRQ=7** Parallel Port I/O port address is 278h and the interrupt address is IRQ7

- ➔ **IO=3BCh;**
IRQ=7 Parallel Port I/O port address is 3BCh and the interrupt address is IRQ7
- ➔ **IO=378h** Parallel Port I/O port address is 378h
- ➔ **IO=278h** Parallel Port I/O port address is 278h
- ➔ **IO=3BCh** Parallel Port I/O port address is 3BCh


➔ **Device Mode [Printer Mode]**

Use the **Device Mode** option to select the mode the parallel port operates in. Configuration options are listed below.

- | | |
|------------------------|----------------|
| ▪ Printer Mode | Default |
| ▪ SPP Mode | |
| ▪ EPP-1.9 and SPP Mode | |
| ▪ EPP-1.7 and SPP Mode | |
| ▪ ECP Mode | |
| ▪ ECP and EPP 1.9 Mode | |
| ▪ ECP and EPP 1.7 Mode | |

5.3.7 H/W Monitor

The H/W Monitor menu (**BIOS Menu 12**) shows the operating temperature, fan speeds and system voltages.



BIOS Menu 12: Hardware Health Configuration

→ PC Health Status

The following system parameters and values are shown. The system parameters that are monitored are:

- System Temperatures:
 - ☐ CPU Temperature
 - ☐ System Temperature
- Fan Speeds:
 - ☐ CPU Fan Speed
- Voltages:
 - ☐ V_core
 - ☐ Vcc
 - ☐ Vcc12
 - ☐ V1_5VDDR
 - ☐ VSb3V
 - ☐ VBAT

PIC0e-PV-D4251/N4551/D5251 User Manual

→ CPU Smart Fan control [Auto Mode]

Use the **CPU Smart Fan control** option to configure the CPU fan.

→ Auto Mode

The fan adjusts its speed using these settings:

Temperature Bound 1

Temperature Bound 2

Temperature Bound 3

Temperature Bound 4


→ Manual Mode

The fan spins at the speed set in:

Manual Duty Cycle Setting

5.3.8 Serial Port Console Redirection

The **Serial Port Console Redirection** menu (**BIOS Menu 13**) allows the console redirection options to be configured. Console redirection allows users to maintain a system remotely by re-directing keyboard input and text output through the serial port.



BIOS Menu 13: Serial Port Console Redirection

→ Console Redirection [Disabled]

Use **Console Redirection** option to enable or disable the console redirection function.

- | | | | |
|---|-----------------|----------------|---|
| ➔ | Disabled | DEFAULT | Disabled the console redirection function |
| ➔ | Enabled | | Enabled the console redirection function |


5.4 Chipset

Use the **Chipset** menu (**BIOS Menu 14**) to access the Northbridge and Southbridge configuration menus



WARNING!


Setting the wrong values for the Chipset BIOS selections in the Chipset BIOS menu may cause the system to malfunction.



BIOS Menu 14: Chipset

5.4.1 Host Bridge Configuration


Use the **Host Bridge Configuration** menu (**BIOS Menu 15**) to configure the Northbridge chipset.



BIOS Menu 15: Host Bridge Chipset Configuration

5.4.1.1 OnChip VGA Configuration

Use the **OnChip VGA Configuration** menu (**BIOS Menu 15**) to configure the OnChip VGA.



BIOS Menu 16: OnChip VGA Configuration

➔ **Share Memory Size [8 MB]**

Use the **Share Memory Size** option to set the amount of system memory allocated to the integrated graphics processor when the system boots. The system memory allocated can then only be used as graphics memory, and is no longer available to applications or the operating system. Configuration options are listed below:

- Disabled
- 1 MB
- 8 MB **Default**


➔ **Multi-Monitor Support [Enabled]**

Use **Multi-Monitor Support** option to enable or disable the multi-monitor function.

- ➔ **Disabled** Disabled the multi-monitor function
- ➔ **Enabled** **DEFAULT** Enabled the multi-monitor function

5.4.2 South Bridge Configuration

Use the **South Bridge Configuration** menu (**BIOS Menu 17**) to configure the Southbridge chipset.



BIOS Menu 17: South Bridge Chipset Configuration

→ Restore on AC Power Loss [Power Off]

Use the **Restore on AC Power Loss** BIOS option to specify what state the system returns to if there is a sudden loss of power to the system.

- **Power Off** The system remains turned off
- **Power On** **DEFAULT** The system turns on
- **Last State** The system returns to its previous state. If it was on, it turns itself on. If it was off, it remains off.

→ HD Audio Controller [Enabled]

Use the **HD Audio Controller** option to enable or disable the High Definition Audio controller.

- **Enabled** **DEFAULT** The onboard High Definition Audio controller automatically detected and enabled
- **Disabled** The onboard High Definition Audio controller is disabled

→ USB Function [Enabled]

Use the **USB Function** BIOS option to enable or disable USB function support.

- **Disabled** USB function support disabled
- **Enabled** **DEFAULT** USB function support enabled

→ USB 2.0 (EHCI) Support [Enabled]

Use the **USB 2.0 (EHCI) Support** BIOS option to enable or disable USB 2.0 support.

- **Enabled** **DEFAULT** USB 2.0 (EHCI) support enabled
- **Disabled** USB 2.0 (EHCI) support disabled


→ Set Spread Spectrum Function [Disabled]

The **Set Spread Spectrum Function** option can help to improve CPU EMI issues.

- ➔ **Disabled** **DEFAULT** The spread spectrum mode is disabled
- ➔ **Enabled** The spread spectrum mode is enabled

5.4.3 Intel IGD SWSCI OpRegion

Use the **Intel IGD SWSCI OpRegion** menu to configure the video device connected to the system.



BIOS Menu 18: South Bridge Chipset Configuration

➔ **DMT Mode Select [DMT Mode]**

Use the **DMT Mode Select** option to select the Intel Dynamic Video Memory Technology (DMT) operating mode.

- ➔ **Fixed Mode** A fixed portion of graphics memory is reserved as graphics memory.
- ➔ **DMT Mode** **DEFAULT** Graphics memory is dynamically allocated according to the system and graphics needs.

➔ **DMT/FIXED Memory [256 MB]**

Use the **DMT/FIXED Memory** option to specify the maximum amount of memory that can be allocated as graphics memory. Configuration options are listed below.

- 128 MB
- 256 MB **Default**
- Maximum

→ IGD - Boot Type [VBIOS Default]

Use the **IGD - Boot Type** option to select the display device used by the system when it boots. Configuration options are listed below.

- VBIOS Default **DEFAULT**
- CRT
- LFP
- CRT + LFP


→ LCD Panel Type [640x480 18bit]

Use the **LCD Panel Type** option to select the type of flat panel connected to the system. Configuration options are listed below.

- 640x480 18bit **DEFAULT**
- 800x480 18bit
- 800x600 18bit
- 1024x768 18bit
- 1280x1024 18bit
- 1366x768 18bit
- 1280x800 18bit
- 1280x600 18bit

5.5 Boot

Use the **Boot** menu (**BIOS Menu 19**) to configure system boot options.



BIOS Menu 19: Boot

➔ **Bootup NumLock State [On]**

Use the **Bootup NumLock State** BIOS option to specify if the number lock setting must be modified during boot up.

- | | | | |
|---|------------|----------------|--|
| ➔ | On | DEFAULT | Allows the Number Lock on the keyboard to be enabled automatically when the computer system boots up. This allows the immediate use of the 10-key numeric keypad located on the right side of the keyboard. To confirm this, the Number Lock LED light on the keyboard is lit. |
| ➔ | Off | | Does not enable the keyboard Number Lock automatically. To use the 10-keys on the keyboard, press the Number Lock key located on the upper left-hand corner of the 10-key pad. The Number Lock LED on the keyboard lights up when the Number Lock is engaged. |

PIC0e-PV-D4251/N4551/D5251 User Manual

→ Quiet Boot [Enabled]

Use the **Quiet Boot** BIOS option to select the screen display when the system boots.

- **Disabled** Normal POST messages displayed
- **Enabled** **DEFAULT** OEM Logo displayed instead of POST messages


→ Launch PXE OpROM [Disabled]

Use the **Launch PXE OpROM** option to enable or disable boot option for legacy network devices.

- **Disabled** **DEFAULT** Ignore all PXE Option ROMs
- **Enabled** Load PXE Option ROMs.

5.6 Security

Use the **Security** menu (**BIOS Menu 20**) to set system and user passwords.



BIOS Menu 20: Security

→ Administrator Password


Use the **Administrator Password** to set or change a administrator password.

➔ User Password

Use the **User Password** to set or change a user password.

5.7 Exit

Use the **Exit** menu (**BIOS Menu 21**) to load default BIOS values, optimal failsafe values and to save configuration changes.



BIOS Menu 21:Exit

➔ Save Changes and Reset

Use the **Save Changes and Reset** option to save the changes made to the BIOS options and to exit the BIOS configuration setup program.

➔ Discard Changes and Reset

Use the **Discard Changes and Reset** option to exit the system without saving the changes made to the BIOS configuration setup program.

➔ Restore Defaults

Use the **Restore Defaults** option to load the optimal default values for each of the parameters on the Setup menus. **F3 key can be used for this operation.**

➔ **Save as User Defaults**

Use the **Save as User Defaults** option to save the changes done so far as user defaults.

➔ **Restore User Defaults**

Use the **Restore User Defaults** option to restore the user defaults to all the setup options.

Appendix**A**

BIOS Options

PIC0e-PV-D4251/N4551/D5251 User Manual

Below is a list of BIOS configuration options in the BIOS chapter.

BIOS Information	70
System Date [xx/xx/xx]	70
System Time [xx:xx:xx]	71
ACPI Sleep State [S3 (Suspend to RAM)]	72
TPM Support [Disable]	73
ATA/IDE Configurations [Enhanced]	75
Configure SATA as [IDE]	76
USB Devices	76
Legacy USB Support [Enabled]	76
Serial Port [Enabled]	78
Change Settings [Auto]	78
Serial Port [Enabled]	79
Change Settings [Auto]	79
Serial Port [Enabled]	79
Change Settings [Auto]	80
Serial Port [Enabled]	80
Change Settings [Auto]	80
IrDA [Enabled]	81
Parallel Port [Enabled]	82
Change Settings [Auto]	82
Device Mode [Printer Mode]	83
PC Health Status	84
CPU Smart Fan control [Auto Mode]	85
Console Redirection [Disabled]	85
Share Memory Size [8 MB]	88
Multi-Monitor Support [Enabled]	88
Restore on AC Power Loss [Power Off]	89
HD Audio Controller [Enabled]	89
USB Function [Enabled]	89
USB 2.0 (EHCI) Support [Enabled]	89
Set Spread Spectrum Function [Disabled]	89
DVMT Mode Select [DVMT Mode]	90
DVMT/FIXED Memory [256 MB]	90

IGD - Boot Type [VBIOS Default].....	91
LCD Panel Type [640x480 18bit].....	91
Bootup NumLock State [On].....	92
Quiet Boot [Enabled]	93
Launch PXE OpROM [Disabled]	93
Administrator Password	93
User Password	94
Save Changes and Reset	94
Discard Changes and Reset	94
Restore Defaults	94
Save as User Defaults	95
Restore User Defaults	95

Appendix

B

One Key Recovery

B.1 One Key Recovery Introduction

The IEI one key recovery is an easy-to-use front end for the Norton Ghost system backup and recovery tool. The one key recovery provides quick and easy shortcuts for creating a backup and reverting to that backup or for reverting to the factory default settings.

The IEI One Key Recovery tool menu is shown below.




Figure B-1: IEI One Key Recovery Tool Menu

Prior to using the IEI One Key Recovery tool (as shown in **Figure B-1**) to backup or restore Windows system, five setup procedures are required.

1. Hardware and BIOS setup (see **Section B.2.1**)
2. Create partitions (see **Section B.2.2**)
3. Install operating system, drivers and system applications (see **Section B.2.3**)
4. Build-up recovery partition (see **Section B.2.4**)
5. Create factory default image (see **Section B.2.5**)

After completing the five initial setup procedures as described above, users can access the recovery tool by pressing <F3> while booting up the system. The detailed information of each function is described in **Section B.4**.



NOTE:


The initial setup procedures for Linux system are described in **Section B.3**.

B.1.1 System Requirement



NOTE:

The recovery CD can only be used with IEI products. The software will fail to run and a warning message will appear when used on non-IEI hardware.



To create the system backup, the main storage device must be split into two partitions (three partitions for Linux). The first partition will be for the operating system, while the second partition will be invisible to the operating system and contain the backup made by the one key recovery software.

The partition created for recovery images must be big enough to contain both the factory default image and the user backup image. The size must be calculated before creating the partitions. Please take the following table as a reference when calculating the size of the partition.

	OS	OS Image after Ghost	Compression Ratio
Windows® 7	7 GB	5 GB	70%
Windows® XPE	776 MB	560 MB	70%
Windows® CE 6.0	36 MB	28 MB	77%

**NOTE:**

Specialized tools are required to change the partition size if the operating system is already installed.

B.1.2 Supported Operating System

The recovery CD is compatible with both Microsoft Windows and Linux operating system (OS). The supported OS versions are listed below.

- Microsoft Windows
 - Windows XP (Service Pack 2 or 3 required)
 - Windows Vista
 - Windows 7
 - Windows CE 5.0
 - Windows CE 6.0
 - Windows XP Embedded
- Linux
 - Fedora Core 12 (Constantine)
 - Fedora Core 11 (Leonidas)
 - Fedora Core 10 (Cambridge)
 - Fedora Core 8 (Werewolf)
 - Fedora Core 7 (Moonshine)
 - RedHat RHEL-5.4
 - RedHat 9 (Ghirke)
 - Ubuntu 8.10 (Intrepid)
 - Ubuntu 7.10 (Gutsy)
 - Ubuntu 6.10 (Edgy)
 - Debian 5.0 (Lenny)
 - Debian 4.0 (Etch)
 - SuSe 11.2
 - SuSe 10.3

**NOTE:**

Installing unsupported OS versions may cause the recovery tool to fail.

B.2 Setup Procedure for Windows

Prior to using the recovery tool to backup or restore Windows system, a few setup procedures are required.

Step 1: Hardware and BIOS setup (see **Section B.2.1**)

Step 2: Create partitions (see **Section B.2.2**)

Step 3: Install operating system, drivers and system applications (see **Section B.2.3**)

Step 4: Build-up recovery partition (see **Section B.2.4**)

Step 5: Create factory default image (see **Section B.2.5**)

The detailed descriptions are described in the following sections.

**NOTE:**

The setup procedures described below are for Microsoft Windows operating system users. For Linux system, most setup procedures are the same with Microsoft Windows except for several steps which is described in **Section B.3**.

B.2.1 Hardware and BIOS Setup

Step 1: Make sure the system is powered off and unplugged.

Step 2: Install a hard drive or SSD in the system. An unformatted and unpartitioned disk is recommended.

Step 3: Connect an optical disk drive to the system and insert the recovery CD.

Step 4: Turn on the system.

Step 5: Press the <DELETE> key as soon as the system is turned on to enter the BIOS.

Step 6: Select the connected optical disk drive as the 1st boot device. (**Boot → Boot Device Priority → 1st Boot Device**).

Step 7: Save changes and restart the computer. Continue to the next section for instructions on partitioning the internal storage.

B.2.2 Create Partitions

To create the system backup, the main storage device must be split into two partitions (three partitions for Linux). The first partition will be for the operating system, while the second partition will be invisible to the operating system and contain the backup made by the one key recovery software.

Step 1: Put the recovery CD in the optical drive of the system.

Step 2: Boot the system from recovery CD. When prompted, press any key to boot from the recovery CD. It will take a while to launch the recovery tool. Please be patient!




Figure B-2: Launching the Recovery Tool

Step 3: The recovery tool setup menu is shown as below.




Figure B-3: Recovery Tool Setup Menu

Step 4: Press <5> then <Enter>.




Figure B-4: Command Mode

Step 5: The command prompt window appears. Type the following commands (marked in red) to create two partitions. One is for the OS installation; the other is for saving recovery files and images which will be an invisible partition.

(Press <Enter> after entering each line below)

system32>**diskpart**

DISKPART>**list vol**

DISKPART>**sel disk 0**

DISKPART>**create part pri size= ____**

DISKPART>**assign letter=N**

DISKPART>**create part pri size= ____**


DISKPART>**assign letter=F**

DISKPART>**exit**

system32>**format N: /fs:ntfs /q /y**

system32>format F: /fs:ntfs /q /v:Recovery /y

system32>exit



```
X:\I386\SYSTEM32\CMD.EXE

X:\I386\SYSTEM32>diskpart → Starts the Microsoft disk partitioning tool.

Microsoft DiskPart version 5.2.3790.1830
Copyright (C) 1999-2001 Microsoft Corporation.
On computer: MININT-JUC

DISKPART> list vol → Show partition information

   Volume ###  Ltr  Label          Fs      Type          Size      Status       Info
   -----
   Volume 0             X  CD_ROM          CDFS     DVD-ROM        405 MB    Healthy      Boot
   Volume 1             D                      FAT132   Removeable    3854 MB    Healthy

DISKPART> sel disk 0 → Select a disk

Disk 0 is now the selected disk.

DISKPART> create part pri size=2000 → Create partition 1 and assign a size.
                                       This partition is for OS installation.
DiskPart succeeded in creating the specified partition.

DISKPART> assign letter=N → Assign partition 1 a code name (N).
DiskPart successfully assigned the drive letter or mount point.

DISKPART> create part pri size=1800 → Create partition 2 and assign a size.
                                       This partition is for recovery images.
DiskPart succeeded in creating the specified partition.

DISKPART> assign letter=F → Assign partition 2 a code name (F).
DiskPart successfully assigned the drive letter or mount point.

DISKPART> exit → Exit diskpart

X:\I386\SYSTEM32>format n: /fs:ntfs /q /y → Format partition 1 (N) as NTFS format.
The type of the file system is ntfs.
The new file system is NTFS.
QuickFormatting 2000M
Creating file system structures.
Format complete.
2048254 KB total disk space.
2035620 KB are available.

X:\I386\SYSTEM32>format f: /fs:ntfs /q /v:Recovery /y
The type of the file system is ntfs.
The new file system is NTFS.
QuickFormatting 1804M
Creating file system structures.
Format complete.
1847474 KB total disk space.
1835860 KB are available.

X:\I386\SYSTEM32>exit → Exit Windows PE
```

Figure B-5: Partition Creation Commands



NOTE:

Use the following commands to check if the partitions were created successfully.

```
X:\I386\SYSTEM32>diskpart
Microsoft DiskPart version 5.2.3790.1830
Copyright (C) 1999-2001 Microsoft Corporation.
On computer: MININT-JUC

DISKPART> sel disk 0
Disk 0 is now the selected disk.

DISKPART> list part

   Partition ###   Type              Size          Offset
-----
Partition 1       Primary           2000 MB         32 KB
Partition 2       Primary          1804 MB       2000 MB

DISKPART> exit
```

Step 6: Press any key to exit the recovery tool and automatically reboot the system.

Please continue to the following procedure: Build-up Recovery Partition.

B.2.3 Install Operating System, Drivers and Applications

Install the operating system onto the unlabelled partition. The partition labeled as "Recovery" is for use by the system recovery tool and should not be used for installing the operating system or any applications.



NOTE:

The operating system installation program may offer to reformat the chosen partition. DO NOT format the partition again. The partition has already been formatted and is ready for installing the new operating system.

To install the operating system, insert the operating system installation CD into the optical drive. Restart the computer and follow the installation instructions.

B.2.4 Build-up Recovery Partition

Step 1: Put the recover CD in the optical drive.

Step 2: Start the system.

Step 3: **Boot the system from recovery CD.** When prompted, press any key to boot from the recovery CD. It will take a while to launch the recovery tool. Please be patient!




Figure B-6: Launching the Recovery Tool

Step 4: When the recovery tool setup menu appears, press <2> then <Enter>.




Figure B-7: System Configuration for Windows

Step 5: The Symantec Ghost window appears and starts configuring the system to build-up a recovery partition. In this process, the partition which is created for

recovery files in **Section B.2.2** is hidden and the recovery tool is saved in this partition.




Figure B-8: Build-up Recovery Partition

Step 6: After completing the system configuration, press any key in the following window to reboot the system.




Figure B-9: Press any key to continue

Step 7: Eject the recovery CD.

B.2.5 Create Factory Default Image




NOTE:

Before creating the factory default image, please configure the system to a factory default environment, including driver and application installations.

To create a factory default image, please follow the steps below.

Step 1: Turn on the system. When the following screen displays (**Figure B-10**), press the <F3> key to access the recovery tool. The message will display for 10 seconds, please press F3 before the system boots into the operating system.



```
Press F3 to boot into recovery mode... _
```

Figure B-10: Press F3 to Boot into Recovery Mode

Step 2: The recovery tool menu appears. Type <4> and press <Enter>. (**Figure B-11**)




Figure B-11: Recovery Tool Menu

Step 3: The About Symantec Ghost window appears. Click **OK** button to continue.




Figure B-12: About Symantec Ghost Window

Step 4: Use mouse to navigate to the option shown below (Figure B-13).




Figure B-13: Symantec Ghost Path

Step 5: Select the local source drive (Drive 1) as shown in Figure B-14. Then click OK.




Figure B-14: Select a Local Source Drive

Step 6: Select a source partition (Part 1) from basic drive as shown in **Figure B-15**.
Then click OK.




Figure B-15: Select a Source Partition from Basic Drive

Step 7: Select **1.2: [Recovery] NTFS drive** and enter a file name called **iei** (Figure B-16). Click **Save**. The factory default image will then be saved in the selected recovery drive and named **IEI.GHO**.



WARNING:

The file name of the factory default image must be **iei.GHO**.




Figure B-16: File Name to Copy Image to

Step 8: When the Compress Image screen in **Figure B-17** prompts, click **High** to make the image file smaller.




Figure B-17: Compress Image

Step 9: The Proceed with partition image creation window appears, click **Yes** to continue.




Figure B-18: Image Creation Confirmation

Step 10: The Symantec Ghost starts to create the factory default image (**Figure B-19**).




Figure B-19: Image Creation Process

Step 11: When the image creation completes, a screen prompts as shown in **Figure B-20**.

Click **Continue** and close the Ghost window to exit the program.




Figure B-20: Image Creation Complete

Step 12: The recovery tool main menu window is shown as below. Press any key to reboot the system.




Figure B-21: Press Any Key to Continue

B.3 Setup Procedure for Linux

The initial setup procedures for Linux system are mostly the same with the procedure for Microsoft Windows. Please follow the steps below to setup recovery tool for Linux OS.

Step 1: **Hardware and BIOS setup.** Refer to **Section B.2.1.**

Step 2: **Install Linux operating system.** Make sure to install GRUB (v0.97 or earlier) MBR type and Ext3 partition type. Leave enough space on the hard drive to create the recover partition later.



NOTE:

If the Linux OS is not installed with GRUB (v0.97 or earlier) and Ext3, the Symantec Ghost may not function properly.

While installing Linux OS, please create two partitions:

- Partition 1: /
- Partition 2: **SWAP**

**NOTE:**

Please reserve enough space for partition 3 for saving recovery images.




Figure B-22: Partitions for Linux

Step 3: Create a recovery partition. Insert the recovery CD into the optical disk drive.

Follow **Step 1 ~ Step 3** described in **Section B.2.2**. Then type the following commands (marked in red) to create a partition for recovery images.

```
system32>diskpart
DISKPART>list vol
DISKPART>sel disk 0
DISKPART>create part pri size= ____
DISKPART>assign letter=N
DISKPART>exit
system32>format N: /fs:ntfs /q /v:Recovery /y
system32>exit
```

Step 4: Build-up recovery partition. Press any key to boot from the recovery CD. It will take a while to launch the recovery tool. Please be patient. When the recovery tool setup menu appears, type <3> and press <Enter> (**Figure B-23**). The Symantec Ghost window appears and starts configuring the system to build-up a recovery partition. After completing the system configuration, press any key to reboot the system. Eject the recovery CD.




Figure B-23: System Configuration for Linux

Step 5: Access the recovery tool main menu by modifying the “menu.lst”. To first access the recovery tool main menu, the menu.lst must be modified. In Linux system, enter Administrator (root). When prompt appears, type:

```
cd /boot/grub
```

```
vi menu.lst
```




Figure B-24: Access menu.lst in Linux (Text Mode)

Step 6: Modify the menu.lst as shown below.

```
#boot=/dev/sda
default=0
timeout=10
splashimage=(hd0,0)/grub/splash.xpm.gz
hiddenmenu
title Fedora (2.6.25-14.fc9.i686)
    root (hd0,0)
    kernel /vmlinuz-2.6.25-14.fc9.i686 ro root=UUID=10f1acd
ac38b5c78910 rhgb quiet
    initrd /initrd-2.6.25-14.fc9.i686.img

title Recovery Partition
    root (hd0,2)
    makeactive
    chainloader +1
```

- Type command:
title Recovery Partition
root (hd0,2)
makeactive
chainloader +1

Step 7: The recovery tool menu appears. (Figure B-25)

```
1. Factory Restore
2. Backup system
3. Restore your last backup.
4. Manual
5. Quit
Please type the number to select and then press Enter:
```

Figure B-25: Recovery Tool Menu

Step 8: Create a factory default image. Follow **Step 2 ~ Step 12** described in **Section B.2.5** to create a factory default image.

B.4 Recovery Tool Functions

After completing the initial setup procedures as described above, users can access the recovery tool by pressing **<F3>** while booting up the system. The main menu of the recovery tool is shown below.




Figure B-26: Recovery Tool Main Menu

The recovery tool has several functions including:

6. **Factory Restore:** Restore the factory default image (iei.GHO) created in **Section B.2.5**.
7. **Backup system:** Create a system backup image (iei_user.GHO) which will be saved in the hidden partition.
8. **Restore your last backup:** Restore the last system backup image
9. **Manual:** Enter the Symantec Ghost window to configure manually.
10. **Quit:** Exit the recovery tool and restart the system.

**WARNING:**

Please do not turn off the system power during the process of system recovery or backup.

**WARNING:**

All data in the system will be deleted during the system recovery. Please backup the system files before restoring the system (either Factory Restore or Restore Backup).

B.4.1 Factory Restore

To restore the factory default image, please follow the steps below.

Step 1: Type <1> and press <Enter> in the main menu.

Step 2: The Symantec Ghost window appears and starts to restore the factory default. A factory default image called **iei.GHO** is created in the hidden Recovery partition.




Figure B-27: Restore Factory Default

Step 3: The screen is shown as in **Figure B-28** when completed. Press any key to reboot the system.




Figure B-28: Recovery Complete Window

B.4.2 Backup System

To backup the system, please follow the steps below.

Step 1: Type <2> and press <Enter> in the main menu.

Step 2: The Symantec Ghost window appears and starts to backup the system. A backup image called **iei_user.GHO** is created in the hidden Recovery partition.




Figure B-29: Backup System

Step 3: The screen is shown as in **Figure B-30** when system backup is completed.

Press any key to reboot the system.




Figure B-30: System Backup Complete Window

B.4.3 Restore Your Last Backup

To restore the last system backup, please follow the steps below.

Step 1: Type <3> and press <Enter> in the main menu.

Step 2: The Symantec Ghost window appears and starts to restore the last backup image (iei_user.GHO).




Figure B-31: Restore Backup

Step 3: The screen is shown as in **Figure B-32** when backup recovery is completed.

Press any key to reboot the system.




Figure B-32: Restore System Backup Complete Window

PICOe-PV-D4251/N4551/D5251 User Manual

B.4.4 Manual

To restore the last system backup, please follow the steps below.

Step 1: Type <4> and press <Enter> in the main menu.

Step 2: The Symantec Ghost window appears. Use the Ghost program to backup or recover the system manually.




Figure B-33: Symantec Ghost Window


Step 3: When backup or recovery is completed, press any key to reboot the system.

B.5 Other Information

B.5.1 Using AHCI Mode or ALi M5283 / VIA VT6421A Controller


When the system uses AHCI mode or some specific SATA controllers such as ALi M5283 or VIA VT6421A, the SATA RAID/AHCI driver must be installed before using one key recovery. Please follow the steps below to install the SATA RAID/AHCI driver.

- Step 1:** Copy the SATA RAID/AHCI driver to a floppy disk and insert the floppy disk into a USB floppy disk drive. The SATA RAID/AHCI driver must be especially designed for the on-board SATA controller.
- Step 2:** Connect the USB floppy disk drive to the system.
- Step 3:** Insert the One Key Recovery CD into the system and boot the system from the CD.
- Step 4:** When launching the recovery tool, press <F6>.




PIC0e-PV-D4251/N4551/D5251 User Manual

Step 5: When the following window appears, press <S> to select “Specify Additional Device”.



Step 6: In the following window, select a SATA controller mode used in the system. Then press <Enter>. The user can now start using the SATA HDD.



Step 7: After pressing <Enter>, the system will get into the recovery tool setup menu.

Continue to follow the setup procedure from **Step 4** in **Section B.2.2 Create Partitions** to finish the whole setup process.

B.5.2 System Memory Requirement

To be able to access the recovery tool by pressing <F3> while booting up the system, please make sure to have enough system memory. The minimum memory requirement is listed below.

- **Using Award BIOS:** 128 MB system memory
- **Using AMI BIOS:** 512 MB system memory.

Appendix

C

Terminology

AC '97	Audio Codec 97 (AC'97) refers to a codec standard developed by Intel® in 1997.
ACPI	Advanced Configuration and Power Interface (ACPI) is an OS-directed configuration, power management, and thermal management interface.
AHCI	Advanced Host Controller Interface (AHCI) is a SATA Host controller register-level interface.
ATA	The Advanced Technology Attachment (ATA) interface connects storage devices including hard disks and CD-ROM drives to a computer.
ARMD	An ATAPI Removable Media Device (ARMD) is any ATAPI device that supports removable media, besides CD and DVD drives.
ASKIR	Amplitude Shift Keyed Infrared (ASKIR) is a form of modulation that represents a digital signal by varying the amplitude ("volume") of the signal. A low amplitude signal represents a binary 0, while a high amplitude signal represents a binary 1.
BIOS	The Basic Input/Output System (BIOS) is firmware that is first run when the computer is turned on and can be configured by the end user
CODEC	The Compressor-Decompressor (CODEC) encodes and decodes digital audio data on the system.
CompactFlash®	CompactFlash® is a solid-state storage device. CompactFlash® devices use flash memory in a standard size enclosure. Type II is thicker than Type I, but a Type II slot can support both types.
CMOS	Complimentary metal-oxide-conductor is an integrated circuit used in chips like static RAM and microprocessors.
COM	COM refers to serial ports. Serial ports offer serial communication to expansion devices. The serial port on a personal computer is usually a male DB-9 connector.
DAC	The Digital-to-Analog Converter (DAC) converts digital signals to analog signals.
DDR	Double Data Rate refers to a data bus transferring data on both the rising and falling edges of the clock signal.

PIC0e-PV-D4251/N4551/D5251 User Manual

DMA	Direct Memory Access (DMA) enables some peripheral devices to bypass the system processor and communicate directly with the system memory.
DIMM	Dual Inline Memory Modules are a type of RAM that offer a 64-bit data bus and have separate electrical contacts on each side of the module.
DIO	The digital inputs and digital outputs are general control signals that control the on/off circuit of external devices or TTL devices. Data can be read or written to the selected address to enable the DIO functions.
EHCI	The Enhanced Host Controller Interface (EHCI) specification is a register-level interface description for USB 2.0 Host Controllers.
EIDE	Enhanced IDE (EIDE) is a newer IDE interface standard that has data transfer rates between 4.0 MBps and 16.6 MBps.
EIST	Enhanced Intel® SpeedStep Technology (EIST) allows users to modify the power consumption levels and processor performance through application software. The application software changes the bus-to-core frequency ratio and the processor core voltage.
FSB	The Front Side Bus (FSB) is the bi-directional communication channel between the processor and the Northbridge chipset.
GbE	Gigabit Ethernet (GbE) is an Ethernet version that transfers data at 1.0 Gbps and complies with the IEEE 802.3-2005 standard.
GPIO	General purpose input
HDD	Hard disk drive (HDD) is a type of magnetic, non-volatile computer storage device that stores digitally encoded data.
ICH	The Input/Output Control Hub (ICH) is an Intel® Southbridge chipset.
IrDA	Infrared Data Association (IrDA) specify infrared data transmission protocols used to enable electronic devices to wirelessly communicate with each other.
L1 Cache	The Level 1 Cache (L1 Cache) is a small memory cache built into the system processor.
L2 Cache	The Level 2 Cache (L2 Cache) is an external processor memory cache.

LCD	Liquid crystal display (LCD) is a flat, low-power display device that consists of two polarizing plates with a liquid crystal panel in between.
LVDS	Low-voltage differential signaling (LVDS) is a dual-wire, high-speed differential electrical signaling system commonly used to connect LCD displays to a computer.
POST	The Power-on Self Test (POST) is the pre-boot actions the system performs when the system is turned-on.
RAM	Random Access Memory (RAM) is volatile memory that loses data when power is lost. RAM has very fast data transfer rates compared to other storage like hard drives.
SATA	Serial ATA (SATA) is a serial communications bus designed for data transfers between storage devices and the computer chipsets. The SATA bus has transfer speeds up to 1.5 Gbps and the SATA II bus has data transfer speeds of up to 3.0 Gbps.
S.M.A.R.T	Self Monitoring Analysis and Reporting Technology (S.M.A.R.T) refers to automatic status checking technology implemented on hard disk drives.
UART	Universal Asynchronous Receiver-transmitter (UART) is responsible for asynchronous communications on the system and manages the system's serial communication (COM) ports.
UHCI	The Universal Host Controller Interface (UHCI) specification is a register-level interface description for USB 1.1 Host Controllers.
USB	The Universal Serial Bus (USB) is an external bus standard for interfacing devices. USB 1.1 supports 12Mbps data transfer rates and USB 2.0 supports 480Mbps data transfer rates.
VGA	The Video Graphics Array (VGA) is a graphics display system developed by IBM.

Appendix

D

Digital I/O Interface

D.1 Introduction

The DIO connector on the PIC0e-PV-D4251/N4551/D5251 is interfaced to GPIO ports on the Super I/O chipset. The DIO has both 4-bit digital inputs and 4-bit digital outputs. The digital inputs and digital outputs are generally control signals that control the on/off circuit of external devices or TTL devices. Data can be read or written to the selected address to enable the DIO functions.



NOTE:

For further information, please refer to the datasheet for the Super I/O chipset.

D.2 DIO Connector Pinouts

The following table describes how the DIO connector pins are connected to the Super I/O GPIO port 1.

Pin	Description	Super I/O Pin	Super I/O Pin Description
1	Ground	N/A	N/A
2	VCC	N/A	N/A
3	Output 3	GP27	General purpose I/O port 2 bit 7.
4	Output 2	GP26	General purpose I/O port 2 bit 6.
5	Output 1	GP25	General purpose I/O port 2 bit 5.
6	Output 0	GP24	General purpose I/O port 2 bit 4.
7	Input 3	GP23	General purpose I/O port 2 bit 3.
8	Input 2	GP22	General purpose I/O port 2 bit 2.
9	Input 1	GP21	General purpose I/O port 2 bit 1.
10	Input 0	GP20	General purpose I/O port 2 bit 0.

Table D-1: Digital I/O Connector Pinouts

D.3 Assembly Language Samples

D.3.1 Enable the DIO Input Function

The BIOS interrupt call INT 15H controls the digital I/O. An assembly program to enable digital I/O input functions is listed below.

MOV	AX, 6F08H	Sets the digital port as input
INT	15H	Initiates the INT 15H BIOS call

D.3.2 Enable the DIO Output Function

The BIOS interrupt call INT 15H controls the digital I/O. An assembly program to enable digital I/O output functions is listed below.

MOV	AX, 6F09H	Sets the digital port as output
MOV	BL, 09H	
INT	15H	Initiates the INT 15H BIOS call

Appendix

E

Watchdog Timer



NOTE:

The following discussion applies to DOS. Contact IEI support or visit the IEI website for drivers for other operating systems.

The Watchdog Timer is a hardware-based timer that attempts to restart the system when it stops working. The system may stop working because of external EMI or software bugs. The Watchdog Timer ensures that standalone systems like ATMs will automatically attempt to restart in the case of system problems.

A BIOS function call (INT 15H) is used to control the Watchdog Timer.

INT 15H:

AH – 6FH Sub-function:	
AL – 2:	Sets the Watchdog Timer's period.
BL:	Time-out value (Its unit-second is dependent on the item "Watchdog Timer unit select" in CMOS setup).

Table E-1: AH-6FH Sub-function

Call sub-function 2 to set the time-out period of Watchdog Timer first. If the time-out value is not zero, the Watchdog Timer starts counting down. When the timer value reaches zero, the system resets. To ensure that this reset condition does not occur, calling sub-function 2 must periodically refresh the Watchdog Timer. However, the watchdog timer is disabled if the time-out value is set to zero.

A tolerance of at least 10% must be maintained to avoid unknown routines within the operating system (DOS), such as disk I/O that can be very time-consuming.

**NOTE:**

The Watchdog Timer is activated through software. The software application that activates the Watchdog Timer must also deactivate it when closed. If the Watchdog Timer is not deactivated, the system will automatically restart after the Timer has finished its countdown.

EXAMPLE PROGRAM:

; INITIAL TIMER PERIOD COUNTER

;

W_LOOP:

;

```
MOV      AX, 6F02H      ;setting the time-out value
MOV      BL, 30          ;time-out value is 48 seconds
INT      15H
```

;

; ADD THE APPLICATION PROGRAM HERE

;

```
CMP      EXIT_AP, 1      ;is the application over?
JNE      W_LOOP          ;No, restart the application
```

```
MOV      AX, 6F02H      ;disable Watchdog Timer
MOV      BL, 0           ;
INT      15H
```

;

; EXIT ;

Appendix

F

Hazardous Materials Disclosure

F.1 Hazardous Materials Disclosure Table for IPB Products Certified as RoHS Compliant Under 2002/95/EC Without Mercury

The details provided in this appendix are to ensure that the product is compliant with the Peoples Republic of China (China) RoHS standards. The table below acknowledges the presences of small quantities of certain materials in the product, and is applicable to China RoHS only.

A label will be placed on each product to indicate the estimated “Environmentally Friendly Use Period” (EFUP). This is an estimate of the number of years that these substances would “not leak out or undergo abrupt change.” This product may contain replaceable sub-assemblies/components which have a shorter EFUP such as batteries and lamps. These components will be separately marked.

Please refer to the table on the next page.

PICOe-PV-D4251/N4551/D5251 User Manual

Part Name	Toxic or Hazardous Substances and Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (CR(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Housing	X	O	O	O	O	X
Display	X	O	O	O	O	X
Printed Circuit Board	X	O	O	O	O	X
Metal Fasteners	X	O	O	O	O	O
Cable Assembly	X	O	O	O	O	X
Fan Assembly	X	O	O	O	O	X
Power Supply Assemblies	X	O	O	O	O	X
Battery	O	O	O	O	O	O
O: This toxic or hazardous substance is contained in all of the homogeneous materials for the part is below the limit requirement in SJ/T11363-2006 X: This toxic or hazardous substance is contained in at least one of the homogeneous materials for this part is above the limit requirement in SJ/T11363-2006						

此附件旨在确保本产品符合中国 RoHS 标准。以下表格标示此产品中某有毒物质的含量符合中国 RoHS 标准规定的限量要求。

本产品上会附有“环境友好使用期限”的标签，此期限是估算这些物质“不会有泄漏或突变”的年限。本产品可能包含有较短的环境友好使用期限的可替换元件，像是电池或灯管，这些元件将会单独标示出来。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (CR(VI))	多溴联苯 (PBB)	多溴二苯 醚 (PBDE)
壳体	X	O	O	O	O	X
显示	X	O	O	O	O	X
印刷电路板	X	O	O	O	O	X
金属螺帽	X	O	O	O	O	O
电缆组装	X	O	O	O	O	X
风扇组装	X	O	O	O	O	X
电力供应组装	X	O	O	O	O	X
电池	O	O	O	O	O	O

O: 表示该有毒有害物质在该部件所有物质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。
X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。