

**MODEL:
HDC-701EL SDK (Linux)**

**Software Development Kit (SDK) that Facilitates
Development of Linux-based Application for HDC-701EL**

User Manual

Revision

Date	Version	Changes
December 23, 2015	1.00	Initial release

Copyright

COPYRIGHT NOTICE

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

TRADEMARKS

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Manual Conventions

**WARNING**

Warnings appear where overlooked details may cause damage to the equipment or result in personal injury. Warnings should be taken seriously.

**CAUTION**

Cautionary messages should be heeded to help reduce the chance of losing data or damaging the product.

**NOTE**

These messages inform the reader of essential but non-critical information. These messages should be read carefully as any directions or instructions contained therein can help avoid making mistakes.

**HOT SURFACE**

This symbol indicates a hot surface that should not be touched without taking care.

Table of Contents

1 DRIVER AND SDK INSTALLATION	6
1.1 OVERVIEW.....	7
1.2 SYSTEM REQUIREMENTS	7
1.3 SOFTWARE INSTALLATION	7
1.3.1 Bin File Only (Ubuntu 14.04.1 kernel 3.13.0-32-Generic 64-bit).....	7
1.3.2 Source Code	9
2 USING THE SDK IN LINUX	11
2.1 LAUNCH IEI HD CAPTURE AP SDK	12
2.2 VIDEO CAPTURE.....	14
2.2.1 Encoding Settings.....	14
2.2.2 Live.....	15
2.2.3 Update HDMI Source	17
2.2.4 Select Other Board.....	17
2.2.5 Change Output.....	17
2.2.6 AES.....	18
2.3 HDC-701EL FUNCTION	19
2.3.1 Set Main Input Source.....	19
2.3.2 Set Aspect Ratio	19
2.3.3 Enable/Disable Audio Input.....	20
2.3.4 Get Sample Rate.....	20
2.3.5 Set Scaler Resolution	20
3 LINUX OPEN SOURCE CODE	21

Chapter

1

Driver and SDK Installation

HDC-701EL SDK (Linux)

1.1 Overview

The IEI HD Capture AP SDK is a video capture tool that allows the user to capture video through the input port in Linux environment.

1.2 System Requirements

The following program must be installed in order to use the IEI HD Capture AP SDK in Linux:

- Kernel: Ubuntu 14.04.1 Distribution (based on Kernel 3.13.0)

1.3 Software Installation

To install the IEI HD Capture AP SDK to a system running Linux, please follow the steps in the following sub-sections.

1.3.1 Bin File Only (Ubuntu 14.04.1 kernel 3.13.0-32-Generic 64-bit)

Step 1: Copy the

IEI_hdcxxx_0_0_3_2_bin_3.13.0-32-generic_x86_64_20151109_5959.tar.gz

(0_0_3_2 release version, 20151109 release date, 5959 svn version, 3.13.0-32-generic kernel version) file from the utility CD to the system hard drive.

The user can also get the latest version from IEI website.

Step 2: Unzip the file by typing:

```
$ tar zxvf IEI_hdcxxx_ (version)_bin_(kernel version) (date)(svn version).tar.gz
$ tar zxvf
IEI_hdcxxx_0_0_3_2_bin_3.13.0-32-generic_x86_64_20151109_5959.tar.gz
```

Step 3: Change to SDK directory by typing:

```
$ cd IEI_hdcxxx_ (version)_bin_(kernel version) (date)(svn version)
$ cd IEI_hdcxxx_0_0_3_2_bin_3.13.0-32-generic_x86_64_20151109_5959
```

Step 4: Login as root by typing:

```
$ sudo su
```

Step 5: Enter the password:

```
password: *****  
$
```

Step 6: Install the IEI HD Capture AP SDK by typing:

```
#sh env.sh  
  
root@ubuntu:/home/test/PL330/Linux/trunk/driver/fellini-linux/api/linux# sh env.sh  
Reading package lists... Done  
Building dependency tree  
Reading state information... Done  
.....  
Setting up libxext-dev:amd64 (2:1.3.2-1ubuntu0.0.14.04.1) ...  
Setting up x11proto-xf86vidmode-dev (2.3.1-2) ...  
Setting up libxf86vm-dev:amd64 (1:1.1.3-1) ...  
Setting up x11proto-dri2-dev (2.8-2) ...  
Setting up x11proto-glx-dev (1.4.17-1) ...  
Setting up libgl1-mesa-dev (10.1.3-0ubuntu0.5) ...  
Setting up libglu1-mesa-dev (9.0.0-2) ...  
Setting up libpulse-dev:amd64 (1:4.0-0ubuntu11.1) ...  
Setting up libsdl1.2-dev (1.2.15-8ubuntu1.1) ...  
Setting up libx11-doc (2:1.6.2-1ubuntu2) ...  
Processing triggers for libc-bin (2.19-0ubuntu6) ...  
Reading package lists... Done  
Building dependency tree  
Reading state information... Done  
vlc is already the newest version.  
0 upgraded, 0 newly installed, 0 to remove and 537 not upgraded.  
----- check OS version -----  
ubuntu-14.4-64  
x64  
/lib/libieiaes.so: ELF 64-bit LSB shared object, x86-64, version 1 (SYSV), dynamically  
linked, not stripped
```


HDC-701EL SDK (Linux)

```
#sh load_pldev300usb.sh

#ls -al /dev/video0
crw-rw----+ 1 root video 81, 0 2015-04-23 00:39 /dev/video0
```

1.3.2 Source Code

Step 1: Copy the **IEI_hdc301xx_(SDK VERSION)_(RELEASE DATE)_(SVN VERSION).tar.gz** file from the utility CD to the system hard drive. The user can also get the latest version from IEI website.

Step 2: Unzip the file by typing:

```
tar zxvf IEI_hdcxxx_(SDK VERSION)_(RELEASE DATE)_(SVN VERSION).tar.gz
tar zxvf IEI_hdcxxx_0_0_3_2_5959.tar.gz
```

Step 3: Change to SDK directory by typing:

```
$ cd hdcxxx_(version) /api/linux/
$ cd hdcxxx_0_0_3_2/api/linux/
```

Step 4: Login as root by typing:

```
$ sudo su
```

Step 5: Enter the password:

```
password: *****
$
```

Step 6: Install the IEI HD Capture AP SDK by typing:

```
# sh build.sh
```

Step 7: The system starts to install the SDK and shows:

```
Reading package lists... Done
Building dependency tree
Reading state information... Done
libsd11.2-dev is already the newest version.
```

```
0 upgraded, 0 newly installed, 0 to remove and 513 not upgraded.
```

```
----- check OS version -----
```

```
ubuntu-14.4-64
```

```
x64
```

```
/lib/libieiaes.so: ELF 64-bit LSB shared object, x86-64, version 1 (SYSV), dynamically  
linked, not stripped
```

```
pldev300usb          565183  0
```

```
videodev            40486  1 pldev300usb#
```

Chapter

2

Using the SDK in Linux

2.1 Launch IEI HD Capture AP SDK

Step 1: To launch the IEI HD Capture AP SDK in Linux, type “hdctest” as below:

```
$ hdctest
```

Step 2: The system starts to launch the SDK.

When the main menu appears, it is ready to use.

```
-----
Build Nov  9 2015 09:59:21
```

```
SW_VERSION 0.0.3.2
-----
```

BOARD	DEV	MODEL	FW_VER	IN_HDMI_RES	IN_AUDIO_FREQ	COLOR SPACE	ENC_RES
[0]	[0]	HDB301L	0.5	I1920X1080P60	A_48K	RGB_LIMITED	O1920X1080P30
[1]	[2]	HDC301EL	0.1	I1920X1080P60	A_48K	YCRCB_601	O1920X1080P30
[2]	[3]	HDC301MS	1.0	I1920X1080P60	A_48K	RGB_LIMITED	O1920X1080P30
[3]	[4]	HDC_701E-2	0.8	I1920X1080P60	A_NA	RGB_FULL	O1920X1080P30

←----- 2 is HDC-701EL card id

```
[97] to capture all video
```

```
[99] exit
```

```
Select Board Or CMD: 0 ←----- select Board
```

```
-----
BOARD  DEV  MODEL  FW_VER  IN_HDMI_RES  IN_AUDIO_FREQ  COLOR SPACE  ENC_RES
[ 0]   [ 0]   HDB301L  0.5    I1920X1080P60  A_48K          RGB_LIMITED  O1920X1080P30
-----
```

```
SW INFO
-----
```

```
VIDEO:
```

```
VIDEO SOURCE: ←----- HDC-701EL only, support 1080P and 720P, see 2.3.5 Set Scaler Resolution
```

```
SOURCE_TYPE          HDMI
```

```
Source-InWidth       1920
```

```
Source-InHeight      1080
```

```
Source-ScanFormat    progressive
```

HDC-701EL SDK (Linux)

Source-InFrameRate 60

ENCODE INPUT:

PictureResolution-InPicWidth 1920

PictureResolution-InPicHeight 1080

InputControl-ScanFormat progressive

InputControl-InFrameRate 60

ENCODE OUTPUT:

PictureResolution-OutPicWidth 1920

PictureResolution-OutPicHeight 1080

InputControl-Fmt progressive

InputControl-OutFrameRate 30

AUDIO:

AudioControlParam-SampleRate NA

SETTING:

35. SCALER Function ←----- HDC-701EL only, see 2.3 HDC-701EL Function

41. AES Check

42. AES CID Check

50. Update HDMI Resolution (if you change source resolution)

CAPTURE:

58. Change Output Resolution

60. Capture Video

62. Live Mode (use VLC)

OTHER:

97. Update Board Information

98. Select Other Board

99. Exit Program

Please enter the choice>>

2.2 Video Capture

To configure the encoding settings and capture the video, please refer to the procedures described in the following sections.

2.2.1 Encoding Settings

Before capturing the video, please connect the hardware and follow the instructions below to configure the encoding settings.

Step 1: Launch the IEI HD Capture AP SDK (refer to **Section 2.1**).

Step 2: Type **60** to select “60. CAPTURE VIDEO” from the main menu.

60

Step 3: The following message shows.

```

cmd 60

-- CTRL C to Stop -----
plstrm video 0 enc config Config0
ofile ./BO_A_HDB301L_I1920X1080P60_O1920X1080P30_RGB_LIMITED_A_48K_20151109_142433_
F0.5_S0.0.2.0.mpg > tmp.log &

plstrm encoder

-----

MCU INFO
SW_VERSION 0.0.2.0
Build Apr 28 2015 14:15:41

-----

BOARD  DEV  MODEL  FW_VER  IN_HDMI_RES  IN_AUDIO_FREQ  COLOR SPACE  ENC_RES
[ 0]  [ 0]  HDB301L  0.5    I1920X1080P60  A_48K          RGB_LIMITED  O1920X1080P30

-----

SW INFO

-----

VIDEO:
INPUT:
PictureResolution-InPicWidth      1920
    
```

HDC-701EL SDK (Linux)

```

PictureResolution-InPicHeight      1080
InputControl-ScanFormat             progressive
InputControl-InFrameRate           60

OUTPUT:
PictureResolution-OutPicWidth       1920
PictureResolution-OutPicHeight     1080
InputControl-Fmt                   progressive
InputControl-OutFrameRate          30

AUDIO:
AudioControlParam-SampleRate       48k

-----
61. STOP VIDEO
Please enter the choice>>

```

Type **61** to stop “61. STOP VIDEO”.

2.2.2 Live

Before capturing the video, please connect the hardware and follow the instructions below to configure the encoding settings.

Step 1: Launch the IEI HD Capture AP SDK (refer to **Section 2.1**).

Step 2: Type **62** to select “Live Mode (use VLC)” from the main menu.

```
62
```

Step 3: The following message shows.

```

cmd 62
plstrm video 2 enc config /tmp/iei_conf2 oudp 127.0.0.1 oport 4562 > /dev/null &

vlc-iei --network-caching=800 udp://@127.0.0.1:4562 > /tmp/vlc2.log 2>&1 &

2736
2738

```

```
plstrm live
```

```
-----  
MCU INFO
```

```
-----  
BOARD  DEV  MODEL  FW_VER  ENCODE_IN    IN_AUDIO_FREQ  COLOR SPACE  ENCODE_OUT  
[ 2]    [ 2]  HDC_301MS  1.0    I1920X1080P60  A_48K          YCRCB_7090  I920X1080P30
```

```
-----  
SW INFO
```

```
-----  
VIDEO:
```

```
ENCODE INPUT:
```

```
PictureResolution-InPicWidth  1920
```

```
PictureResolution-InPicHeight 1080
```

```
InputControl-ScanFormat      progressive
```

```
InputControl-InFrameRate     60
```

```
ENCODE OUTPUT:
```

```
PictureResolution-OutPicWidth  1920
```

```
PictureResolution-OutPicHeight 1080
```

```
InputControl-Fmt             progressive
```

```
InputControl-OutFrameRate     30
```

```
AUDIO:
```

```
AudioControlParam-SampleRate  48k
```

```
-----  
SETTING:
```

```
41. AES    Check
```

```
42. AES    CID Check
```

```
50. Update HDMI Resolution (if you change source resolution)
```

```
-----  
CAPTURE:
```

```
61. Stop Video
```


HDC-701EL SDK (Linux)

```
-----  
OTHER:  
97. Update Board Information  
98. Select Other Board  
99. Exit Program  
Please enter the choice>>
```

Type **61** to stop "61. STOP VIDEO".

2.2.3 Update HDMI Source

To update HDMI source resolution, type **50**.

2.2.4 Select Other Board

To display main menu, type **98**.

2.2.5 Change Output

To change output resolution, type **58**.

```
cmd 58  
----- SELECT OUTPUT -----  
3 . 640X480P60  
4 . 720X480P60  
5 . 720X576P50  
6 . 800X600P60  
7 . 1024X768P60  
8 . 1280X720P50  
9 . 1280X720P60  
10 . 1280X768P60  
11 . 1280X800P60  
12 . 1280X1024P30  
13 . 1360X768P50  
14 . 1440X900P30  
15 . 1680X1050P30  
16 . 1920X1080P25
```

```
17 . 1920X1080P30
18 . 1920X1080P24
99 . Not Select
```

```
99 . Not Select
```

3

MCU INFO

SW_VERSION 0.0.1.9

Build Apr 23 2015 00:46:01

BOARD	DEV	MODEL	FW_VER	IN_HDMI_RES	IN_AUDIO_FREQ	COLOR SPACE	ENC_RES
[0]	[0]	HDB301L	0.5	I1920X1080P60	A_48K	RGB_LIMITED	O640X480P60

2.2.6 AES

Step 1: Type **80** to proceed with board AES check.

```
cmd 80
- PublicKey:    67 45 8b 6b
- vid1 :    c6 23 7b 32
- vid2 :    69 98 3c 64
- AES pass 0
```

Step 2: Type **81** to input custom AES CID Key.

```
please input company id ***.xxxx
- cid:    x x x x
- PublicKey:    73 48 33 66
- vid1 :    51 dc b0 74
- vid2 :    ff 5c 49 19
- AES pass 0
```

HDC-701EL SDK (Linux)

2.3 HDC-701EL Function

Step 1: Launch the IEI HD Capture AP SDK (refer to **Section 2.1**).

Step 2: Type **35** to set up HDC-701EL scaler function.

```
cmd 35
=====SCALER FUNCTION SHOW CMD =====
[ 1] SET_MAIN_INPUT_SOURCE   : HDMI
[ 44] SET_ASPECT_RATIO       : DOT_BY_DOT
[ 61] AUDIO_ENABLE          : AUDIO_DISABLE
[ 64] GET_SAMPLE_RATE        : RATE_NA
[ 65] SET_SCALER_RESOLUTION  : RES_720P

[99] EXIT
```

2.3.1 Set Main Input Source

Type **1** to set up the main input source.

```
#1

[ 0]DVI_VGA
[ 1]DVI_DIGITAL
[ 2]DVI_HDMI
[ 3]HDMI
[ 4]DP

#
```

2.3.2 Set Aspect Ratio

Type **44** to set up the aspect ratio.

```
#44

[ 0]FULL_SCREEN
[ 1]KEEP_ASPECT_RATIO
[ 2]DOT_BY_DOT
```

2.3.3 Enable/Disable Audio Input

Type **61** to enable or disable audio input.

```
#61  
  
[ 0]AUDIO ENABLE  
[ 1]AUDIO DISABLE  
#
```

2.3.4 Get Sample Rate

Type **64** to get the sample rate.

```
#64  
  
[ 64] GET_SAMPLE_RATE      : RATE_48KHz
```

2.3.5 Set Scaler Resolution

Type **65** to set up the scaler output resolution.

```
#65  
  
[ 0]RES_720P  
[ 1]RES_1080P  
#
```

Chapter

3

Linux Open Source Code

Linux Open Source Code

This product from IEI contains software originating from Fujitsu and its suppliers and also contains component from the open source community. Software code is subject to the GNU General Public License. See the GNU General Public License for the exact terms and conditions of this license.

The GPL Code used in this product are distributed without any warranty and are subject to the copyrights of their authors. You can obtain the open source code in the user manual CD-ROM or at <http://www.ieiworld.com> under "Download" page.

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.,
51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA
Everyone is permitted to copy and distribute verbatim copies
of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

HDC-701EL SDK (Linux)

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

HDC-701EL SDK (Linux)

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

HDC-701EL SDK (Linux)

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

HDC-701EL SDK (Linux)

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

```
Gnomovision version 69, Copyright (C) year name of author
```

```
Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'.
```

```
This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.
```

The hypothetical commands ``show w'` and ``show c'` should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than ``show w'` and ``show c'`; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

```
Yoyodyne, Inc., hereby disclaims all copyright interest in the program
```

```
`Gnomovision' (which makes passes at compilers) written by James Hacker.
```

```
<signature of Ty Coon>, 1 April 1989
```

```
Ty Coon, President of Vice
```

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.