


PuIM Series


PuIM-1G4SF-I350




www.ieiworld.com

Package Contents


PuIM-1G4SF-I350



PuIM-1 G4SF-I350 Block Diagram




LAN LED Status



LED	State	Description
Link (Right)	Yellow 	Active
Speed (Left)	Green 	1 Gbps data rate
	Orange 	100 Mbps data rate


Hardware Installation



Networking Module Installation


Step 1

Use the Torx wrench to remove the two Torx screws.




Step 2

Remove the slot cover. Save the slot cover screws.



Step 3

Slide an IEI networking module into the slot until the module is seated in the slot correctly and securely.



Step 4

Install the previously-removed Torx screws to secure the module to the chassis.

