



» Gather your materials from this kit:



TANK System



Power Adapter



Wall Mount Kit

» What's installed:

- Ubuntu desktop 20.04
- Intel® Distribution of OpenVINO™ toolkit

» You also need the following (not included in the kit):

- Monitor
- Mouse
- HDMI or DisplayPort cable
- Ethernet cable
- Keyboard

» Learn more about the kit and get started:



IEI TANK-XM811 AIoT Dev. Kit



Get Started Guide




Copyright© 2022 IEI. All rights reserved. Specifications are subject to change without notice. Intel, the Intel logo, and Intel Core are trademarks of Intel Corporation or its subsidiaries. Other brands and product names are trademarks or registered trademarks of their respective holder.

# TANK

**ACCELERATE TO THE FUTURE**


## IEI TANK-XM811 AIoT Developer Kit Quick Start Guide



**! Important: Read all of the instructions carefully**

**1 Connect the HDMI or DisplayPort devices**

Plug in the HDMI or DisplayPort connector.




**2 Connect the Ethernet cable and peripheral devices**

The TANK system is equipped with Ethernet capabilities.



**3 Plug the power adapter into power connector**



**4 Turn on**

Press and hold the power button for three seconds or until the LED lights up



**5 Log in**

Log in with the default user name and password.

Username:

Password:

**6**



Learn more from the Get Started Guide.