

**MODEL:
NANO-ADL-P**

**EPIC SBC Supports Intel® Alder Lake-P Processor,
Dual HDMI, DP, iDPM, M.2 A Key, M.2 B Key, USB 3.2, SATA
6Gb/s, COM, iAUDIO, PCIe x4 for Riser Card and RoHS**

User Manual

Revision

Date	Version	Changes
June 27, 2023	1.00	Initial release

Copyright

COPYRIGHT NOTICE

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

TRADEMARKS

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Manual Conventions



WARNING

Warnings appear where overlooked details may cause damage to the equipment or result in personal injury. Warnings should be taken seriously.



CAUTION

Cautionary messages should be heeded to help reduce the chance of losing data or damaging the product.



NOTE

These messages inform the reader of essential but non-critical information. These messages should be read carefully as any directions or instructions contained therein can help avoid making mistakes.

Table of Contents

1 INTRODUCTION.....	15
1.1 INTRODUCTION.....	16
1.2 FEATURES.....	17
1.3 CONNECTORS	18
1.4 DIMENSIONS.....	19
1.5 DATA FLOW	20
1.6 TECHNICAL SPECIFICATIONS	21
2 PACKING LIST.....	23
2.1 ANTI-STATIC PRECAUTIONS.....	24
2.2 UNPACKING PRECAUTIONS.....	24
2.3 PACKING LIST	25
2.4 OPTIONAL ITEMS	26
3 CONNECTORS	28
3.1 PERIPHERAL INTERFACE CONNECTORS.....	29
3.1.1 NANO-ADL-P Layout	29
3.1.2 Peripheral Interface Connectors	29
3.1.3 External Interface Panel Connectors.....	31
3.2 INTERNAL PERIPHERAL CONNECTORS	31
3.2.1 Battery Connector.....	31
3.2.2 AT/ATX Power Mode Setting	33
3.2.3 12V Power Input Connector	34
3.2.4 Digital I/O Connector	35
3.2.5 EC Debug Connector.....	36
3.2.6 Clear CMOS Button.....	36
3.2.7 Flash Descriptor Security Override Setting Jumper	37
3.2.8 Fan Connector (CPU).....	39
3.2.9 Audio Connector	40
3.2.10 Buzzer Connector.....	41
3.2.11 Front Panel Connector.....	42

3.2.12 I ² C Connector	43
3.2.13 SMBus Connector	44
3.2.14 M.2 A-key Slot	45
3.2.15 M.2 B-key Slot	47
3.2.16 PCIe x4 Slots	49
3.2.17 IDPM Slot	50
3.2.18 Power button connector	52
3.2.19 Reset button connector	53
3.2.20 SATA 6Gb/s Connectors	54
3.2.21 SATA Power Connectors	55
3.2.22 RS-232 Serial Port Connectors	56
3.2.23 RS-232/422/485 Serial Port Connectors	57
3.2.24 Flash SPI ROM Connector	58
3.2.25 Flash EC ROM Connector	59
3.2.26 Internal USB 2.0 connectors	60
3.3 EXTERNAL PERIPHERAL INTERFACE CONNECTOR PANEL	61
3.3.1 External dual USB 3.2 Gen 2 connectors	61
3.3.2 External dual HDMI Connector	62
3.3.3 External 2.5GbE RJ-45 connectors	63
3.3.4 External DP connector	64
4 INSTALLATION	65
4.1 ANTI-STATIC PRECAUTIONS	66
4.2 INSTALLATION CONSIDERATIONS	66
4.3 M.2 MODULE INSTALLATION	67
4.4 HEAT SPREADER	71
4.5 RISER CARD INSTALLATION	72
4.6 INTERNAL PERIPHERAL DEVICE CONNECTIONS	75
4.6.1 SATA Drive Connection	75
4.6.2 AT Power Connection	76
4.6.3 7.1 Channel Audio Kit Installation	78
4.7 SOFTWARE DRIVERS	79
4.7.1 Software Installation	79
4.7.2 Driver Download	80
5 BIOS	82

NANO-ADL-P

5.1 INTRODUCTION.....	83
5.1.1 Starting Setup.....	83
5.1.2 Using Setup	84
5.1.2.1 Keyboard Navigation	84
5.1.2.2 Touch Navigation	85
5.1.3 Getting Help.....	86
5.1.4 Unable to Reboot after Configuration Changes	86
5.1.5 BIOS Menu Bar.....	86
5.2 MAIN.....	87
5.3 ADVANCED.....	90
5.3.1 CPU Configuration	91
5.3.2 Trusted Computing.....	95
5.3.3 RTC Wake Settings	96
5.3.4 F81966 Super IO Configuration	98
5.3.4.1 Serial Port 1 Configuration	99
5.3.4.2 Serial Port 2 Configuration	100
5.3.4.3 Serial Port 3 Configuration	101
5.3.4.4 Serial Port 4 Configuration	102
5.3.4.5 Serial Port 5 Configuration	103
5.3.4.6 Serial Port 6 Configuration	104
5.3.5 EC KB9068 H/W Monitor.....	105
5.3.5.1 Smart Fan Mode Configuration	107
5.3.6 Serial Port Console Redirection	108
5.3.6.1 Console Redirection Settings	109
5.3.7 NVMe Configuration.....	112
5.4 CHIPSET	113
5.4.1 System Agent (SA) Configuration	114
5.4.1.1 Memory Configuration	115
5.4.1.2 Graphics Configuration.....	117
5.4.1.3 PEG Port Configuration.....	119
5.4.2 PCH-IO Configuration	120
5.4.2.1 PCI Express Configuration	123
5.4.2.1.1 PCIe Root Port Setting.....	124
5.4.2.2 SATA Configuration.....	125
5.4.2.3 HD Audio Configuration.....	127

5.5 SECURITY	128
5.6 BOOT.....	130
5.6.1 Boot Configuration	130
5.6.2 Boot Option Priorities.....	131
5.7 SAVE & EXIT	132
A REGULATORY COMPLIANCE	134
B PRODUCT DISPOSAL	136
C BIOS OPTIONS	138
D WATCHDOG TIMER	142
E ERROR BEEP CODE.....	145
E.1 PEI BEEP CODES.....	146
E.2 DXE BEEP CODES	146
F HAZARDOUS MATERIALS DISCLOSURE.....	147
F.1 RoHS II DIRECTIVE (2015/863/EU)	148
F.2 CHINA RoHS.....	149

List of Figures

Figure 1-1: NANO-ADL-P	16
Figure 1-2: Connectors	18
Figure 1-3: NANO-ADL-P Dimensions (mm)	19
Figure 1-4: Data Flow Diagram	20
Figure 3-1: Peripheral Interface Connectors	29
Figure 3-2: Battery Connector Location	32
Figure 3-3: AT/ATX Power Mode Switch Location	33
Figure 3-4: 12V Power Input Connector Location	34
Figure 3-5: Digital I/O Connector Location	35
Figure 3-6: EC Debug Connector Location	36
Figure 3-7: Clear CMOS Jumper Location	37
Figure 3-8: Flash Descriptor Security Override Setting Jumper Location	38
Figure 3-9: CPU Fan Connector Location	39
Figure 3-10: Audio Connector Location	40
Figure 3-11: Buzzer Connector Location	41
Figure 3-12: Front Panel Connector Location	42
Figure 3-13: I ² C Connector Location	43
Figure 3-14: SMBus Connector Location	44
Figure 3-15: M.2 A-key Slot Location	45
Figure 3-16: M.2 B-key Slot Location	47
Figure 3-17: PCIe x4 Slot Location	49
Figure 3-18: IDPM Slot Location	50
Figure 3-19: Power Button Connector Location	52
Figure 3-20: Reset Button Connector Location	53
Figure 3-21: SATA 6Gb/s Connector Location	54
Figure 3-22: SATA Power Connector Location	55
Figure 3-23: RS-232 Connector Locations	56
Figure 3-24: RS-232/422/485 Connector Locations	57
Figure 3-25: Flash SPI ROM Connector Location	58
Figure 3-26: Flash EC ROM Connector Location	59
Figure 3-27: Internal USB 2.0 Connector Location	60

Figure 3-28: External Peripheral Interface Connector	61
Figure 3-29: External dual USB 3.2 Gen 2 connectors	61
Figure 3-30: HDMI Connectors	62
Figure 3-31: LAN LED Location.....	63
Figure 3-32: DP Connector	64
Figure 4-1: Inserting the M.2 Module into the Slot at an Angle.....	68
Figure 4-2: Securing the M.2 Module.....	68
Figure 4-3: Press the Retainer.....	69
Figure 4-4: Aligning the M.2 Module with the Retainer.....	69
Figure 4-5: Securing the M.2 Module.....	70
Figure 4-6: Heat Sink Retention Screws.....	71
Figure 4-7:Outwards Riser Card Installation Example	72
Figure 4-8: NWR-L2S-R10	72
Figure 4-9: Inwards Riser Card Installation Example	73
Figure 4-10: NWR-R2S-R10.....	73
Figure 4-11:L-shaped Bracket Installation Example	74
Figure 4-12: SATA Drive Cable Connection.....	75
Figure 4-13: SATA Power Drive Connection.....	76
Figure 4-14: Power Cable to Motherboard Connection	77
Figure 4-15: Connect Power Cable to Power Supply.....	77
Figure 4-16: 7.1 Channel Audio Kit	78
Figure 4-17: IEI Resource Download Center.....	79
Figure 5-1: BIOS Starting Menu	83

List of Tables

Table 1-1: NANO-ADL-P Specifications.....	22
Table 2-1: Packing List.....	25
Table 2-2: Optional Items	27
Table 3-1: Peripheral Interface Connectors	30
Table 3-2: Rear Panel Connectors	31
Table 3-3: Battery Connector Pinouts	32
Table 3-4: AT/ATX Power Mode Switch Settings.....	33
Table 3-5: 12V Power Input Connector Pinouts	34
Table 3-6: Digital I/O Connector Pinouts.....	35
Table 3-7: EC Debug Connector Pinouts	36
Table 3-8: Clear CMOS Jumper Pinouts.....	37
Table 3-9: Flash Descriptor Security Override Setting Jumper Pinouts.....	38
Table 3-10: CPU Fan Connector Pinouts.....	39
Table 3-11: Audio Connector Pinouts	40
Table 3-12: Buzzer Connector Pinouts.....	41
Table 3-13: Front Panel Connector Pinouts.....	42
Table 3-14: I ² C Connector Pinouts.....	43
Table 3-15: SMBus Connector Pinouts	44
Table 3-16: M.2 A-key Connector Pinouts.....	46
Table 3-17: M.2 B-key Connector Pinouts.....	48
Table 3-18: iDPM Connector Pinouts.....	51
Table 3-19: Power Button Connector Pinouts	52
Table 3-20: Reset Button Connector Pinouts	53
Table 3-21: SATA 6Gb/s Connector Pinouts.....	54
Table 3-22: SATA Power Connector Pinouts.....	55
Table 3-23: RS-232 Connector Pinouts	56
Table 3-24: RS-232/422/485 Connector Pinouts	57
Table 3-25: Flash SPI ROM Connector Pinouts.....	58
Table 3-26: Flash EC ROM Connector Pinouts.....	59
Table 3-27: Internal USB 2.0 Connector Pinouts.....	60
Table 3-28: USB 3.2 Port Pinouts.....	62

Table 3-29: HDMI Connector Pinouts	63
Table 3-30: 2.5GbE RJ45 Pinouts.....	63
Table 3-31: LAN LED Pinouts	63
Table 3-32: DP Connector Pinouts.....	64
Table 5-1: BIOS Navigation Keys	84
Table 5-2: BIOS On-screen Navigation Keys	85

BIOS Menus

BIOS Menu 1: Main (1/3).....	87
BIOS Menu 2: Main (2/3).....	87
BIOS Menu 3: Main (3/3).....	88
BIOS Menu 4: Advanced	90
BIOS Menu 5: CPU Configuration (1/3).....	91
BIOS Menu 6: CPU Configuration (2/3).....	92
BIOS Menu 7: CPU Configuration (3/3).....	92
BIOS Menu 8: Trusted Computing Configuration	95
BIOS Menu 9: RTC Wake Settings (1/2).....	96
BIOS Menu 10: RTC Wake Settings (2/2).....	97
BIOS Menu 11: F81966 Super IO Configuration	98
BIOS Menu 12: Serial Port 1 Configuration Menu	99
BIOS Menu 13: Serial Port 2 Configuration Menu	100
BIOS Menu 14: Serial Port 3 Configuration Menu	101
BIOS Menu 15: Serial Port 4 Configuration Menu	102
BIOS Menu 16: Serial Port 5 Configuration Menu	103
BIOS Menu 17: Serial Port 6 Configuration Menu	104
BIOS Menu 18: EC KB9068 H/W Monitor.....	105
BIOS Menu 19: Smart Fan Mode Configuration	107
BIOS Menu 20: Serial Port Console Redirection (1/2).....	108
BIOS Menu 21: Serial Port Console Redirection (2/2).....	109
BIOS Menu 22: COM Console Redirection Settings	110
BIOS Menu 23: NVMe Configuration.....	112
BIOS Menu 24: Chipset	113
BIOS Menu 25: System Agent (SA) Configuration	114
BIOS Menu 26: Memory Configuration (1/2)	115
BIOS Menu 27: Memory Configuration (2/2)	116
BIOS Menu 28: Graphics Configuration	117
BIOS Menu 29: PEG Port Configuration.....	119
BIOS Menu 30: PCH-IO Configuration (1/2)	120
BIOS Menu 31: PCH-IO Configuration (2/2)	121

BIOS Menu 32: PCI Express Configuration	123
BIOS Menu 33: PCIe Slot Configuration Submenu	124
BIOS Menu 34: SATA Configuration	125
BIOS Menu 35: HD Audio Configuration	127
BIOS Menu 36: Security (1/2).....	128
BIOS Menu 37: Security (2/2).....	129
BIOS Menu 38: Boot	130
BIOS Menu 39: Save & Exit.....	132

Chapter

1

Introduction

1.1 Introduction




Figure 1-1: NANO-ADL-P

The NANO-ADL-P is powered by 12th Gen. Intel® mobile Alder Lake-P on board SoC and on-board 8GB 3200 MHz LPDDR4x memory (up to 16GB). The NANO-ADL-P supports one SATA 6Gb/s drive. Moreover, the NANO-ADL-P includes DP, two HDMI and IEI iDPM slot for quadruple independent display.

The NANO-ADL-P provides two 2.5GbE interfaces through the Intel® I225V controllers. Expansion and I/O include one PCIe x4 slot, two M.2 slots, six COM ports, four USB 3.2 Gen 2 and four USB 2.0.

NANO-ADL-P

1.2 Features

Some of the NANO-ADL-P motherboard features are listed below:

- 12th Gen. Intel® mobile Alder Lake-P on board SoC
- On-board 8GB 3200 MHz LPDDR4x memory, up to 16GB
- 2 x Intel® I225V 2.5GbE controller
- Quadruple independent display by two HDMI, DP and IEI iDPM slot
- One SATA 6Gb/s connector
- Four USB 3.2 Gen 2 ports and four USB 2.0 ports
- One M.2 A key for Wi-Fi & BT; one M.2 B key with SIM slot
- 1 x PCIe x4 slot
- Six serial ports
- TPM 2.0 security function supported by PTT
- RoHS compliant

1.3 Connectors

The connectors on the NANO-ADL-P are shown in the figure below.




Figure 1-2: Connectors

NANO-ADL-P

1.4 Dimensions

The main dimensions of the NANO-ADL-P are shown in the diagram below.




Figure 1-3: NANO-ADL-P Dimensions (mm)

1.5 Data Flow

Figure 1-4 shows the data flow between the system chipset, the CPU and other components installed on the motherboard.




Figure 1-4: Data Flow Diagram

NANO-ADL-P

1.6 Technical Specifications

The NANO-ADL-P technical specifications are listed below.

Specification/Model	NANO-ADL-P
Form Factor	EPIC
CPU Supported	12th Gen. Intel® mobile Alder Lake-P on board SoC
Memory	On-board 8GB 3200 MHz LPDDR4x memory, up to 16GB
Graphics Engine	Intel® Xe Graphics architecture, 4 independent displays, up to 8K resolutions
Display Output	Quadruple independent display 2 x HDMI 1.4a (up to 4096 x 2160 @ 30Hz) 1 x DP 1.4a (up to 4096 x 2160 @ 60Hz) 1 x IEI iDPM slot (only for IEI eDP/ LVDS/ VGA module)
Ethernet Controllers	2 x Intel® I225V 2.5GbE controller
Audio	1 x Analog audio (2x5 pin, p=2.0) supports 7.1 channel HD audio by IEI AC-KIT-888S audio kit
BIOS	AMI UEFI BIOS
Watchdog Timer	Software programmable supports 1~255 sec. system reset
Expansions	1 x M.2 2230 A key for Wi-Fi & BT (PCIe Gen3 x1 & USB 2.0) 1 x M.2 3042/2280 B key with SIM slot (PCIe x2) 1 x PCIe x4 slot (PCIe x4 signal, x4 & x2+x2 & x2+x1+x1)
I/O Interface Connectors	
Audio Connectors	One internal audio connector (10-pin header)
Digital I/O	12-bit digital I/O
Ethernet	Two RJ-45 GbE ports
Fan	1 x System fan connector (1x4 pin)
Front Panel	1 x Front panel (1x6 pin, p=2.0; power LED, HDD LED) 1 x Power button connector (1x2 pin, p=2.0) 1 x Reset button connector (1x2 pin, p=2.0)

Specification/Model	NANO-ADL-P
I²C	One 4-pin wafer connector
Serial ATA	One SATA 6Gb/s connectors
Serial Ports	2 x RS-232/422/485 4 x RS-232
SMBus	One 4-pin wafer connector
USB Ports	4 x USB 3.2 Gen 2 (Type-A) (10Gb/s) 4 x USB 2.0 (2x4 pin, p=2.0)
Environmental and Power Specifications	
Power Supply	AT/ATX power supply
Power Consumption	12V@4.62A (12th Gen Intel® Core™ i7-1265UE CPU with 8 GB 3200 MHz LPDDR4x memory, max. loading, EuP mode enabled)
Operating Temperature	0°C ~ 60°C
Storage Temperature	-30°C ~ 70°C
Operating Humidity	5% ~ 95% (non-condensing)
Physical Specifications	
Dimensions	115 mm x 165 mm
Weight (GW/NW)	900g / 400g

Table 1-1: NANO-ADL-P Specifications

Chapter

2

Packing List

2.1 Anti-static Precautions



WARNING!

Static electricity can destroy certain electronics. Make sure to follow the ESD precautions to prevent damage to the product, and injury to the user.

Make sure to adhere to the following guidelines:

- **Wear an anti-static wristband:** Wearing an anti-static wristband can prevent electrostatic discharge.
- **Self-grounding:** Touch a grounded conductor every few minutes to discharge any excess static buildup.
- **Use an anti-static pad:** When configuring any circuit board, place it on an anti-static mat.
- **Only handle the edges of the PCB:** Don't touch the surface of the motherboard. Hold the motherboard by the edges when handling.

2.2 Unpacking Precautions

When the NANO-ADL-P is unpacked, please do the following:

- Follow the anti-static guidelines above.
- Make sure the packing box is facing upwards when opening.
- Make sure all the packing list items are present.

NANO-ADL-P

2.3 Packing List



NOTE:

If any of the components listed in the checklist below are missing, do not proceed with the installation. Contact the IEI reseller or vendor the NANO-ADL-P was purchased from or contact an IEI sales representative directly by sending an email to sales@ieiworld.com.

The NANO-ADL-P is shipped with the following components:












Quantity	Item and Part Number	Image
1	NANO-ADL-P single board computer	
2	SATA cable	
1	Quick installation guide	<p><small>EPIC SEC Supports Intel® Alder Lake-P Processor, Dual HDMI DP, EDIMM M.2 A Key, M.2 B Key, 10G SFP, SATA, USB, COM, M.2 NVMe, PCIe M.2 Slot, 4K Display and 4K Display</small></p> <p>NANO-ADL-P</p> <p>Quick Installation Guide</p> <p>Version 1.0</p> <p>December 12, 2022</p> <p>Package List:</p> <p>NANO-ADL-P package includes the following items:</p> <ul style="list-style-type: none"> • 1 x NANO-ADL-P single board computer with heat spreader • 1 x SATA with power cable • 1 x QIG <p></p> <p><small>©2022 Copyright by IEI Integration Corp. All rights reserved.</small></p>

Table 2-1: Packing List

2.4 Optional Items

The following are optional components which may be separately purchased:

Item and Part Number	Image
SATA power cable (P/N: 32102-000100-200-RS)	
Realtek ALC888S 7.1 Channel HD Audio board, RoHS (P/N: AC-KIT-888S-R10)	
Dual-port USB cable with bracket, 300mm, p=2.0 (P/N: CB-USB02A-RS)	
RS-232/422/485 cable, 200mm, p=2.0 (P/N: 32205-002700-200-RS)	
eDP to eDP converter board (for IEI iDPM connector) (P/N: iDPM-eDP-R10)	
eDP to LVDS converter board (for IEI iDPM connector) (P/N: iDPM-LVDS-R10)	
eDP to VGA converter board (for IEI iDPM connector) (P/N: iDPM-VGA-R10)	
PCIe x2 to two PCIe x1 riser card for NANO on the left side (P/N: NWR-L2S-R10)	

NANO-ADL-P


Item and Part Number	Image
PCIe x2 to two PCIe x1 riser card for NANO on the right side (P/N: NWR-R2S-R10)	

Table 2-2: Optional Items

Chapter

3

Connectors

NANO-ADL-P

3.1 Peripheral Interface Connectors

This chapter details all the peripheral interface connectors.

3.1.1 NANO-ADL-P Layout

The figures below show all the peripheral interface connectors.




Figure 3-1: Peripheral Interface Connectors

3.1.2 Peripheral Interface Connectors

The table below lists all the connectors on the board.

Connector	Type	Label
AT/ATX power mode setting	3-pin switch	J_ATX_AT1
Clear CMOS jumper	Button	J_CMOS1
Flash descriptor security override jumper	2-pin header	ME_FLASH1

Connector	Type	Label
Audio connector for IEI AC-KIT-888S kit	10-pin header	IAUDIO1
12V power input connector	4-pin connector	PWR1
RTC battery connector	2-pin header	BAT1
Buzzer connector	2-pin header	SP1
Digital I/O connector	14-pin header	J_DIO1
EC debug connector	6-pin header	EC_DBG1
Fan connector	4-pin header	CPU/FAN1
Front panel connector	6-pin header	F_PANEL1
I2C connector	4-pin wafer	J_I2C1
Power button connector	2-pin header	PWR_BTN1
Reset button connector	2-pin header	RST_BTN1
RS-232 serial port connectors	10-pin header	COM1, COM2, COM3, COM4
RS-232/422/485 serial port connectors	10-pin header	COM5, COM6
SATA 6Gb/s connector	10-pin box header	SATA1
SATA power connector	2-pin header	SATA_PWR1
SMBus connector	4-pin wafer	J_SMB1
Flash SPI ROM connector	6-pin header	J_SPI1
Flash EC ROM connector	8-pin header	EC_SPI1
Internal USB 2.0 connectors	8-pin header	USB2_1, USB2_2
IEI iDPM slot	20-pin box header	IDPM
PCIe x4 slot	PCIe x4 Slot	PCIEX4_1
M.2 2230 A key slot	M-key slot	M2_A1
M.2 2242/2280 B key slot	M-key slot	M2_B1

Table 3-1: Peripheral Interface Connectors

NANO-ADL-P

3.1.3 External Interface Panel Connectors

The table below lists the connectors on the external I/O panel.

Connector	Type	Label
External dual HDMI connector	HDMI	HDMI1
External DP connector	DP	DP1
External 2.5GbE RJ-45 connector	RJ45	LAN1, LAN2
External dual USB 3.2 Gen 2 connectors	USB	USB3_1, USB3_2

Table 3-2: Rear Panel Connectors

3.2 Internal Peripheral Connectors

The section describes all of the connectors on the NANO-ADL-P.

3.2.1 Battery Connector



CAUTION:

Risk of explosion if battery is replaced by an incorrect type. Only certified engineers should replace the on-board battery.

Dispose of used batteries according to instructions and local regulations.



NOTE:

It is recommended to attach the RTC battery onto the system chassis in which the NANO-ADL-P is installed.

- CN Label:** **BAT1**
- CN Type:** 2-pin header
- CN Location:** See **Figure 3-2**
- CN Pinouts:** See **Table 3-3**

A system battery is placed in the battery holder. The battery provides power to the system clock to retain the time when power is turned off.




Figure 3-2: Battery Connector Location

Pin	Description	Pin	Description
1	VBATT	2	GND

Table 3-3: Battery Connector Pinouts

NANO-ADL-P

3.2.2 AT/ATX Power Mode Setting

- CN Label:** J_ATX_AT1
- CN Type:** 3-pin switch
- CN Location:** See **Figure 3-3**
- CN Pinouts:** See **Table 3-4**

The AT/ATX power mode selection is made through the AT/ATX power mode switch.




Figure 3-3: AT/ATX Power Mode Switch Location

Pin	Description	Pin	Description
Short A - B	ATX Power Mode (default)	Short B - C	AT Power Mode

Table 3-4: AT/ATX Power Mode Switch Settings

3.2.3 12V Power Input Connector

- CN Label:** PWR1
- CN Type:** 4-pin Molex
- CN Location:** See **Figure 3-4**
- CN Pinouts:** See **Table 3-5**

The 12V power input connector supports the +12V power supply.




Figure 3-4: 12V Power Input Connector Location

Pin	Description	Pin	Description
1	GND	3	+12V
2	GND	4	+12V

Table 3-5: 12V Power Input Connector Pinouts

NANO-ADL-P

3.2.4 Digital I/O Connector

- CN Label:** J_DIO1
- CN Type:** 14-pin header, p=2.0 mm
- CN Location:** See **Figure 3-5**
- CN Pinouts:** See **Table 3-6**

The Digital I/O connector provides programmable input and output for external devices.




Figure 3-5: Digital I/O Connector Location

Pin	Description	Pin	Description
1	GND	2	VCC
3	Output 5	4	Output 4
5	Output 3	6	Output 2
7	Output 1	8	Output 0
9	Input 5	10	Input 4
11	Input 3	12	Input 2
13	Input 1	14	Input 0

Table 3-6: Digital I/O Connector Pinouts

3.2.5 EC Debug Connector

- CN Label:** EC_DEBUG1
- CN Type:** 6-pin header
- CN Location:** See Figure 3-6
- CN Pinouts:** See Table 3-7

The EC debug connector is used for EC debug.




Figure 3-6: EC Debug Connector Location

Pin	Description	Pin	Description
1	NC	4	EDICLK
2	EDICS	5	EDIDI
3	EDIDO	6	GND

Table 3-7: EC Debug Connector Pinouts

3.2.6 Clear CMOS Button

- CN Label:** J_CMOS1
- CN Type:** Button
- CN Location:** See Figure 3-7
- CN Pinouts:** See Table 3-8

The J_CMOS1 is used to Clear CMOS Setup.

NANO-ADL-P




Figure 3-7: Clear CMOS Jumper Location

Pin	Description
NC	Keep CMOS Setup (Normal Operation)
Press	Clear CMOS Setup

Table 3-8: Clear CMOS Jumper Pinouts

3.2.7 Flash Descriptor Security Override Setting Jumper

- CN Label:** ME_FLASH1
- CN Type:** 2-pin header
- CN Location:** See Figure 3-8
- CN Pinouts:** See Table 3-9

The Flash Descriptor Security Override Setting Jumper connector is used for Flash Descriptor Security Override.




Figure 3-8: Flash Descriptor Security Override Setting Jumper Location

Pin	Description
Open	Disabled (default)
Short	Enabled

Table 3-9: Flash Descriptor Security Override Setting Jumper Pinouts

NANO-ADL-P

3.2.8 Fan Connector (CPU)

- CN Label:** CPU/FAN1
- CN Type:** 4-pin header, p=2.54 mm
- CN Location:** See **Figure 3-9**
- CN Pinouts:** See **Table 3-10**

The fan connector attaches to a CPU cooling fan.




Figure 3-9: CPU Fan Connector Location

Pin	Description	Pin	Description
1	GND	3	FANIO
2	+12V	4	PWM (+5V)

Table 3-10: CPU Fan Connector Pinouts

3.2.9 Audio Connector

- CN Label:** IAUDIO1
- CN Type:** 10-pin header, p=2.54 mm
- CN Location:** See **Figure 3-10**
- CN Pinouts:** See **Table 3-11**

This connector connects to speakers, a microphone and an audio input.




Figure 3-10: Audio Connector Location

Pin	Description	Pin	Description
1	HDA_SYNC_R	2	HDA_BCLK_R
3	HDA_SDO_R	4	HDA_PCBEEP
5	HDA_SDI_0_R	6	HDA_RST_R
7	+5V	8	GND
9	+12V	10	GND

Table 3-11: Audio Connector Pinouts

NANO-ADL-P

3.2.10 Buzzer Connector

- CN Label:** SP1
- CN Type:** 2-pin header, p=2.54 mm
- CN Location:** See **Figure 3-11**
- CN Pinouts:** See **Table 3-12**

The buzzer connector is connected with the buzzer to give a beep warning when the motherboard goes wrong.




Figure 3-11: Buzzer Connector Location

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	+5V	2	PC_BEEP_N

Table 3-12: Buzzer Connector Pinouts

3.2.11 Front Panel Connector

- CN Label:** F_PANEL1
- CN Type:** 6-pin header, p=2.54 mm
- CN Location:** See Figure 3-12
- CN Pinouts:** See Table 3-13

The front panel connector connects to the power LED indicator and HDD LED indicator on the system front panel.




Figure 3-12: Front Panel Connector Location

Pin	Description	Pin	Description
1	VCC	4	PWR_LED-
2	GND	5	HDD_LED+
3	PWR_LED+	6	HDD_LED-

Table 3-13: Front Panel Connector Pinouts

NANO-ADL-P

3.2.12 I²C Connector

- CN Label:** J_I2C1
- CN Type:** 4-pin wafer, p=1.25 mm
- CN Location:** See **Figure 3-13**
- CN Pinouts:** See **Table 3-14**

The I²C connector is used to connect I²C-bus devices to the mainboard.




Figure 3-13: I²C Connector Location

Pin	Description	Pin	Description
1	GND	3	I2C_CLK
2	SMB_DATA_EC	4	+5V

Table 3-14: I²C Connector Pinouts

3.2.13 SMBus Connector

- CN Label:** J_SMB1
- CN Type:** 4-pin wafer, p=1.25 mm
- CN Location:** See **Figure 3-14**
- CN Pinouts:** See **Table 3-15**

The SMBus is a two-wire bus used for communication with low bandwidth devices on a motherboard such as power related chips and temperature sensors.




Figure 3-14: SMBus Connector Location

Pin	Description
1	GND
2	SMB_DATA
3	SMB_CLK
4	+5V

Table 3-15: SMBus Connector Pinouts

NANO-ADL-P

3.2.14 M.2 A-key Slot

- CN Label:** M2_A1
- CN Type:** M-key slot
- CN Location:** See **Figure 3-15**
- CN Pinouts:** See **Table 3-16**

The M.2 2230 slot is keyed in the A position.




Figure 3-15: M.2 A-key Slot Location

Pin	Description	Pin	Description
1	GND	2	+3.3V
3	USB2_DP	4	+3.3V
5	USB2_DN	6	NC
7	GND	8	Module Key
9	Module Key	10	Module Key
11	Module Key	12	Module Key
13	Module Key	14	Module Key
15	Module Key	16	NC
17	NC	18	GND
19	NC	20	NC
21	NC	22	NC
23	GND	24	GND
25	NC	26	NC

Pin	Description	Pin	Description
27	NC	28	NC
29	GND	30	GND
31	NC	32	NC
33	GND	34	NC
35	PCIE_TX_DP	36	GND
37	PCIE_TX_DN	38	WLAN_CL_RST_N
39	GND	40	WLAN_CL_DATA
41	PCIE_RX_DP	42	WLAN_CL_CLK
43	PCIE_RX_DN	44	NC
45	GND	46	NC
47	PCIE_CLK+	48	NC
49	PCIE_CLK-	50	NC
51	GND	52	PLT_RST
53	NC	54	BT_ON
55	PCH_WAKE_N	56	WLAN_OFF
57	GND	58	NC
59	NC	60	NC
61	NC	62	NC
63	GND	64	NC
65	NC	66	NC
67	NC	68	NC
69	GND	70	NC
71	NC	72	+3.3V
73	NC	74	+3.3V
75	GND		

Table 3-16: M.2 A-key Connector Pinouts

NANO-ADL-P

3.2.15 M.2 B-key Slot

- CN Label:** M2_B1
- CN Type:** M-key slot
- CN Location:** See Figure 3-16
- CN Pinouts:** See Table 3-17

The M.2 2242/2280 slot is keyed in the B position.




Figure 3-16: M.2 B-key Slot Location

Pin	Description	Pin	Description
1	GND	2	+V3.3
3	GND	4	+V3.3
5	GND	6	NC
7	USB2_DP	8	W_DISABLE_N
9	USB2_DN	10	NC
11	GND	12	Module Key
13	Module Key	14	Module Key
15	Module Key	16	Module Key
17	Module Key	18	Module Key
19	Module Key	20	NC
21	GND	22	NC
23	M.2_B_WAKE	24	NC

Pin	Description	Pin	Description
25	NC	26	NC
27	GND	28	NC
29	PCIE_1_RX_DN	30	SIM_RST
31	PCIE_1_RX_DP	32	SIM_CLK
33	GND	34	SIM_CIO
35	PCIE_1_TX_DN	36	SIM_VCC
37	PCIE_1_TX_DP	38	NC
39	GND	40	M.2_SMCLK
41	PCIE_0_RX_DN	42	M.2_SMDATA
43	PCIE_0_RX_DP	44	NC
45	GND	46	NC
47	PCIE_0_TX_DN	48	NC
49	PCIE_0_TX_DP	50	PLT_RST_N
51	GND	52	NC
53	PCIE_CLK_DN	54	M.2_B_WAKE
55	PCIE_CLK_DP	56	NC
57	GND	58	NC
59	NC	60	NC
61	NC	62	NC
63	NC	64	NC
65	NC	66	NC
67	NC	68	NC
69	NC	70	+V3.3
71	GND	72	+V3.3
73	GND	74	+V3.3
75	GND		

Table 3-17: M.2 B-key Connector Pinouts

NANO-ADL-P

3.2.16 PCIe x4 Slots

CN Label:	PCIEX4_1
CN Type:	PCIe x4 Slot
CN Location:	See Figure 3-17

The PCIe x4 slot enables a PCIe x4 expansion module to be connected to the board.




Figure 3-17: PCIe x4 Slot Location

3.2.17 IDPM Slot

- CN Label:** IDPM
- CN Type:** IEI iDPM slot
- CN Location:** See **Figure 3-18**

The iDPM slot is only for IEI eDP/LVDS/VGA module




Figure 3-18: IDPM Slot Location

Pin	Description	Pin	Description
1	GND	2	+3.3V
3	GND	4	+3.3V
5	GND	6	+3.3V
7	GND	8	+3.3V
9	GND	10	+3.3V
11	+5V	12	Module Key
13	Module Key	14	Module Key
15	Module Key	16	Module Key
17	Module Key	18	Module Key
19	Module Key	20	+3.3VS
21	DISPLAY_DETECT_P IN21	22	+3.3VS
23	DISPLAY_DETECT_P IN23	24	+3.3VS

NANO-ADL-P

25	GND	26	+3.3VS
27	GND	28	GND
29	EDP_TX3_DN	30	+12VS
31	EDP_TX3_DP	32	+12VS
33	GND	34	+12VS
35	EDP_TX2_DN	36	+12VS
37	EDP_TX2_DP	38	GND
39	GND	40	SMB_CLK
41	EDP_TX1_DN	42	SMB_DATA
43	EDP_TX1_DP	44	GND
45	GND	46	EC_BKLT_CTRL
47	EDP_TX0_DN	48	EDP1_BKLT_CTRL
49	EDP_TX0_DP	50	EDP1_BKLT_EN
51	GND	52	EDP1_VDD_EN #
53	EDP_AUX_DN	54	EDP_HPD_R
55	EDP_AUX_DP	56	BUF_PLT_RST#
57	GND	58	LVDS_EN
59	GND	60	+V5S
61	GND	62	+V5S
63	GND	64	+V5S
65	GND	66	+V5S
67	GND	68	+12VA
69	GND	70	+12VA
71	GND	72	+12VA
73	GND	74	+12VA
75	GND		

Table 3-18: iDPM Connector Pinouts

3.2.18 Power button connector

- CN Label:** PWR_BTN1
- CN Type:** 2-pin header
- CN Location:** See **Figure 3-19**
- CN Pinouts:** See **Table 3-19**

The power button allows users to turn the system on and off.




Figure 3-19: Power Button Connector Location

Pin	Description	Pin	Description
1	PWRBTN_SW#	2	GND

Table 3-19: Power Button Connector Pinouts

NANO-ADL-P

3.2.19 Reset button connector

- CN Label:** RST_BTN1
- CN Type:** 2-pin header
- CN Location:** See **Figure 3-20**
- CN Pinouts:** See **Table 3-20**

The reset button connector is connected to a reset switch on the system chassis to enable users to reboot the system when the system is turned on.




Figure 3-20: Reset Button Connector Location

Pin	Description	Pin	Description
1	EXTRST-	2	GND

Table 3-20: Reset Button Connector Pinouts

3.2.20 SATA 6Gb/s Connectors

- CN Label:** SATA1
- CN Type:** 7-pin SATA connector
- CN Location:** See **Figure 3-21**
- CN Pinouts:** See **Table 3-21**

The SATA drive connectors can be connected to SATA drives and support up to 6Gb/s data transfer rate.




Figure 3-21: SATA 6Gb/s Connector Location

Pin	Description
1	GND
2	SATA_TX+
3	SATA_TX-
4	GND
5	SATA_RX-
6	SATA_RX+
7	GND
8	N/C

Table 3-21: SATA 6Gb/s Connector Pinouts

NANO-ADL-P

3.2.21 SATA Power Connectors

- CN Label:** SATA_PWR1
- CN Type:** 2-pin header
- CN Location:** See **Figure 3-22**
- CN Pinouts:** See **Table 3-22**

The SATA power connector provides +5 V power output to the SATA connector.




Figure 3-22: SATA Power Connector Location

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	+5V	2	PC_BEEP_N

Table 3-22: SATA Power Connector Pinouts

3.2.22 RS-232 Serial Port Connectors

CN Label: COM1, COM2, COM3, COM4

CN Type: 10-pin wafer, p=2.54 mm

CN Location: See Figure 3-23

CN Pinouts: See Table 3-23

Each of these connectors provides RS-232 communications.




Figure 3-23: RS-232 Connector Locations

Pin	Description	Pin	Description
1	DCD	2	DSR
3	RXD	4	RTS
5	TXD	6	CTS
7	DTR	8	RI
9	GND	10	GND

Table 3-23: RS-232 Connector Pinouts

NANO-ADL-P

3.2.23 RS-232/422/485 Serial Port Connectors

- CN Label:** COM5, COM6
- CN Type:** 10-pin wafer, p=2.54 mm
- CN Location:** See Figure 3-24
- CN Pinouts:** See Table 3-24

Each of these connectors provides RS-232/422/485 communications.




Figure 3-24: RS-232/422/485 Connector Locations

Pin	Description	Pin	Description
1	DCD	2	DSR
3	RXD	4	RTS
5	TXD	6	CTS
7	DTR	8	RI
9	GND	10	GND

Table 3-24: RS-232/422/485 Connector Pinouts

3.2.24 Flash SPI ROM Connector

- CN Label:** J_SPI1
- CN Type:** 6-pin header, p=1.25 mm
- CN Location:** See Figure 3-25
- CN Pinouts:** See Table 3-25

The Flash SPI ROM connector is used to flash the SPI ROM.




Figure 3-25: Flash SPI ROM Connector Location

Pin	Description	Pin	Description
1	+3.3V	4	SPI_CLK
2	SPI_CS#	5	SPI_SI
3	SPI_SO	6	GND

Table 3-25: Flash SPI ROM Connector Pinouts

NANO-ADL-P

3.2.25 Flash EC ROM Connector

- CN Label:** EC_SPI1
- CN Type:** 8-pin header, p=1.25 mm
- CN Location:** See **Figure 3-26**
- CN Pinouts:** See **Table 3-26**

The Flash EC ROM connector is used to flash the EC ROM.




Figure 3-26: Flash EC ROM Connector Location

Pin	Description	Pin	Description
1	EC_SPI_CS#_R	2	+3.3V
3	EC_SPI_MISO_R	4	NC
5	EC_DET_FLASH	6	EC_SPI_CLK_R
7	GND	8	EC_SPI_MOSI_R

Table 3-26: Flash EC ROM Connector Pinouts

3.2.26 Internal USB 2.0 connectors

- CN Label:** USB2_1, USB2_2
- CN Type:** 8-pin header, p=1.25 mm
- CN Location:** See Figure 3-27
- CN Pinouts:** See Table 3-27

Each USB connector provides two USB 2.0 ports by dual-port USB cable.




Figure 3-27: Internal USB 2.0 Connector Location

Pin	Description	Pin	Description
1	VCC	2	GND
3	USB_DATA-	4	USB_DATA+
5	USB_DATA+	6	USB_DATA-
7	GND	8	VCC

Table 3-27: Internal USB 2.0 Connector Pinouts

NANO-ADL-P

3.3 External Peripheral Interface Connector Panel

The figure below shows the external peripheral interface connector (EPIC) panel. The EPIC panel consists of the following:




Figure 3-28: External Peripheral Interface Connector

3.3.1 External dual USB 3.2 Gen 2 connectors

- CN Label:** USB3_1, USB3_2
- CN Type:** USB 3.2
- CN Location:** See Figure 3-29
- CN Pinouts:** See Table 3-28

The external dual USB 3.2 Gen 2 connectors on the NANO-ADL-P.




Figure 3-29: External dual USB 3.2 Gen 2 connectors

Pin	Description	Pin	Description
1	VCC	10	VCC
2	USB_DATA-	11	USB_DATA-
3	USB_DATA+	12	USB_DATA+
4	GND	13	GND

Pin	Description	Pin	Description
5	USB3_RX-	14	USB3_RX-
6	USB3_RX+	15	USB3_RX+
7	GND	16	GND
8	USB3_TX-	17	USB3_TX-
9	USB3_TX+	18	USB3_TX+

Table 3-28: USB 3.2 Port Pinouts

3.3.2 External dual HDMI Connector

- CN Label:** HDMI1
- CN Type:** HDMI
- CN Location:** See Figure 3-30
- CN Pinouts:** See Table 3-29

The external dual HDMI connectors on the NANO-ADL-P.




Figure 3-30: HDMI Connectors

Pin	Description	Pin	Description
1	HDMI_DATA2P	11	GND
2	GND	12	HDMI_CLKN
3	HDMI_DATA2N	13	N/C
4	HDMI_DATA1P	14	N/C
5	GND	15	HDMI_CLK
6	HDMI_DATA1N	16	HDMI_SDA
7	HDMI_DATA0P	17	GND
8	GND	18	+5V
9	HDMI_DATA0N	19	HDMI_HPD

NANO-ADL-P

Pin	Description	Pin	Description
10	HDMI_CLKP		

Table 3-29: HDMI Connector Pinouts

3.3.3 External 2.5GbE RJ-45 connectors

- CN Label:** LAN1, LAN2
- CN Type:** RJ45
- CN Location:** See **Figure 3-31**
- CN Pinouts:** See **Table 3-30**

The LAN connector connects to a local network.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	LAN1_MD0+	5	LAN1_MD2+
2	LAN1_MD0-	6	LAN1_MD2-
3	LAN1_MD1+	7	LAN1_MD3+
4	LAN1_MD1-	8	LAN1_MD3-

Table 3-30: 2.5GbE RJ45 Pinouts




Figure 3-31: LAN LED Location

LED	Description	LED	Description
Off	No link	Off	10 Mbps connection
Yellow	Linked	orange	1000 Mbps connection
Blinking	TX/RX activity	Green	2.5 Gbps connection

Table 3-31: LAN LED Pinouts

3.3.4 External DP connector

- CN Label:** DP1
- CN Type:** DP
- CN Location:** See **Figure 3-32**
- CN Pinouts:** See **Table 3-32**

The external DP connectors on the NANO-ADL-P.




Figure 3-32: DP Connector

The external DP connectors.

Pin	Description	Pin	Description
1	LANE0P	11	GND
2	GND	12	LANE3N
3	LANE0N	13	CONFIG_A_1
4	LANE1P	14	CONFIG_A_2
5	GND	15	AUXP
6	LANE1N	16	GND
7	LANE2P	17	AUXN
8	GND	18	HPD
9	LANE2N	19	GND
10	LANE3P	20	+5V

Table 3-32: DP Connector Pinouts

Chapter

4

Installation

4.1 Anti-static Precautions



WARNING:

Failure to take ESD precautions during the installation of the NANO-ADL-P may result in permanent damage to the NANO-ADL-P and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the NANO-ADL-P. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the NANO-ADL-P or any other electrical component is handled, the following anti-static precautions are strictly adhered to.

- **Wear an anti-static wristband:** Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- **Self-grounding:** Before handling the board touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- **Use an anti-static pad:** When configuring the NANO-ADL-P, place it on an anti-static pad. This reduces the possibility of ESD damaging the NANO-ADL-P.
- **Only handle the edges of the PCB:** When handling the PCB, hold the PCB by the edges.

4.2 Installation Considerations



NOTE:

The following installation notices and installation considerations should be read and understood before installation. All installation notices must be strictly adhered to. Failing to adhere to these precautions may lead to severe damage and injury to the person performing the installation.

NANO-ADL-P



WARNING:

The installation instructions described in this manual should be carefully followed in order to prevent damage to the components and injury to the user.

Before and during the installation please **DO** the following:

- Read the user manual:
 - The user manual provides a complete description of the NANO-ADL-P installation instructions and configuration options.
- Wear an electrostatic discharge cuff (ESD):
 - Electronic components are easily damaged by ESD. Wearing an ESD cuff removes ESD from the body and helps prevent ESD damage.
- Place the NANO-ADL-P on an anti-static pad:
 - When installing or configuring the motherboard, place it on an anti-static pad. This helps to prevent potential ESD damage.
- Turn all power to the NANO-ADL-P off:
 - When working with the NANO-ADL-P, make sure that it is disconnected from all power supplies and that no electricity is being fed into the system.

Before and during the installation of the NANO-ADL-P, **DO NOT**:

- Remove any of the stickers on the PCB board. These stickers are required for warranty validation.
- Use the product before verifying all the cables and power connectors are properly connected.
- Allow screws to come in contact with the PCB circuit, connector pins, or its components.

4.3 M.2 Module Installation

The NANO-ADL-P provide two ways to install the M.2 expansion card. One is using screw, and the other is using the retainer. Please follow the steps below.

Mode One: Using screw

- Step 1:** Locate the M.2 module slot. See **Chapter 3**.
- Step 2:** Remove the retention screw secured on the motherboard.
- Step 3:** Line up the notch on the module with the notch on the slot. Slide the M.2 module into the socket at an angle of about 20° (**Figure 4-1**).




Figure 4-1: Inserting the M.2 Module into the Slot at an Angle

- Step 4:** Secure the M.2 module with the previously removed retention screw (**Figure 4-2**).




Figure 4-2: Securing the M.2 Module

NANO-ADL-P

Mode Two: Using the Retainer

Step 1: Press the retainer down as shown below. (See **Figure 4-3**)




Figure 4-3: Press the Retainer

Step 2: Line up the notch on the M.2 module with the notch on the slot. Slide the M.2 module into the socket at an angle of about 20°. (See **Figure 4-1**)

Step 3: Align the notch on the end of the M.2 module with the clip of the retainer. (See

Step 4: **Figure 4-4**)




Figure 4-4: Aligning the M.2 Module with the Retainer

Step 5: Press the M.2 module down until it is secured into place by the retainer. (See **Figure 4-5**)




Figure 4-5: Securing the M.2 Module

Step 6: If you want to remove the M.2 module, you should press the retainer down as described in Step 1 to release the M.2 module. (See **Figure 4-3**)

NANO-ADL-P

4.4 Heat Spreader

**WARNING:**

The heat spreader installed on the NANO-ADL-P can only serve as a heat conductor, which needs additional heat dissipation mechanism to achieve suitable thermal condition. DO NOT put the NANO-ADL-P with the heat spreader directly on a surface that cannot dissipate system heat, and never run the NANO-ADL-P without the heat spreader secured to the board.

When the NANO-ADL-P is shipped, it is secured to a heat spreader with six retention screws. The heat spreader must have a direct contact with a heat dissipation surface to ensure stable operation. In addition, a thin layer of thermal paste has to be applied onto the heat dissipation surface where it contacts the heat spreader.




Figure 4-6: Heat Sink Retention Screws

4.5 Riser Card Installation

The NANO-EHL features a PCIe x4 (x2 signal) slot, which is a new design of the motherboard to expand functionality. By installing an IEI-developed riser card into the PCIe slot, the x4 signal is divided into x2+x2 slots and x2+x1+x1 slots, offering great configuration flexibility and expandability.

Two types of riser cards with different orientation are available, one with slots facing outwards and the other with slots facing inwards.

The outwards-facing riser card (P/N: NWR-R2S-R10), although lower in height, is able to provide better spacing to ensure expansion cards to run at a low temperature. It is ideal for the chassis that is wide enough for the expansion card to be placed.




Figure 4-7: Outwards Riser Card Installation Example



Figure 4-8: NWR-L2S-R10

NANO-ADL-P

The inwards-facing riser card (P/N: NWR-R2S- R10) is designed with higher height to keep a decent space between the expansion cards and the motherboard. This can help improve the airflow and heat transfer within the system. It is suitable for installation where space is limited.




Figure 4-9: Inwards Riser Card Installation Example



Figure 4-10: NWR-R2S-R10

Both of the riser cards can be firmly secured to enhance stability by using the L-shaped bracket, in which screw holes are perfectly matched with those on the side of the heatsink and on the riser card, making it easy and convenient to install. See **Figure 4-11**.




Figure 4-11:L-shaped Bracket Installation Example

NANO-ADL-P

4.6 Internal Peripheral Device Connections

This section outlines the installation of peripheral devices to the onboard connectors.

4.6.1 SATA Drive Connection

The NANO-ADL-P is shipped with two SATA drive cables. To connect the SATA drives to the connectors, please follow the steps below.

Step 1: Locate the connectors. The locations of the SATA drive connectors are shown in **Chapter 3**.

Step 2: Insert the cable connector. Insert the cable connector into the on-board SATA drive connector until it clips into place. See **Figure 4-12**.




Figure 4-12: SATA Drive Cable Connection

Step 3: Connect the cable to the SATA disk. Connect the connector on the other end of the cable to the connector at the back of the SATA drive. See **Figure 4-13**.

Step 4: Connect the SATA power cable. Connect the SATA power connector to the back of the SATA drive. See **Figure 4-13**.




Figure 4-13: SATA Power Drive Connection

The SATA power cable can be bought from IEI. See Optional Items in Section 2.4.

4.6.2 AT Power Connection

Follow the instructions below to connect the NANO-ADL-P to an AT power supply.



WARNING:

Disconnect the power supply power cord from its AC power source to prevent a sudden power surge to the NANO-ADL-P.

Step 1: **Locate the power cable.** The power cable is shown in the packing list in Chapter 2.

NANO-ADL-P

Step 2: Connect the power cable to the motherboard. Connect the 4-pin (2x2) Molex type power cable connector to the power connector on the motherboard. See

Figure 4-14




Figure 4-14: Power Cable to Motherboard Connection

Step 3: Connect power cable to power supply. Connect one of the 4-pin (1x4) Molex type power cable connectors to an AT power supply. See **Figure 4-15**




Figure 4-15: Connect Power Cable to Power Supply

4.6.3 7.1 Channel Audio Kit Installation

**NOTE:**

This item must be ordered separately, and connects to the audio connector. For further information please contact the nearest distributor, reseller or vendor or contact an IEI sales representative directly.

The audio kit attaches to the audio connector. The audio kit provides 7.1 channel audio. To install the audio kit, please refer to the steps below:

Step 1: **Connect the cable to the audio kit.** Connect the included cable to the audio kit. Make sure pin 1 aligns with the marked pin.

Step 2: **Connect the cable to the board.** Connect the other end of the cable to the board. Make sure to line up the marked pin 1.




Figure 4-16: 7.1 Channel Audio Kit

Step 3: **Mount the audio kit onto the chassis.** Once the audio kit is connected to the board, secure the audio kit bracket to the system chassis.

NANO-ADL-P

Step 4: Connect the audio devices. Connect speakers and external audio sources to the audio jacks on the audio kit.

Step 5: Install the driver. Install the 7.1 channel audio driver included with the board.

4.7 Software Drivers

4.7.1 Software Installation

All the drivers for the NANO-ADL-P are available on IEI Resource Download Center (<https://download.ieiworld.com>). Type NANO-ADL-P and press Enter to find all the relevant software, utilities, and documentation.





Figure 4-17: IEI Resource Download Center


4.7.2 Driver Download

To download drivers from IEI Resource Download Center, follow the steps below.

Step 1: Go to <https://download.ieiworld.com>. Type NANO-ADL-P and press Enter.




Step 2: All product-related software, utilities, and documentation will be listed. You can choose **Driver** to filter the result.



Step 3: Click the driver file name on the page and you will be prompted with the following window. You can download the entire ISO file (❶), or click the small arrow to find an individual driver and click the file name to download (❷).

NANO-ADL-P

**NOTE:**

To install software from the downloaded ISO image file in Windows 8, 8.1 or 10, double-click the ISO file to mount it as a virtual drive to view its content. On Windows 7 system, an additional tool (such as Virtual CD-ROM Control Panel from Microsoft) is needed to mount the file.

Chapter

5

BIOS

NANO-ADL-P

5.1 Introduction

The BIOS is programmed onto the BIOS chip. The BIOS setup program allows changes to certain system settings. This chapter outlines the options that can be changed.

**NOTE:**

Some of the BIOS options may vary throughout the life cycle of the product and are subject to change without prior notice.

5.1.1 Starting Setup

The UEFI BIOS is activated when the computer is turned on. The setup program can be activated in one of two ways.

1. **Using keyboard:** Press the **DEL** or **F2** as soon as the system is turned on.
2. **Using touchscreen:** Press the **Setup** button on the upper right corner of the BIOS Starting Menu.

If the message disappears before the **DEL** or **F2** key is pressed, restart the computer and try again, then the BIOS Starting Menu will appear. Select "Setup" and press Enter to get into the BIOS Setup.




Figure 5-1: BIOS Starting Menu

5.1.2 Using Setup

The BIOS Setup menu can be navigated by using a keyboard or a touchscreen.

5.1.2.1 Keyboard Navigation

For keyboard navigation, use the navigation keys shown in **Table 5-1**.


Key	Function
Up arrow	Move to previous item
Down arrow	Move to next item
Left arrow	Move to the item on the left hand side
Right arrow	Move to the item on the right hand side
+	Increase the numeric value or make changes
-	Decrease the numeric value or make changes
Page Up	Move to the previous page
Page Dn	Move to the next page
Esc	Main Menu – Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
F1	General help, only for Status Page Setup Menu and Option Page Setup Menu
F2	Load previous values
F3	Load optimized defaults
F4	Save changes and Exit BIOS
<K>	Scroll help area upwards
<M>	Scroll help area downwards

Table 5-1: BIOS Navigation Keys

NANO-ADL-P

5.1.2.2 Touch Navigation

For touchscreen navigation, use the on-screen navigation keys shown below.



On-screen Button	Function
Previous Values	Load the last value you set.
Optimized Defaults	Load the factory default values in order to achieve the best performance.
Back	Return to the previous menu.
Soft kbd	Display the on-screen keyboard.
Save & Exit	Save the changes made to the BIOS options and reset the system.

Table 5-2: BIOS On-screen Navigation Keys

5.1.3 Getting Help

When **F1** is pressed a small help window describing the appropriate keys to use and the possible selections for the highlighted item appears. To exit the Help Window, press the **Esc** key.

5.1.4 Unable to Reboot after Configuration Changes

If the computer cannot boot after changes to the system configuration is made, CMOS defaults. Use the clear CMOS button described in **Chapter 4**.

5.1.5 BIOS Menu Bar

The **menu bar** on top of the BIOS screen has the following main items:

- Main – Changes the basic system configuration.
- Advanced – Changes the advanced system settings.
- Chipset – Changes the chipset settings.
- Security – Sets User and Supervisor Passwords.
- Boot – Changes the system boot configuration.
- Save & Exit – Selects exit options and loads default settings


The following sections completely describe the configuration options found in the menu items at the top of the BIOS screen and listed above.

NANO-ADL-P


5.2 Main

The **Main** BIOS menu (**BIOS Menu 2**) appears when the **BIOS Setup** program is entered.

The **Main** menu gives an overview of the basic system information.



BIOS Menu 1: Main (1/3)



BIOS Menu 2: Main (2/3)



BIOS Menu 3: Main (3/3)

➔ **BIOS Information**

The **BIOS Information** lists a brief summary of the BIOS. The fields in **BIOS Information** cannot be changed. The items shown in the system overview include:

- **BIOS Vendor:** Installed BIOS vendor
- **Core Version:** Current BIOS version
- **Compliance:** Current UEFI & PI version
- **Project Version:** the board version
- **Build Date and Time:** Date the current BIOS version was made
- **EC Version:** Current EC version

➔ **Processor Information**

The **Processor Information** lists a brief summary of the Processor. The fields in **Processor Information** cannot be changed. The items shown in the system overview include:

- **Name:** Displays the Processor Details
- **Type:** Displays the Processor Type
- **Speed:** Displays the Processor Speed

NANO-ADL-P

- **ID:** Displays the Processor ID

→ PCH Information

The **PCH Information** lists a brief summary of the PCH. The fields in **PCH Information** cannot be changed. The items shown in the system overview include:

- **Name:** Displays the PCH Name
- **PCH SKU:** Displays the PCH SKU
- **Stepping:** Displays the PCH Stepping
- **TXT Capability of Platform/PCH:** Displays the TXT Capability
- **Production Type:** Displays the Production Type
- **ME FW Version:** Displays the ME Firmware Version
- **ME Firmware SKU:** Displays the ME Firmware SKU
- **PMC FW Version:** Displays the PMC Firmware Version

→ System Date [xx/xx/xx]

Use the **System Date** option to set the system date. Manually enter the day, month and year.

→ System Time [xx:xx:xx]

Use the **System Time** option to set the system time. Manually enter the hours, minutes and seconds.


5.3 Advanced

Use the **Advanced** menu (**BIOS Menu 4**) to configure the CPU and peripheral devices through the following sub-menus:



WARNING!

Setting the wrong values in the sections below may cause the system to malfunction. Make sure that the settings made are compatible with the hardware.




BIOS Menu 4: Advanced

NANO-ADL-P

5.3.1 CPU Configuration


Use the **CPU Configuration** menu (**BIOS Menu 5**) to view detailed CPU specifications or enable the Intel Virtualization Technology.



BIOS Menu 5: CPU Configuration (1/3)



BIOS Menu 6: CPU Configuration (2/3)



BIOS Menu 7: CPU Configuration (3/3)

NANO-ADL-P

→ Intel (VMX) Virtualization Technology [Enabled]

Use the **Intel (VMX) Virtualization Technology** option to enable or disable virtualization on the system. When combined with third party software, Intel® Virtualization technology allows several OSs to run on the same system at the same time.

- **Disabled** Disables Intel Virtualization Technology.
- **Enabled** **DEFAULT** Enables Intel Virtualization Technology.

→ Power Limit 1 [0]

Use the + or – key to change the **Power Limit 1** value. BIOS will program the default values for Limit 1 and Power Limit 1 Time Window. For 12.50W, enter 12500.

→ Power Limit 2 [0]

Use the + or – key to change the **Power Limit 2** value. BIOS will round to the nearest 1/8W when programming. 0 = no custom override. For 12.50W, enter 12500.

→ Power Limit 1 Time Window [0]

Use the **Power Limit 1 Time Window** option to select the PL1 time duration. The value may vary from 0 to 128. For 0 is the default value

→ EIST [Enabled]

Use the **EIST** option to enable or disable the capability that allows more than two frequency ranges to be supported.

- **Disabled** Disables the EIST Technology
- **Enabled** **DEFAULT** Enables the EIST Technology

→ C states [Disabled]

Use the **C states** option to enable or disable CPU power management which allows CPU to go to C states when it is not 100% utilized.

- **Disabled** **DEFAULT** Disables CPU power management

➔ **Enabled** Enables CPU power management

➔ **Turbo Mode [Enabled]**

Use the **Turbo Mode** option to enable or disable Turbo Mode which requires Intel Speed Step or Intel Speed Shift to be available and enabled.

➔ **Disabled** Disables Turbo Mode Technology

➔ **Enabled** **DEFAULT** Enables Turbo Mode Technology

➔ **Active Performance Cores [All]**

Use the **Active Performance Cores** BIOS option to enable numbers of P-cores in the processor package.

➔ **All** **DEFAULT** Enable all P-cores in the processor package.

➔ **1** Enable one P-core in the processor package.

➔ **Active Efficient Cores [All]**

Use the **Active Efficient Cores** BIOS option to enable numbers of E-cores in the processor package.

➔ **All** **DEFAULT** Enable all E-cores in the processor package.

➔ **0** Enable zero E-core in the processor package.

➔ **1** Enable one E-cores in the processor package.

➔ **2** Enable two E-cores in the processor package.

➔ **3** Enable three E-cores in the processor package.

➔ **4** Enable four E-cores in the processor package.

➔ **5** Enable five E-cores in the processor package.

➔ **6** Enable six E-cores in the processor package.

➔ **7** Enable seven E-cores in the processor package.

NANO-ADL-P


→ Hyper-Threading [Enabled]

Use the **Hyper-Threading** option to enable or disable the **Hyper-Threading** Technology.

- **Disabled** Disables Hyper-Threading Technology
- **Enabled** **DEFAULT** Enables Hyper-Threading Technology

5.3.2 Trusted Computing

Use the **Trusted Computing** menu (**BIOS Menu 8**) to configure settings related to the Trusted Computing Group (TCG) Trusted Platform Module (TPM).



BIOS Menu 8: Trusted Computing Configuration

→ Security Device Support [Enable]

Use the **Security Device Support** option to enable or disable BIOS support for security device.

- **Disable** TPM support is disabled.

→ **Enable** **DEFAULT** TPM support is enabled.

→ **Pending Operation [None]**

Use the **Pending Operation** option to schedule an operation for the security device.

→ **None** **DEFAULT** TPM information is previous.S

→ **TPM Clear** TPM information is cleared


5.3.3 RTC Wake Settings

The **RTC Wake Settings** menu (**BIOS Menu 9**) configures RTC wake event.



BIOS Menu 9: RTC Wake Settings (1/2)

NANO-ADL-P



BIOS Menu 10: RTC Wake Settings (2/2)

→ Wake system with Fixed Time [Enabled]


Use the **Wake system with Fixed Time** option to enable or disable the system wake on alarm event.

- **Disabled** The real time clock (RTC) cannot generate a wake event
- **Enabled** **DEFAULT** If selected, the **Wake up every day** option appears allowing you to enable to disable the system to wake every day at the specified time. Besides, the following options appear with values that can be selected:
 - Wake up date
 - Wake up hour
 - Wake up minute
 - Wake up second

After setting the alarm, the computer turns itself on from a suspend state when the alarm goes off.

5.3.4 F81966 Super IO Configuration

Use the **F81966 Super IO Configuration** menu (**BIOS Menu 11**) to set or change the configurations for serial ports.




BIOS Menu 11: F81966 Super IO Configuration

NANO-ADL-P

5.3.4.1 Serial Port 1 Configuration

Use the **Serial Port 1 Configuration** menu (**BIOS Menu 12**) to configure the serial port.



BIOS Menu 12: Serial Port 1 Configuration Menu

→ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

→ **Disabled** Disable the serial port

→ **Enabled** **DEFAULT** Enable the serial port


→ Device Settings

The **Device Settings** option shows the serial port IO port address and interrupt address.

→ **IO=3F8h;** Serial Port I/O port address is 3F8h and the interrupt
IRQ=4 address is IRQ4

5.3.4.2 Serial Port 2 Configuration

Use the **Serial Port 2 Configuration** menu (**BIOS Menu 13**) to configure the serial port.



BIOS Menu 13: Serial Port 2 Configuration Menu

➔ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled** Disable the serial port
- ➔ **Enabled** **DEFAULT** Enable the serial port

➔ Device Settings


The **Device Settings** option shows the serial port IO port address and interrupt address.

- ➔ **IO=2F8h;** Serial Port I/O port address is 2F8h and the interrupt
IRQ=3 address is IRQ3

NANO-ADL-P

5.3.4.3 Serial Port 3 Configuration

Use the **Serial Port 3 Configuration** menu (**BIOS Menu 14**) to configure the serial port.



BIOS Menu 14: Serial Port 3 Configuration Menu

→ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

→ **Disabled** Disable the serial port

→ **Enabled** **DEFAULT** Enable the serial port


→ Device Settings

The **Device Settings** option shows the serial port IO port address and interrupt address.

→ **IO=2E0h;** Serial Port I/O port address is 2E0h and the interrupt
IRQ=10 address is IRQ10

5.3.4.4 Serial Port 4 Configuration

Use the **Serial Port 4 Configuration** menu (**BIOS Menu 15**) to configure the serial port.



BIOS Menu 15: Serial Port 4 Configuration Menu

→ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled** Disable the serial port
- **Enabled** **DEFAULT** Enable the serial port

→ Device Settings


The **Device Settings** option shows the serial port IO port address and interrupt address.

- **IO=2E8h;** Serial Port I/O port address is 2E8h and the interrupt
IRQ=10 address is IRQ10

NANO-ADL-P

5.3.4.5 Serial Port 5 Configuration

Use the **Serial Port 5 Configuration** menu (**BIOS Menu 16**) to configure the serial port.



BIOS Menu 16: Serial Port 5 Configuration Menu

→ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled** Disable the serial port
- **Enabled** **DEFAULT** Enable the serial port

→ Device Settings

The **Device Settings** option shows the serial port IO port address and interrupt address.

- **IO=2C0h;** Serial Port I/O port address is 2C0h and the interrupt
IRQ=10 address is IRQ10

→ Device Mode [RS232]

Use the **Device Mode** option to change the serial port mode.

→ PC Health Status


The following system parameters and values are shown. The system parameters that are monitored are:

- System Temperatures:
 - CPU Temperature
 - System Temperature1
 - System Temperature2
- Fan Speeds:
 - CPU_Fan1 Speed
- Voltages:
 - +VCCCORE
 - +5VS
 - +12S
 - +V3.3S
 - +VDDQ

NANO-ADL-P

5.3.5.1 Smart Fan Mode Configuration

Use the **Smart Fan Mode Configuration** submenu (**BIOS Menu 19**) to configure the CPU/system fan start/off temperature and control mode.



BIOS Menu 19: Smart Fan Mode Configuration

→ CPU_FAN1 Smart Fan Control [Auto Mode]

Use the **CPU_FAN1 Smart Fan Control** option to configure the CPU Smart Fan.

- **Manual Mode** The fan spins at the speed set in Manual Mode settings.
- **Auto Mode** **DEFAULT** The fan adjusts its speed using Auto Mode settings.

→ CPU_FAN1 Start Temperature

If the CPU temperature is between **fan off** and **fan start**, the fan speed change to **fan start PWM**. To set a value, Use the + or – key to change the value or enter a decimal number between 1 and 100.

→ CPU_FAN1 Off Temperature


If the CPU temperature is lower than the value set this option, the fan speed change to be lowest. To set a value, Use the + or – key to change the value or enter a decimal number between 1 and 100.

→ CPU_FAN1 Start PWM

Use the **CPU_FAN1 Start PWM** option to set the PWM start value. Use the + or – key to change the value or enter a decimal number between 1 and 100.


5.3.6 Serial Port Console Redirection

The **Serial Port Console Redirection** menu (**BIOS Menu 20**) allows the console redirection options to be configured. Console Redirection allows users to maintain a system remotely by re-directing keyboard input and text output through the serial port.



BIOS Menu 20: Serial Port Console Redirection (1/2)

NANO-ADL-P



BIOS Menu 21: Serial Port Console Redirection (2/2)

→ Console Redirection [Disabled]


Use **Console Redirection** option to enable or disable the console redirection function.

- **Disabled** **DEFAULT** Disabled the console redirection function
- **Enabled** Enabled the console redirection function

The **Console Redirection Settings** submenu will be available when the **Console Redirection** option is enabled.

5.3.6.1 Console Redirection Settings

The following options are available in the **Console Redirection Settings** submenu (**BIOS Menu 22**) when the **COM Console Redirection** (for COM1 to COM6) option is enabled.



BIOS Menu 22: COM Console Redirection Settings

➔ **Terminal Type [ANSI]**

Use the **Terminal Type** option to specify the remote terminal type.

- ➔ **VT100** The target terminal type is VT100
- ➔ **VT100+** The target terminal type is VT100+
- ➔ **VT-UTF8** The target terminal type is VT-UTF8
- ➔ **ANSI** **DEFAULT** The target terminal type is ANSI

➔ **Bits per second [115200]**

Use the **Bits per second** option to specify the serial port transmission speed. The speed must match on the other side. Long or noisy lines may require lower speeds.

- ➔ **9600** Sets the serial port transmission speed at 9600.
- ➔ **19200** Sets the serial port transmission speed at 19200.
- ➔ **38400** Sets the serial port transmission speed at 38400.

NANO-ADL-P

- **57600** Sets the serial port transmission speed at 57600.
- **115200** **DEFAULT** Sets the serial port transmission speed at 115200.

→ Data Bits [8]

Use the **Data Bits** option to specify the number of data bits.

- **7** Sets the data bits at 7.
- **8** **DEFAULT** Sets the data bits at 8.

→ Parity [None]

Use the **Parity** option to specify the parity bit that can be sent with the data bits for detecting the transmission errors.

- **None** **DEFAULT** No parity bit is sent with the data bits.
- **Even** The parity bit is 0 if the number of ones in the data bits is even.
- **Odd** The parity bit is 0 if the number of ones in the data bits is odd.
- **Mark** The parity bit is always 1. This option does not allow for error detection.
- **Space** The parity bit is always 0. This option does not allow for error detection.


→ Stop Bits [1]

Use the **Stop Bits** option to specify the number of stop bits used to indicate the end of a serial data packet. Communication with slow devices may require more than 1 stop bit.

- **1** **DEFAULT** Sets the number of stop bits at 1.
- **2** Sets the number of stop bits at 2.

5.3.7 NVMe Configuration

Use the **NVMe Configuration (BIOS Menu 23)** menu to display the NVMe controller and device information.



BIOS Menu 23: NVMe Configuration

NANO-ADL-P


5.4 Chipset

Use the **Chipset** menu (**BIOS Menu 24**) to access the PCH IO and System Agent (SA) configuration menus.



WARNING!


Setting the wrong values for the Chipset BIOS selections in the Chipset BIOS menu may cause the system to malfunction.



BIOS Menu 24: Chipset

5.4.1 System Agent (SA) Configuration

Use the **System Agent (SA) Configuration** menu (**BIOS Menu 25**) to configure the System Agent (SA) parameters.



BIOS Menu 25: System Agent (SA) Configuration

➔ **VT-d [Enabled]**

Use the **VT-d** option to enable or disable the VT-d capability.

- ➔ **Disabled** Disable the VT-d capability
- ➔ **Enabled** **DEFAULT** Enable the VT-d capability

NANO-ADL-P

5.4.1.1 Memory Configuration

Use the **Memory Configuration** submenu (**BIOS Menu 27**) to view memory information.



BIOS Menu 26: Memory Configuration (1/2)



BIOS Menu 27: Memory Configuration (2/2)

NANO-ADL-P

5.4.1.2 Graphics Configuration

Use the **Graphics Configuration (BIOS Menu 28)** menu to configure the video device connected to the system.



BIOS Menu 28: Graphics Configuration

→ Primary Display [Auto]

Use the **Primary Display** option to select the primary graphics controller the system uses.

The following options are available:

- Auto **Default**
- IGFX
- PEG
- PCI
- SG

→ Internal Graphics [Enabled]

Use the **Internal Graphics** option to configure whether to keep IGFX enabled. If user wants to support dual display by internal graphics and external graphics, this Internal Graphics

option should be set to Enabled and the above Primary Display option should be set to IGFX.

- **Auto** Auto mode
- **Disabled** Disables IGFX.
- **Enabled** **Default** Enables IGFX.


→ **DVMT Pre-Allocated [160M]**

Use the **DVMT Pre-Allocated** option to set the amount of system memory allocated to the integrated graphics processor when the system boots. The system memory allocated can then only be used as graphics memory, and is no longer available to applications or the operating system. Configuration options are listed below:

- 80M
- 160M **Default**

NANO-ADL-P

5.4.1.3 PEG Port Configuration



BIOS Menu 29: PEG Port Configuration

5.4.2 PCH-IO Configuration

Use the **PCH-IO Configuration** menu (**BIOS Menu 30**) to configure the PCH parameters.



BIOS Menu 30: PCH-IO Configuration (1/2)

NANO-ADL-P



BIOS Menu 31: PCH-IO Configuration (2/2)

→ Auto Power Button Function [Disabled (AT)]

Use the **Auto Power Button Function** BIOS option to show the power mode state. Use the J_ATX_AT1 to switch the AT/ATX power mode.

- **Enabled (AT)** **DEFAULT** The system power mode is AT.
- **Disabled (ATX)** The system power mode is ATX.

→ Restore AC Power Loss [Last State]

Use the **Auto Power Button Status** option to show the power mode state. Use the J_ATX_AT1 to switch the AT/ATX power mode.

- **Enabled (AT)** **DEFAULT** The system power mode is AT.
- **Disabled (ATX)** The system power mode is ATX.

→ **Power Saving Function (EUP) [Disabled]**

Use the **Power Saving Function (EUP)** BIOS option to enable or disable the power saving function.

- **Disabled** **DEFAULT** Power saving function is disabled.
- **Enabled** Power saving function is enabled. It will reduce power consumption when the system is off.

→ **USB Power state [+5VDUAL]**

Use the **USB Power state** option to enable or disable the USB Power.

- **+5VDUAL** **DEFAULT** USB Power is on.
- **+5V** USB Power is off.

NANO-ADL-P

5.4.2.1 PCI Express Configuration

Use the **PCI Express Configuration** submenu (**BIOS Menu 32**) to configure the PCI Express slots.



BIOS Menu 32: PCI Express Configuration

5.4.2.1.1 PCIe Root Port Setting

Use the **M.2 Slot(M2_M1)**, **PCIE7 Slot(x1)**, **PCIE6 Slot(x4)**, **PCIE1 Slot(x4)** submenu (**BIOS Menu 33**) to configure the PCIe Root Port Setting.



BIOS Menu 33: PCIe Slot Configuration Submenu

→ PCIe Speed [Auto]

Use the **PCIe Speed** option to specify the PCI Express port speed. Configuration options are listed below.

- **Auto** **DEFAULT** Auto mode.
- **Gen1** Configure PCIe Speed to Gen1.
- **Gen2** Configure PCIe Speed to Gen2.
- **Gen3** Configure PCIe Speed to Gen3.

→ Detect Non-Compliance Device [Disabled]


Use the **Detect Non-Compliance Device** option to configure whether to detect if a non-compliance PCI Express device is connected to the PCI Express port.

NANO-ADL-P

- ➔ **Disabled** **DEFAULT** Do not detect if a non-compliance PCI Express device is connected to the PCI Express port.
- ➔ **Enabled** Detect if a non-compliance PCI Express device is connected to the PCI Express port.

5.4.2.2 SATA Configuration

Use the **SATA Configuration** menu (**BIOS Menu 34**) to change and/or set the configuration of the SATA devices installed in the system.



BIOS Menu 34: SATA Configuration

➔ **SATA Controller(s) [Enabled]**

Use the **SATA Controller(s)** option to designate the correspondent port as hot-pluggable.

- ➔ **Disabled** Disable the SATA device.
- ➔ **Enabled** **DEFAULT** Enable the SATA device.

→ **SATA Mode Selection [AHCI]**

Use the **SATA Mode Selection** option to determine how the SATA devices operate.

- **AHCI** **DEFAULT** Configures SATA devices as AHCI device.
- **Intel RST Premium
With Intel Optane
System Acceleration** Configures SATA devices to the Intel RST
Premium With Intel Optane System Acceleration
mode.

→ **Hot Plug [Disabled]**


Use the **Hot Plug** option to designate the correspondent port as hot-pluggable.

- **Disabled** **DEFAULT** Disables the hot-pluggable function of the SATA port.
- **Enabled** Designates the SATA port as hot-pluggable.

NANO-ADL-P

5.4.2.3 HD Audio Configuration

Use the **HD Audio Configuration** menu (**BIOS Menu 35**) to configure the PCH Azalia settings.



BIOS Menu 35: HD Audio Configuration

→ HD Audio [Enabled]

Use the **HD Audio** option to enable or disable the High Definition Audio controller.

- **Disabled** The onboard High Definition Audio controller is disabled.
- **Enabled** **DEFAULT** The onboard High Definition Audio controller is enabled.


5.5 Security

Use the **Security** menu (**BIOS Menu 37**) to set system and user passwords.



BIOS Menu 36: Security (1/2)

NANO-ADL-P

**BIOS Menu 37: Security (2/2)****→ Administrator Password**


Use the **Administrator Password** to set or change an administrator password.

→ User Password

Use the **User Password** to set or change a user password.

5.6 Boot

Use the **Boot** menu (**BIOS Menu 38**) to configure system boot options.



BIOS Menu 38: Boot

5.6.1 Boot Configuration

→ Quiet Boot [Enabled]

Use the **Quiet Boot** BIOS option to select the screen display when the system boots.

- **Disabled** Normal POST messages displayed
- **Enabled** **DEFAULT** OEM Logo displayed instead of POST messages

→ Launch PXE OpROM [Disabled]

Use the **Launch PXE OpROM** option to enable or disable boot option for legacy network devices.

NANO-ADL-P

- ➔ **Disabled** **DEFAULT** Ignore all PXE Option ROMs
- ➔ **Enabled** Load PXE Option ROMs.

➔ **Option ROM Messages [Force BIOS]**

Use the **Option ROM Messages** option to set the Option ROM display mode.

- ➔ **Force BIOS** **DEFAULT** Sets display mode to force BIOS.
- ➔ **Keep Current** Sets display mode to current.

5.6.2 Boot Option Priorities

Use the Boot Option # N to choose the system boots from the peripherals you selected. The following Boot Options are listed as an example.

➔ **Boot Option #1**

Sets the system boot order **ADATA SP580** as the first priority.

- ➔ **Windows Boot Manager (P1: ADATA SSD SP580 240GB)**
- ➔ **Disabled**


➔ **Boot Option #2**

Sets the system boot order **USB Partition 1** as the second priority.

- ➔ **UEFI: USB, Partition 1**
- ➔ **Disabled**

5.7 Save & Exit

Use the **Save & Exit** menu (**BIOS Menu 39**) to load default BIOS values, optimal failsafe values and to save configuration changes.



BIOS Menu 39: Save & Exit

→ Save Changes and Reset

Use the **Save Changes and Reset** option to save the changes made to the BIOS options and reset the system.

→ Discard Changes and Reset

Use the **Discard Changes and Reset** option to exit the system without saving the changes made to the BIOS configuration setup program.

→ Restore Defaults

Use the **Restore Defaults** option to load the optimal default values for each of the parameters on the Setup menus. **F3 key can be used for this operation.**

NANO-ADL-P

→ **Save as User Defaults**

Use the **Save as User Defaults** option to save the changes done so far as user defaults.

→ **Restore User Defaults**

Use the **Restore User Defaults** option to restore the user defaults to all the setup options.

Appendix

A

Regulatory Compliance

DECLARATION OF CONFORMITY



This equipment has been tested and found to comply with specifications for CE marking. If the user modifies and/or installs other devices in the equipment, the CE conformity declaration may no longer apply.

FCC WARNING



This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Appendix

B

Product Disposal


NANO-ADL-P

**CAUTION:**

Risk of explosion if battery is replaced by an incorrect type. Only certified engineers should replace the on-board battery.

Dispose of used batteries according to instructions and local regulations.

- Outside the European Union–If you wish to dispose of used electrical and electronic products outside the European Union, please contact your local authority so as to comply with the correct disposal method.
- Within the European Union–The device that produces less waste and is easier to recycle is classified as electronic device in terms of the European Directive 2012/19/EU (WEEE), and must not be disposed of as domestic garbage.



EU-wide legislation, as implemented in each Member State, requires that waste electrical and electronic products carrying the mark (left) must be disposed of separately from normal household waste. This includes monitors and electrical accessories, such as signal cables or power cords. When you need to dispose of your device, please follow the guidance of your local authority, or ask the shop where you purchased the product. The mark on electrical and electronic products only applies to the current European Union Member States.

Please follow the national guidelines for electrical and electronic product disposal.

Appendix

C

BIOS Options

NANO-ADL-P

Below is a list of BIOS configuration options in the BIOS chapter.

➔ BIOS Information	88
➔ Processor Information.....	88
➔ PCH Information.....	89
➔ System Date [xx/xx/xx]	89
➔ System Time [xx:xx:xx]	89
➔ Intel (VMX) Virtualization Technology [Enabled]	93
➔ Power Limit 1 [0]	93
➔ Power Limit 2 [0]	93
➔ Power Limit 1 Time Window [0].....	93
➔ EIST [Enabled].....	93
➔ C states [Disabled].....	93
➔ Turbo Mode [Enabled]	94
➔ Active Performance Cores [All].....	94
➔ Active Efficient Cores [All].....	94
➔ Hyper-Threading [Enabled].....	95
➔ Security Device Support [Enable]	95
➔ Pending Operation [None]	96
➔ Wake system with Fixed Time [Enabled].....	97
➔ Serial Port [Enabled].....	99
➔ Device Settings	99
➔ Serial Port [Enabled].....	100
➔ Device Settings	100
➔ Serial Port [Enabled].....	101
➔ Device Settings	101
➔ Serial Port [Enabled].....	102
➔ Device Settings	102
➔ Serial Port [Enabled].....	103
➔ Device Settings	103
➔ Device Mode [RS232].....	103
➔ Serial Port [Enabled].....	104
➔ Device Settings	104
➔ Device Mode [RS232].....	105
➔ PC Health Status	106

→ CPU_FAN1 Smart Fan Control [Auto Mode]	107
→ CPU_FAN1 Start Temperature	107
→ CPU_FAN1 Off Temperature	108
→ CPU_FAN1 Start PWM	108
→ Console Redirection [Disabled].....	109
→ Terminal Type [ANSI].....	110
→ Bits per second [115200].....	110
→ Data Bits [8]	111
→ Parity [None].....	111
→ Stop Bits [1].....	111
→ VT-d [Enabled].....	114
→ Primary Display [Auto]	117
→ Internal Graphics [Enabled].....	117
→ DVMT Pre-Allocated [160M]	118
→ Auto Power Button Function [Disabled (AT)]	121
→ Restore AC Power Loss [Last State]	121
→ Power Saving Function (EUP) [Disabled].....	122
→ USB Power state [+5V DUAL]	122
→ PCIe Speed [Auto].....	124
→ Detect Non-Compliance Device [Disabled]	124
→ SATA Controller(s) [Enabled]	125
→ SATA Mode Selection [AHCI].....	126
→ Hot Plug [Disabled]	126
→ HD Audio [Enabled]	127
→ Administrator Password	129
→ User Password	129
→ Quiet Boot [Enabled]	130
→ Launch PXE OpROM [Disabled]	130
→ Option ROM Messages [Force BIOS].....	131
→ Boot Option #1	131
→ Boot Option #2	131
→ Save Changes and Reset	132
→ Discard Changes and Reset	132
→ Restore Defaults	132
→ Save as User Defaults	133

NANO-ADL-P

➔ Restore User Defaults	133
-------------------------------	-----

Appendix

D

Watchdog Timer

NANO-ADL-P

**NOTE:**

The following discussion applies to DOS environment. Contact IEI support or visit the IEI website for specific drivers for other operating systems.

The Watchdog Timer is provided to ensure that standalone systems can always recover from catastrophic conditions that cause the CPU to crash. This condition may have occurred by external EMIs or a software bug. When the CPU stops working correctly, Watchdog Timer either performs a hardware reset (cold boot) or a Non-Maskable Interrupt (NMI) to bring the system back to a known state.

A BIOS function call (INT 15H) is used to control the Watchdog Timer.

INT 15H:

AH – 6FH Sub-function:	
AL – 2:	Sets the Watchdog Timer's period.
BL:	Time-out value (Its unit-second is dependent on the item "Watchdog Timer unit select" in CMOS setup).

Table D-1: AH-6FH Sub-function

Call sub-function 2 to set the time-out period of Watchdog Timer first. If the time-out value is not zero, the Watchdog Timer starts counting down. When the timer value reaches zero, the system resets. To ensure that this reset condition does not occur, calling sub-function 2 must periodically refresh the Watchdog Timer. However, the watchdog timer is disabled if the time-out value is set to zero.

A tolerance of at least 10% must be maintained to avoid unknown routines within the operating system (DOS), such as disk I/O that can be very time-consuming.

**NOTE:**

When exiting a program it is necessary to disable the Watchdog Timer, otherwise the system resets.

EXAMPLE PROGRAM:

; INITIAL TIMER PERIOD COUNTER

;

W_LOOP:

;

```
MOV     AX, 6F02H      ;setting the time-out value
MOV     BL, 30         ;time-out value is 48 seconds
INT     15H
```

;

; ADD THE APPLICATION PROGRAM HERE

;

```
CMP     EXIT_AP, 1     ;is the application over?
JNE     W_LOOP        ;No, restart the application
```

```
MOV     AX, 6F02H      ;disable Watchdog Timer
MOV     BL, 0          ;
INT     15H
```

;

; EXIT ;

Appendix

E

Error Beep Code

E.1 PEI Beep Codes

Number of Beeps	Description
1	Memory not Installed
1	Memory was installed twice (InstallPeiMemory routine in PEI Core called twice)
2	Recovery started
3	DXE IPL was not found
3	DXE Core Firmware Volume was not found
4	Recovery failed
4	S3 Resume failed
7	Reset PPI is not available

E.2 DXE Beep Codes

Number of Beeps	Description
1	Invalid password
4	Some of the Architectural Protocols are not available
5	No Console Output Devices are found
5	No Console Input Devices are found
6	Flash update is failed
7	Reset protocol is not available
8	Platform PCI resource requirements cannot be met



NOTE:

If you have any question, please contact IEI for further assistance.

Appendix

F

Hazardous Materials Disclosure

F.1 RoHS II Directive (2015/863/EU)

The details provided in this appendix are to ensure that the product is compliant with the RoHS II Directive (2015/863/EU). The table below acknowledges the presences of small quantities of certain substances in the product, and is applicable to RoHS II Directive (2015/863/EU).

Please refer to the following table.

Part Name	Toxic or Hazardous Substances and Elements									
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (CR(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)	Bis(2-ethylhexyl) phthalate (DEHP)	Butyl benzyl phthalate (BBP)	Dibutyl phthalate (DBP)	Diisobutyl phthalate (DIBP)
Housing	O	O	O	O	O	O	O	O	O	O
Printed Circuit Board	O	O	O	O	O	O	O	O	O	O
Metal Fasteners	O	O	O	O	O	O	O	O	O	O
Cable Assembly	O	O	O	O	O	O	O	O	O	O
Fan Assembly	O	O	O	O	O	O	O	O	O	O
Power Supply Assemblies	O	O	O	O	O	O	O	O	O	O
Battery	O	O	O	O	O	O	O	O	O	O
<p>O: This toxic or hazardous substance is contained in all of the homogeneous materials for the part is below the limit requirement in Directive (EU) 2015/863.</p> <p>X: This toxic or hazardous substance is contained in at least one of the homogeneous materials for this part is above the limit requirement in Directive (EU) 2015/863.</p>										

NANO-ADL-P

F.2 China RoHS

此附件旨在确保本产品符合中国 RoHS 标准。以下表格标示此产品中某有毒物质的含量符合中国 RoHS 标准规定的限量要求。

本产品上会附有“环境友好使用期限”的标签，此期限是估算这些物质“不会有泄漏或突变”的年限。本产品可能包含有较短的环境友好使用期限的可替换元件，像是电池或灯管，这些元件将会单独标示出来。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (CR(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
壳体	○	○	○	○	○	○
印刷电路板	○	○	○	○	○	○
金属螺帽	○	○	○	○	○	○
电缆组装	○	○	○	○	○	○
风扇组装	○	○	○	○	○	○
电力供应组装	○	○	○	○	○	○
电池	○	○	○	○	○	○
<p>O: 表示该有毒有害物质在该部件所有物质材料中的含量均在 SJ/T11364-2014 與 GB/T26572-2011 标准规定的限量要求以下。</p> <p>X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11364-2014 與 GB/T26572-2011 标准规定的限量要求。</p>						