




IEI Technology Corp.



**MODEL:  
IMB-Q670**

**Micro-ATX LGA1155 Motherboard for Intel® Core™ i7/i5/i3  
Quad/Dual core CPU, Intel® Q67, DDR3, VGA/DVI/HDMI  
Dual Intel PCIe GbE, Two USB 3.0 ports, Ten COM ports  
Two SATA 6Gb/s ports, Audio and RoHS**

# User Manual

Rev. 1.00 – April 28, 2011



# Revision

---

Date	Version	Changes
April 28, 2011	1.00	Initial release

# Copyright

---

## **COPYRIGHT NOTICE**

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

## **TRADEMARKS**

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

# Table of Contents

---

<b>1 INTRODUCTION.....</b>	<b>1</b>
1.1 INTRODUCTION.....	2
1.2 BENEFITS .....	2
1.3 FEATURES.....	3
1.4 CONNECTORS .....	4
1.5 DIMENSIONS.....	5
1.6 DATA FLOW .....	6
1.7 TECHNICAL SPECIFICATIONS .....	7
<b>2 PACKING LIST.....</b>	<b>9</b>
2.1 ANTI-STATIC PRECAUTIONS .....	10
2.2 UNPACKING PRECAUTIONS.....	10
2.3 PACKING LIST.....	11
2.4 OPTIONAL ITEMS .....	12
<b>3 CONNECTORS .....</b>	<b>14</b>
3.1 PERIPHERAL INTERFACE CONNECTORS.....	15
3.1.1 IMB-Q670 Layout .....	15
3.1.2 Peripheral Interface Connectors .....	15
3.1.3 External Interface Panel Connectors.....	16
3.2 INTERNAL PERIPHERAL CONNECTORS .....	17
3.2.1 ATX Power Connector .....	17
3.2.2 Battery Connector.....	18
3.2.3 CPU Fan Connector .....	19
3.2.4 CPU Power Connector .....	20
3.2.5 Digital I/O Connector.....	21
3.2.6 Front Panel Audio Connector.....	22
3.2.7 Front Panel Connector .....	23
3.2.8 FW Programming.....	24
3.2.9 Infrared Interface Connector.....	25
3.2.10 Memory Card Slot.....	26

## IMB-Q670 Micro-ATX Motherboard

3.2.11 PCH Fan Connector.....	27
3.2.12 PCI Express Power .....	28
3.2.13 SATA 3Gb/s Drive Connector .....	29
3.2.14 SATA 6Gb/s Drive Connector .....	30
3.2.15 Serial Port Connector, RS-422/485.....	31
3.2.16 Serial Port Connectors, RS-232.....	32
3.2.17 SMBus Connector .....	34
3.2.18 SPDIF Connector.....	35
3.2.19 SPI Connector.....	36
3.2.20 System Fan Connector .....	36
3.2.21 TPM Connector.....	37
3.2.22 USB Connectors.....	38
<b>3.3 EXTERNAL PERIPHERAL INTERFACE CONNECTOR PANEL .....</b>	<b>40</b>
3.3.1 Audio Connector .....	40
3.3.2 Keyboard/Mouse Connector .....	41
3.3.3 Ethernet and USB Connector.....	41
3.3.4 HDMI Port Connector .....	42
3.3.5 Serial Port Connectors (COM1).....	43
3.3.6 VGA and DVI Connector .....	44
<b>4 INSTALLATION .....</b>	<b>46</b>
4.1 ANTI-STATIC PRECAUTIONS .....	47
4.2 INSTALLATION CONSIDERATIONS.....	47
4.2.1 Socket LGA1155 CPU Installation .....	49
4.2.2 Socket LGA1155 Cooling Kit Installation.....	52
4.2.3 DIMM Installation .....	54
4.3 JUMPER SETTINGS .....	55
4.3.1 AT/ATX Power Mode Jumper (by active hardware) .....	55
4.3.2 Clear CMOS Jumper.....	56
4.3.3 ME Debug Connector .....	57
4.3.4 USB Power Select Jumper .....	58
4.3.5 Wake-on LAN Jumper .....	58
4.4 INTERNAL PERIPHERAL DEVICE CONNECTIONS.....	59
4.4.1 SATA Drive Connection .....	59
4.5 EXTERNAL PERIPHERAL INTERFACE CONNECTION .....	61

4.5.1 Audio Connector .....	61
4.5.2 LAN Connection.....	62
4.5.3 Parallel Device Connection.....	63
4.5.4 PS/2 Keyboard and Mouse Connection .....	64
4.5.5 Serial Device Connection .....	65
4.5.6 USB Connection (Dual Connector).....	66
4.5.7 VGA Monitor Connection .....	67
4.6 SOFTWARE INSTALLATION .....	68
<b>5 BIOS.....</b>	<b>71</b>
5.1 INTRODUCTION.....	72
5.1.1 Starting Setup.....	72
5.1.2 Using Setup .....	72
5.1.3 Getting Help.....	73
5.1.4 Unable to Reboot after Configuration Changes .....	73
5.1.5 BIOS Menu Bar.....	73
5.2 MAIN.....	74
5.3 ADVANCED.....	75
5.3.1 ACPI Settings.....	76
5.3.2 Trusted Computing .....	77
5.3.3 CPU Configuration.....	78
5.3.3.1 CPU Information.....	79
5.3.4 SATA Configuration .....	80
5.3.5 Intel TXT(LT) Configuration.....	81
5.3.6 USB Configuration.....	82
5.3.7 Super IO Configuration .....	84
5.3.7.1 Serial Port n Configuration .....	85
5.3.8 H/W Monitor .....	90
5.3.8.1 FAN 1 Configuration .....	92
5.3.8.2 FAN 2 Configuration .....	93
5.3.9 Secondary Super IO Configuration .....	95
5.3.9.1 Serial Port 7 Configuration .....	96
5.3.9.2 Serial Port 8 Configuration .....	97
5.3.9.3 Serial Port 9 Configuration .....	97
5.3.9.4 Serial Port 10 Configuration .....	98

## IMB-Q670 Micro-ATX Motherboard

5.3.10 Serial Port Console Redirection .....	99
5.4 CHIPSET .....	101
5.4.1 Northbridge Configuration .....	103
5.4.2 Southbridge Configuration .....	105
5.4.3 Integrated Graphics .....	109
5.4.4 ME Subsystem .....	110
5.4.4.1 AMT Configuration .....	111
5.5 BOOT .....	113
5.6 SECURITY .....	114
5.7 EXIT .....	115
<b>A BIOS OPTIONS .....</b>	<b>117</b>
<b>B TERMINOLOGY .....</b>	<b>121</b>
<b>C DIGITAL I/O INTERFACE .....</b>	<b>125</b>
C.1 INTRODUCTION .....	126
C.2 DIO CONNECTOR PINOUTS .....	126
C.3 ASSEMBLY LANGUAGE SAMPLES .....	126
C.3.1 Enable the DIO Input Function .....	126
C.3.2 Enable the DIO Output Function .....	127
<b>D WATCHDOG TIMER .....</b>	<b>128</b>
<b>E COMPATIBILITY .....</b>	<b>131</b>
E.1 COMPATIBLE OPERATING SYSTEMS .....	132
E.2 COMPATIBLE PROCESSORS .....	132
<b>F HAZARDOUS MATERIALS DISCLOSURE .....</b>	<b>133</b>
F.1 HAZARDOUS MATERIALS DISCLOSURE TABLE FOR IPB PRODUCTS CERTIFIED AS ROHS COMPLIANT UNDER 2002/95/EC WITHOUT MERCURY .....	134

# List of Figures

---

Figure 1-1: IMB-Q670.....	2
Figure 1-2: Connectors .....	4
Figure 1-3: IMB-Q670 Dimensions (mm) .....	5
Figure 1-4: Data Flow Diagram.....	6
Figure 3-1: Connectors and Jumpers.....	15
Figure 3-2: ATX Power Connector Pinout Location.....	18
Figure 3-3: Battery Connector Location.....	19
Figure 3-4: CPU Fan Connector Location .....	20
Figure 3-5: CPU Power Connector Location.....	21
Figure 3-6: Digital I/O Connector Location .....	22
Figure 3-7: Front Panel Audio Connector Location .....	23
Figure 3-8: Front Panel Connector Location .....	24
Figure 3-9: FW Programming Connector Location .....	25
Figure 3-10: Infrared Connector Location.....	26
Figure 3-11: Memory Card Slot Location .....	27
Figure 3-12: PCH Fan Connector Location .....	28
Figure 3-13: PCIe Power Location .....	29
Figure 3-14: SATA 3Gb/s Drive Connector Location .....	30
Figure 3-15: SATA 6Gb/s Drive Connector Location .....	31
Figure 3-16: Serial Port Connector Location .....	32
Figure 3-17: Serial Port Connector Location .....	33
Figure 3-18: SMBus Connector Location .....	34
Figure 3-19: SPDIF Connector Location .....	35
Figure 3-20: SPI Connector Location .....	36
Figure 3-21: System Fan Connector Location.....	37
Figure 3-22: TPM Connector Location.....	38
Figure 3-23: USB Connector Pinout Locations .....	39
Figure 3-24: External Peripheral Interface Connector .....	40
Figure 3-25: Audio Connector .....	41
Figure 3-26: Serial Port Connector Pinouts.....	44



## IMB-Q670 Micro-ATX Motherboard

Figure 3-27: VGA Connector .....	45
Figure 4-1: Intel LGA1155 Socket .....	49
Figure 4-2: Remove Protective Cover.....	50
Figure 4-3: CPU Socket Load Plate.....	50
Figure 4-4: Insert the Socket LGA1155 CPU.....	51
Figure 4-5: Cooling Kits (CF-1156A-RS and CF-1156B-RS) .....	52
Figure 4-6: Securing the Heat sink to the IMB-Q670.....	53
Figure 4-7: DIMM Installation.....	54
Figure 4-8: AT/ATX Power Mode Jumper Location.....	56
Figure 4-9: Clear BIOS Jumper Location .....	57
Figure 4-10: ME Debug Connector Location .....	57
Figure 4-11: USB Power Select Jumper Location .....	58
Figure 4-12: Wake-on LAN Connector Pinout Locations .....	59
Figure 4-13: SATA Drive Cable Connection.....	60
Figure 4-14: SATA Power Drive Connection.....	61
Figure 4-15: Audio Connector .....	62
Figure 4-16: LAN Connection .....	63
Figure 4-17: Parallel Device Connector.....	64
Figure 4-18: PS/2 Keyboard/Mouse Connector .....	65
Figure 4-19: Serial Device Connector.....	66
Figure 4-20: USB Connector.....	67
Figure 4-21: VGA Connector .....	68
Figure 4-22: Introduction Screen .....	69
Figure 4-23: Available Drivers .....	70

# List of Tables

---

Table 1-1: IMB-Q670 Specifications.....	8
Table 2-1: Packing List.....	12
Table 2-2: Optional Items.....	13
Table 3-1: Peripheral Interface Connectors.....	16
Table 3-2: Rear Panel Connectors.....	17
Table 3-3: ATX Power Connector Pinouts.....	18
Table 3-4: Battery Connector Pinouts.....	19
Table 3-5: CPU Fan Connector Pinouts.....	20
Table 3-6: CPU Power Connector Pinouts.....	21
Table 3-7: Digital I/O Connector Pinouts.....	22
Table 3-8: Front Panel Audio Connector Pinouts.....	23
Table 3-9: Front Panel Connector Pinouts.....	24
Table 3-10: FW Programming Connector Pinouts.....	25
Table 3-11: Infrared Connector Pinouts.....	26
Table 3-12: PCH Fan Connector Pinouts.....	28
Table 3-13: PCIe Power Pinouts.....	29
Table 3-14: SATA 3Gb/s Drive Connector Pinouts.....	30
Table 3-15: SATA 6Gb/s Drive Connector Pinouts.....	31
Table 3-16: Serial Port Connector Pinouts.....	32
Table 3-17: Serial Port Connector Pinouts.....	34
Table 3-18: SMBus Connector Pinouts.....	35
Table 3-19: SPDIF Connector Pinouts.....	35
Table 3-20: SPI Connector Pinouts.....	36
Table 3-21: System Fan Connector Pinouts.....	37
Table 3-22: TPM Connector Pinouts.....	38
Table 3-23: USB Port Connector Pinouts.....	39
Table 3-24: PS/2 Connector Pinouts.....	41
Table 3-25: LAN Pinouts.....	42
Table 3-26: USB Port Pinouts.....	42
Table 3-27: HDMI Connector Pinouts.....	43

## IMB-Q670 Micro-ATX Motherboard

Table 3-28: Serial Port Connector Pinouts .....	43
Table 3-29: VGA Connector Pinouts.....	44
Table 3-30: DVI Connector Pinouts.....	45
Table 4-1: Jumpers .....	55
Table 4-2: AT/ATX Power Mode Jumper Settings .....	56
Table 4-3: Clear BIOS Jumper Settings.....	56
Table 4-4: ME Debug Connector Pinouts.....	58
Table 4-5: USB Power Select Jumper Settings .....	58
Table 4-6: Wake-on LAN Connector Pinouts .....	59
Table 5-1: BIOS Navigation Keys .....	73
Table 5-2: Digital I/O Connector Pinouts.....	126

# BIOS Menus

---

BIOS Menu 1: Main .....	74
BIOS Menu 2: Advanced .....	76
BIOS Menu 3: ACPI Configuration .....	76
BIOS Menu 4: TPM Configuration .....	77
BIOS Menu 5: CPU Configuration .....	78
BIOS Menu 6: CPU Configuration .....	79
BIOS Menu 7: SATA Configuration .....	80
BIOS Menu 8: Intel TXT(LT) Configuration .....	82
BIOS Menu 9: USB Configuration .....	82
BIOS Menu 10: Super IO Configuration.....	84
BIOS Menu 11: Serial Port n Configuration Menu .....	85
BIOS Menu 12: H/W Monitor .....	91
BIOS Menu 13: FAN 1 Configuration .....	92
BIOS Menu 14: FAN 2 Configuration .....	94
BIOS Menu 15: Secondary Super IO Configuration .....	95
BIOS Menu 16: Serial Port Console Redirection .....	100
BIOS Menu 17: Chipset .....	102
BIOS Menu 18:Northbridge Chipset Configuration.....	103
BIOS Menu 19: Southbridge Chipset Configuration .....	106
BIOS Menu 20: Integrated Graphics .....	109
BIOS Menu 21: ME Subsystem.....	111
BIOS Menu 22: AMT Configuration .....	112
BIOS Menu 23: Boot .....	113
BIOS Menu 24: Security .....	114
BIOS Menu 25:Exit.....	115

Chapter

1

# Introduction

---

## 1.1 Introduction



**Figure 1-1: IMB-Q670**

The IMB-Q670 is a MicroATX motherboard. It accepts a Socket LGA1155 Intel® Core™ i3/i5/i7 processor and supports four 240-pin 1333/1066 MHz dual-channel DDR3 DIMM modules up to 32.0 GB maximum. The IMB-Q670 includes a VGA, HDMI, and DVI-D port. Expansion and I/O include one PCI slot, one PCIe x16 slot, one PCIe x4 slot, one PCIe x16 slot with x1 signal, two USB 3.0 ports on the rear panel by NEC D720200F1, two USB 2.0 on the rear panel, eight USB 2.0 by pin header, four SATA 3Gb/s connectors, two SATA 6Gb/s connectors, ten COM ports, and a keyboard/mouse connector.

## 1.2 Benefits

Some of the IMB-Q670 motherboard benefits include:

- Powerful graphics with multiple monitors
- Staying connected with both wired LAN connections
- Speedy running of multiple programs and applications

## IMB-Q670 Micro-ATX Motherboard

### 1.3 Features

Some of the IMB-Q670 motherboard features are listed below:

- Micro-ATX
- RoHS compliant
- LGA1155 CPU socket
- One PCI card expansion slot
- One PCIe x16 card expansion slot
- One PCIe x16 card expansion slot with x1 signal
- One PCIe x4 card expansion slot
- Supports two dual-channel DDR3 DIMMs
- One external RS-232 serial port
- Eight internal RS-232 serial ports connectors
- One internal RS-422/485 serial port connector
- Two Intel PCIe Gigabit Ethernet connectors
- Four SATA 3Gb/s connectors
- Two SATA 6Gb/s connectors
- High Definition audio
- Intel® Q67 Chipset

### 1.4 Connectors

The connectors on the IMB-Q670 are shown in the figure below.




Figure 1-2: Connectors





## 1.6 Data Flow

Figure 1-4 shows the data flow between the system chipset, the CPU and other components installed on the motherboard.




Figure 1-4: Data Flow Diagram

## IMB-Q670 Micro-ATX Motherboard

### 1.7 Technical Specifications

IMB-Q670 technical specifications are listed below.

Specification/Model	IMB-Q670
<b>Form Factor</b>	Micro-ATX
<b>CPU Supported</b>	LGA1155 Socket Intel® Core™ i7/i5/i3 Quad/Dual core
<b>Northbridge Chipset</b>	Intel® Q67
<b>Integrated Graphics</b>	Supports DirectX 10.1/OpenGL 3.0 Full MPEG2, VC1, AVC Decode
<b>Memory</b>	Four 240-pin 1333/1066 MHz Dual-Channel DDR3 SDRAM DIMMs support up to 32.0 GB maximum
<b>Southbridge Chipset</b>	Intel® Q67
<b>Audio</b>	Realtek ALC888 HD Audio codec (Line-in, Line-out, Mic)
<b>BIOS</b>	UEFI BIOS
<b>Digital I/O</b>	24-bit, 12-bit input/12-bit output
<b>Ethernet Controllers</b>	Intel® 82574L/Intel® 82579 PHY with Intel® AMT 7.0 support
<b>Super I/O Controller</b>	Fintek F81866
<b>Watchdog Timer</b>	Software programmable supports 1~255 sec. system reset
<b>Expansion</b>	
<b>PCI</b>	One PCI slot
<b>PCIe</b>	One PCIe x4 slot One PCIe x16 slot One PCIe x16 slot (with x1 signal)
<b>I/O Interface Connectors</b>	
<b>Audio Connectors</b>	One external audio jack (line-in, line-out, mic-in) One internal front panel audio connector (2x5 pin header)
<b>Display port</b>	One VGA Integrated in the Intel® Q67 One HDMI Integrated in the Intel® Q67 One DVI-D Integrated in the Intel® Q67

<b>Specification/Model</b>	<b>IMB-Q670</b>
<b>Ethernet</b>	Two RJ-45 ports
<b>Keyboard/Mouse</b>	Dual PS/2 port
<b>TPM</b>	2 x 10-pin pin header
<b>Serial Ports</b>	One external RS-232 serial port One RS-422/485 via internal box pin headers Eight RS-232 via internal box pin headers
<b>USB ports</b>	Two external USB 2.0 ports on rear IO Two external USB 3.0 ports on rear IO by NEC D720200F1 Eight internal USB 2.0 ports by pin header
<b>Serial ATA</b>	Four SATA 3Gb/s channels with 3.0 Gb/s data transfer rates Two SATA 6Gb/s channels with 6.0 Gb/s data transfer rates
<b>Environmental and Power Specifications</b>	
<b>Power Supply</b>	ATX supported
<b>Power Consumption</b>	3.3V@1.75A, 5V@6.61A , 12V@3.68A, 12V@0.09A, 5VSb@0.12 (Intel® 2.60GHz CPU with 1333MHz DDR3 4GB x 4 Memory)
<b>Operating temperature</b>	-20°C ~ 60°C/-4°F ~ 140°F
<b>Humidity</b>	5% ~ 95% (non-condensing)
<b>Physical Specifications</b>	
<b>Dimensions</b>	244 mm x 244 mm
<b>Weight GW/NW</b>	1200 g / 680 g

**Table 1-1: IMB-Q670 Specifications**

Chapter

2

# Packing List

---

## 2.1 Anti-static Precautions

---



### WARNING!

Static electricity can destroy certain electronics. Make sure to follow the ESD precautions to prevent damage to the product, and injury to the user.

---

Make sure to adhere to the following guidelines:

- **Wear an anti-static wristband:** Wearing an anti-static wristband can prevent electrostatic discharge.
- **Self-grounding:** Touch a grounded conductor every few minutes to discharge any excess static buildup.
- **Use an anti-static pad:** When configuring any circuit board, place it on an anti-static mat.
- **Only handle the edges of the PCB:** Don't touch the surface of the motherboard. Hold the motherboard by the edges when handling.

## 2.2 Unpacking Precautions

When the IMB-Q670 is unpacked, please do the following:

- Follow the antistatic guidelines above.
- Make sure the packing box is facing upwards when opening.
- Make sure all the packing list items are present.

## IMB-Q670 Micro-ATX Motherboard






### 2.3 Packing List




#### NOTE:

If any of the components listed in the checklist below are missing, do not proceed with the installation. Contact the IEI reseller or vendor the IMB-Q670 was purchased from or contact an IEI sales representative directly by sending an email to [sales@iei.com.tw](mailto:sales@iei.com.tw).

The IMB-Q670 is shipped with the following components:

Quantity	Item and Part Number	Image
1	IMB-Q670	
4	SATA cable (P/N: 32000-062800-RS)	
1	I/O shielding (P/N: 45014-0008C0-00-RS)	
1	Mini jumper pack (2.54mm) (P/N:33100-000079-RS)	
1	Utility CD	

Quantity	Item and Part Number	Image
1	Quick Installation Guide	

**Table 2-1: Packing List**


## 2.4 Optional Items

The following are optional components which may be separately purchased:

Item and Part Number	Image
Dual Ports USB Cable with Bracket (P/N: CB-USB02-RS)	
SATA Power Cable (P/N: 32102-000100-100-RS) (P/N: 32102-000100-200-RS)	
LGA1155/LGA1156 Cooler kit (1U Chassis compatible, 73W) (P/N: CF-1156A-RS)	
LGA1155/LGA1156 Cooler kit (95W) (P/N: CF-1156B-RS)	
RS-422/485 cable (P/N: 19800-000058-RS)	
Quad port RS-232 cable (400/400/400/400MM) (P/N: 32205-001203-100-RS)	



## IMB-Q670 Micro-ATX Motherboard

Item and Part Number	Image
20-Pin INFINEON TPM Module, S/W management tool (P/N: TPM-IN01-R10)	

**Table 2-2: Optional Items**



Chapter

3

# Connectors

---

## IMB-Q670 Micro-ATX Motherboard

### 3.1 Peripheral Interface Connectors

This chapter details all the jumpers and connectors.

#### 3.1.1 IMB-Q670 Layout

The figures below show all the connectors and jumpers.




Figure 3-1: Connectors and Jumpers

#### 3.1.2 Peripheral Interface Connectors

The table below lists all the connectors on the board.

Connector	Type	Label
ATX Power connector	24-pin ATX	ATX
Battery connector	3-pin wafer	BAT1

Connector	Type	Label
CPU fan	4-pin wafer	CPU_FAN
CPU power	4-pin box header	CPU12V1
Digital I/O	24-pin header	DIO1
Front panel audio	10-pin header	FP_AUDIO
Front panel	14-pin header	F_PANEL1
FW programming	8-pin header	CN1
Infrared interface	5-pin header	IR1
Memory card	DIMM slot	DIMM1, DIMM2
PCH fan connector	3-pin header	PCH_FAN1
PCI-E power	4-pin molex	PCIE_12V1
SATA 3Gb/s drive connector	16-pin SATA connector	SATA34, SATA56
SATA 6Gb/s drive connector	7-pin SATA connector	SATA1, SATA2
Serial port, RS-422/485	4-pin box headers	COM2
Serial port, RS-232	40-pin box headers	COM3-6, COM7-10
SMBus connector	4-pin wafer	SMBUS_1
SPDIF	5-pin header	SPDIF1
SPI connector	8-pin header	SPI
System fan connectors	3-pin wafer	SYS_FAN1, SYS_FAN2
TPM connector	20-pin header	TPM
USB connectors	8-pin headers	USB1, USB2, USB3, USB4

**Table 3-1: Peripheral Interface Connectors**

### 3.1.3 External Interface Panel Connectors

The table below lists the connectors on the external I/O panel.

## IMB-Q670 Micro-ATX Motherboard

Connector	Type	Label
Audio connector	Audio jack	AUDIO_JACK
Keyboard/Mouse	Dual PS/2	KBMS
Ethernet and USB ports	RJ-45, USB	LAN1_USB LAN2_USB
HDMI connector	HDMI port	HDMI
Serial Port connector (COM1)	9-pin male DB-9	COM1
VGA and DVI connector	15-pin female, 24-pin header	DVI+CRT

**Table 3-2: Rear Panel Connectors**


## 3.2 Internal Peripheral Connectors

The section describes all of the connectors on the IMB-Q670.

### 3.2.1 ATX Power Connector

- CN Label:** ATX
- CN Type:** 24-pin ATX (2x12)
- CN Location:** See **Figure 3-2**
- CN Pinouts:** See **Table 3-3**

The ATX power connector connects to an ATX power supply.



**Figure 3-2: ATX Power Connector Pinout Location**

Pin	Description	Pin	Description
1	+3.3 V	13	+3.3 V
2	+3.3 V	14	-12 V
1	+3.3V	13	+3.3V
2	+3.3V	14	-12V
3.	GND	15	GND
4	+5 V	16	PS-ON-
5	GND	17	GND
6	+5V	18	GND
7	GND	19	GND
8	PWRGD_PS	20	NC
9	+5VSB	21	+5 V
10	+12V	22	+5 V
11	+12V	23	+5 V
12	+3.3V	24	GND

**Table 3-3: ATX Power Connector Pinouts**


### 3.2.2 Battery Connector

CN Label:      **BAT1**

## IMB-Q670 Micro-ATX Motherboard

- CN Type:** 3-pin slot
- CN Location:** See **Figure 3-3**
- CN Pinouts:** See **Table 3-4**

This is connected to the system battery. The battery provides power to the system clock to retain the time when power is turned off.



**Figure 3-3: Battery Connector Location**


Pin	Description
1	NC
2	BAT +
3	BAT-(GND)

**Table 3-4: Battery Connector Pinouts**

### 3.2.3 CPU Fan Connector

- CN Label:** CPU\_FAN
- CN Type:** 4-pin wafer
- CN Location:** See **Figure 3-4**
- CN Pinouts:** See **Table 3-5**

The fan connector attaches to a CPU cooling fan.



**Figure 3-4: CPU Fan Connector Location**

PIN NO.	DESCRIPTION
1	GND
2	+12 V
3	FANIN
4	FANOUT

**Table 3-5: CPU Fan Connector Pinouts**


### 3.2.4 CPU Power Connector

- CN Label:** CPU12V1
- CN Type:** 4-pin box header
- CN Location:** See **Figure 3-5**
- CN Pinouts:** See **Table 3-6**

The CPU power input connector provides power to the CPU.



## IMB-Q670 Micro-ATX Motherboard



**Figure 3-5: CPU Power Connector Location**


PIN NO.	DESCRIPTION
1	GND
2	GND
3	+12V
4	+12V

**Table 3-6: CPU Power Connector Pinouts**

### 3.2.5 Digital I/O Connector

- CN Label:** DIO1
- CN Type:** 24-pin header
- CN Location:** See **Figure 3-6**
- CN Pinouts:** See **Table 3-7**

The digital I/O connector provides programmable input and output for external devices. The digital I/O provides 12-bit output and 12-bit input.



**Figure 3-6: Digital I/O Connector Location**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GND	2	+5V
3	D_IN0	4	D_OUT0
5	D_IN1	6	D_OUT1
7	D_IN2	8	D_OUT2
9	D_IN3	10	D_OUT3
11	D_8IN0	12	D_8OUT0
13	D_8IN1	14	D_8OUT1
15	D_8IN2	16	D_8OUT2
17	D_8IN3	18	D_8OUT3
19		20	
21		22	
23		24	


**Table 3-7: Digital I/O Connector Pinouts**

### 3.2.6 Front Panel Audio Connector

- CN Label:** FP\_AUDIO
- CN Type:** 10-pin header
- CN Location:** See **Figure 3-7**
- CN Pinouts:** See **Table 3-8**

## IMB-Q670 Micro-ATX Motherboard

This connector connects to speakers, a microphone and an audio input.



**Figure 3-7: Front Panel Audio Connector Location**


Pin	Description	Pin	Description
1	MIC_L	2	Audio GND
3	MIC_R	4	FP_AUO DETECT
5	Line_R	6	PD
7	F_SENSE	8	NC
9	Line_L	10	PD

**Table 3-8: Front Panel Audio Connector Pinouts**

### 3.2.7 Front Panel Connector

<b>CN Label:</b>	<b>F_PANEL</b>
<b>CN Type:</b>	14-pin header
<b>CN Location:</b>	See <b>Figure 3-8</b>
<b>CN Pinouts:</b>	See <b>Table 3-9</b>

The front panel connector connects to the indicator LEDs and buttons on the computer's front panel.



**Figure 3-8: Front Panel Connector Location**

FUNCTION	PIN	DESCRIPTION	FUNCTION	PIN	DESCRIPTION
Power LED	1	Power LED	Speaker	2	Beep Power
	3	NC		4	NC
	5	GND		6	NC
Power Button	7	PWRBTSW#	Reset	8	PC Beep
	9	GND		10	NC
HDD LED	11	HDDLED		12	EXTRST#
	13	HDDLED#	14	GND	


**Table 3-9: Front Panel Connector Pinouts**

### 3.2.8 FW Programming

- CN Label:** CN1
- CN Type:** 8-pin header
- CN Location:** See **Figure 3-9**
- CN Pinouts:** See **Table 3-10**

The FW Programming connector is used for programming the firmware.

## IMB-Q670 Micro-ATX Motherboard



**Figure 3-9: FW Programming Connector Location**


Pin	Description	Pin	Description
1	+3.3V	2	TDO
3	TDI	4	NC
5	NC	6	TMS
7	GND	8	TCK

**Table 3-10: FW Programming Connector Pinouts**

### 3.2.9 Infrared Interface Connector

- CN Label:** IR1
- CN Type:** 5-pin header (1x5)
- CN Location:** See **Figure 3-10**
- CN Pinouts:** See **Table 3-11**

The infrared connector attaches to an infrared receiver for use with remote controls.



**Figure 3-10: Infrared Connector Location**

Pin	Description
1	+5V
2	NC
3	IR_RX
4	GND
5	IR_TX

**Table 3-11: Infrared Connector Pinouts**

### 3.2.10 Memory Card Slot

- CN Label:** DIMM1, DIMM2
- CN Type:** DDR3 DIMM slot
- CN Location:** See **Figure 3-11**

The DIMM slots are for DIMM memory modules.

## IMB-Q670 Micro-ATX Motherboard





Figure 3-11: Memory Card Slot Location

### 3.2.11 PCH Fan Connector

<b>CN Label:</b>	<b>PCH_FAN</b>
<b>CN Type:</b>	3-pin header
<b>CN Location:</b>	See <b>Figure 3-12</b>
<b>CN Pinouts:</b>	See <b>Table 3-12</b>

The PCH fan connector attaches to a PCH cooling fan.



**Figure 3-12: PCH Fan Connector Location**

Pin	Description
1	FANIN
2	+12V
3	GND

**Table 3-12: PCH Fan Connector Pinouts**


### 3.2.12 PCI Express Power

- CN Label:** PCIE\_POWER
- CN Type:** 4-pin Molex
- CN Location:** See **Figure 3-13**
- CN Pinouts:** See **Table 3-13**

Provides extra power to the PCIe x16 card.



## IMB-Q670 Micro-ATX Motherboard



**Figure 3-13: PCIe Power Location**


Pin	Description
1	VCC +5V
2	GND
3	GND
4	VCC +12V

**Table 3-13: PCIe Power Pinouts**

### 3.2.13 SATA 3Gb/s Drive Connector

- CN Label:** SATA34, SATA56
- CN Type:** 16-pin SATA connector
- CN Location:** See **Figure 3-14**
- CN Pinouts:** See **Table 3-14**

The SATA drive connectors can be connected to SATA drives.


**Figure 3-14: SATA 3Gb/s Drive Connector Location**

Pin	Description	Pin	Description
1	GND	9	SATATXP3/5
2	SATATXP2/4	10	SATATXN3/5
3	SATATXN2/4	11	GND
4	GND	12	SATARXN3/5
5	SATARXN2/4	13	SATARXP3/5
6	SATARXP2/4	14	GND
7	GND	15	GND
8	GND	16	GND


**Table 3-14: SATA 3Gb/s Drive Connector Pinouts**

### 3.2.14 SATA 6Gb/s Drive Connector

- CN Label:** SATA1, SATA2
- CN Type:** 7-pin SATA drive connectors
- CN Location:** See **Figure 3-15**
- CN Pinouts:** See **Table 3-15**

## IMB-Q670 Micro-ATX Motherboard

The SATA drive connectors can be connected to SATA drives.



**Figure 3-15: SATA 6Gb/s Drive Connector Location**


Pin	Description
1	GND
2	SATATXP
3	SATATXN
4	GND
5	SATARXN
6	SATARXP
7	GND

**Table 3-15: SATA 6Gb/s Drive Connector Pinouts**

### 3.2.15 Serial Port Connector, RS-422/485

- CN Label:** COM2
- CN Type:** 4-pin box header (1x4)
- CN Location:** See **Figure 3-16**
- CN Pinouts:** See **Table 3-16**

Used for RS-422/485 communications.



**Figure 3-16: Serial Port Connector Location**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	RXD485#	3	RXD485+
2	RXD485+	4	RXD485#


**Table 3-16: Serial Port Connector Pinouts**

### 3.2.16 Serial Port Connectors, RS-232

- CN Label:** COM3-6, COM7-10
- CN Type:** 40-pin box header (2x20)
- CN Location:** See **Figure 3-17**
- CN Pinouts:** See **Table 3-17**

Each of these connectors provides RS-232 connections.

# IMB-Q670 Micro-ATX Motherboard



**Figure 3-17: Serial Port Connector Location**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	NDCD3/7#	2	NDSR3/7#
3	NRXD3/7	4	NRTS3/7#
5	NTXD3/7	6	NCTS3/7#
7	NDTR3/7#	8	NR13/7#
9	GND	10	GND
11	NDCD4/8#	12	NDSR4/8#
13	NRXD4/8	14	NRTS4/8#
15	NTXD4/8	16	NCTS4/8#
17	NDTR4/8#	18	NR14/8#
19	GND	20	GND
21	NDCD5/9#	22	NDSR5/9#
23	NRXD5/9	24	NRTS5/9#
25	NTXD5/9#	26	NCTS5/9#
27	NDTR5/9#	28	NR15/9#
29	GND	30	GND
31	NDCD6/10	32	NDSR6/10#
33	NRXD6/10#	34	NRTS6/10#
35	NTXD6/10	36	NCTS6/10#
37	NDTR6/10#	38	NR16/10#


PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
39	GND	40	GND

**Table 3-17: Serial Port Connector Pinouts**

### 3.2.17 SMBus Connector

- CN Label:** SMBUS\_1
- CN Type:** 4-pin wafer
- CN Location:** See **Figure 3-18**
- CN Pinouts:** See **Table 3-18**

The SMBus (System Management Bus) connector provides low-speed system management communications.


**Figure 3-18: SMBus Connector Location**

PIN	DESCRIPTION
1	5V
2	SMBCLK_RESUME
3	SMBDATA_RESUME
4	GND

## IMB-Q670 Micro-ATX Motherboard

PIN	DESCRIPTION
-----	-------------

Table 3-18: SMBus Connector Pinouts

### 3.2.18 SPDIF Connector

<b>CN Label:</b>	<b>SPDIF</b>
<b>CN Type:</b>	5-pin header
<b>CN Location:</b>	See <b>Figure 3-19</b>
<b>CN Pinouts:</b>	See <b>Table 3-19</b>

Use the SPDIF connector to connect digital audio devices to the system.




Figure 3-19: SPDIF Connector Location


PIN	DESCRIPTION
1	+5V
2	NC
3	SPDIFOUT
4	GND
5	SPDIFIN

Table 3-19: SPDIF Connector Pinouts

### 3.2.19 SPI Connector

- CN Label:** SPI
- CN Type:** 8-pin header
- CN Location:** See **Figure 3-20**
- CN Pinouts:** See **Table 3-20**

The SPI connector is used to flash the BIOS.



**Figure 3-20: SPI Connector Location**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	SPI_VCC	2	GND
3	SPI_CS	4	SPI_CLK
5	SPI_SO	6	SPI_SI
7	NC	8	NC

**Table 3-20: SPI Connector Pinouts**


### 3.2.20 System Fan Connector

- CN Label:** SYS\_FAN1, SYS\_FAN2
- CN Type:** 3-pin wafer
- CN Location:** See **Figure 3-21**
- CN Pinouts:** See **Table 3-21**



## IMB-Q670 Micro-ATX Motherboard

The fan connector attaches to a cooling fan.



**Figure 3-21: System Fan Connector Location**


PIN NO.	DESCRIPTION
1	NC
2	+12 V
3	GND

**Table 3-21: System Fan Connector Pinouts**

### 3.2.21 TPM Connector

- CN Label:** TPM
- CN Type:** 20-pin header
- CN Location:** See **Figure 3-22**
- CN Pinouts:** See **Table 3-22**

The TPM connector connects to a TPM module.



**Figure 3-22: TPM Connector Location**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	TPMCLK	2	GND
3	LFRAME-	4	NC
5	PCIRST4-	6	+5V
7	LAD3	8	LAD2
9	LAD0	10	LAD1
11	GND	12	GND
13	SMBCLK_MAIN	14	SMBDATA_MAIN
15	+3.3V	16	SERIRQ
17	GND	18	CLKRUN-
19	+3.3V	20	LDRQ0-

**Table 3-22: TPM Connector Pinouts**

### 3.2.22 USB Connectors

**CN Label:** USB1, USB2, USB3, USB4


**CN Type:** 8-pin header (2x4)

**CN Location:** See Figure 3-23

**CN Pinouts:** See Table 3-23

## IMB-Q670 Micro-ATX Motherboard

The USB connectors connect to USB devices. Each pin header provides two USB ports.



**Figure 3-23: USB Connector Pinout Locations**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	+5V	2	GND
3	DATA-	4	DATA+
5	DATA+	6	DATA-
7	GND	8	+5V

**Table 3-23: USB Port Connector Pinouts**

### 3.3 External Peripheral Interface Connector Panel

The figure below shows the external peripheral interface connector (EPIC) panel. The EPIC panel consists of the following:




Figure 3-24: External Peripheral Interface Connector

#### 3.3.1 Audio Connector

CN Label:	AUDIO_JACK
CN Type:	Audio jack
CN Location:	See Figure 3-24

The audio jacks connect to external audio devices.

- **Line In port (Light Blue):** Connects a CD-ROM, DVD player, or other audio devices.
- **Line Out port (Lime):** Connects to a headphone or a speaker. With multi-channel configurations, this port can also connect to front speakers.
- **Microphone (Pink):** Connects a microphone.

## IMB-Q670 Micro-ATX Motherboard




Figure 3-25: Audio Connector

### 3.3.2 Keyboard/Mouse Connector

<b>CN Label:</b>	<b>KBMS</b>
<b>CN Type:</b>	Dual PS/2
<b>CN Location:</b>	See <b>Figure 3-24</b>
<b>CN Pinouts:</b>	See <b>Table 3-24</b>

The PS/2 ports are for connecting a PS/2 mouse and a PS/2 keyboard.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	KB_DATA	8	NC
2	NC	9	GND
3	GND	10	KBPWR
4	KBPWR	11	MS_CLK
5	KB_CLK	12	NC
6	NC	13	KB_GND
7	MS_DATA	14	KB_GND

Table 3-24: PS/2 Connector Pinouts

### 3.3.3 Ethernet and USB Connector

<b>CN Label:</b>	<b>LAN1_USB, LAN2_USB</b>
------------------	---------------------------

- CN Type:** RJ-45, USB
- CN Location:** See **Figure 3-24**
- CN Pinouts:** See **Table 3-25** and **Table 3-26**

The LAN connector connects to a local network.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	1.9V_LAN1/ 1.05V_LAN2	2	TRD1/2P0
3	TRD1/2N0	4	TRD1/2P1
5	TRD1/2N1	6	TRD1/2P2
7	TRD1/2N2	8	TRD1/2P3
9	TRD1/2N3	10	GND
11	L1/2_LINK_100#	12	L1/2_LINK_1000#
13	L1/2_LINK_ACT#	14	3.3V_LAN/LAN1

**Table 3-25: LAN Pinouts**

The USB connector can be connected to a USB device.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	USBPWR1/2	2	USBDATA0/8-
3	USBDATA0/8+	4	GND
5	USBPWR1/2	6	USBDATA1/9-
7	USBDATA1/9+	8	GND

**Table 3-26: USB Port Pinouts**

### 3.3.4 HDMI Port Connector

- CN Label:** HDMI
- CN Type:** HDMI connector
- CN Location:** See **Figure 3-24**
- CN Pinouts:** See **Table 3-27**

## IMB-Q670 Micro-ATX Motherboard

The HDMI port connects to an HDMI device.

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	HDMI_TMDS_C_DATA2	13	NC
2	GND	14	NC
3	HDMI_TMDS_C_DATA2#	15	HDMI_DDC_SCLK
4	HDMI_TMDS_C_DATA1	16	HDMI_DDC_SDATA
5	GND	17	GND
6	HDMI_TMDS_C_DATA1#	18	+5V
7	HDMI_TMDS_C_DATA0	19	HDMI_HPD
8	GND	20	GND
9	HDMI_TMDS_C_DATA0#	21	GND
10	HDMI_TMDS_C_CLK	22	GND
11	GND	23	GND
12	HDMI_TMDS_C_CLK#		

**Table 3-27: HDMI Connector Pinouts**


### 3.3.5 Serial Port Connectors (COM1)

- CN Label:** COM1
- CN Type:** DB-9 connector
- CN Location:** See **Figure 3-24**
- CN Pinouts:** See **Table 3-28**

The serial port connects to a RS-232 serial communications device.

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	NDCD	6	NDSR
2	NRXD	7	NRTS
3	NTXD	8	NCTS
4	NDTR	9	NRI
5	GND		

**Table 3-28: Serial Port Connector Pinouts**


**Figure 3-26: Serial Port Connector Pinouts**

### 3.3.6 VGA and DVI Connector

- CN Label:** DVI+CRT
- CN Type:** 15-pin Female, 24-pin header
- CN Location:** See **Figure 3-24**
- CN Pinouts:** See **Table 3-29** and **Table 3-30**


The VGA connector connects to a monitor that accepts a standard VGA input.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	CRT_RED	2	CRT_GREEN
3	CRT_BLUE	4	NC
5	GND	6	GND
7	GND	8	GND
9	+5V CRT	10	CRT_PLUG#
11	NC	12	CRT_DDC_DATA
13	CRT_HSYNC	14	CRT_VSYNC
15	CRT_DDC_CLK		

**Table 3-29: VGA Connector Pinouts**



## IMB-Q670 Micro-ATX Motherboard



**Figure 3-27: VGA Connector**

The DVI connector connects to a monitor that supports DVI video input.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	DVI_TMDS_C_DATA2#	2	DVI_TMDS_C_DATA2
3	GND	4	NC
5	NC	6	DVI_DDC_SCLK
7	DVI_DDC_SDATA	8	NC
9	DVI_TMDS_C_DATA1#	10	DVI_TMDS_C_DATA1
11	GND	12	NC
13	NV	14	+5V_DVI
15	GND	16	DVI_HPD
17	DVI_TMDS_C_DATA0#	18	DVI_TMDS_C_DATA0
19	GND	20	NC
21	NC	22	GND
23	DVI_TMDS_C_CLK	24	DVI_TMDS_C_CLK#

**Table 3-30: DVI Connector Pinouts**

Chapter

4

# Installation

---

## IMB-Q670 Micro-ATX Motherboard

### 4.1 Anti-static Precautions

---



#### WARNING:

Failure to take ESD precautions during the installation of the IMB-Q670 may result in permanent damage to the IMB-Q670 and severe injury to the user.

---

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the IMB-Q670. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the IMB-Q670 or any other electrical component is handled, the following anti-static precautions are strictly adhered to.

- **Wear an anti-static wristband:** - Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- **Self-grounding:** - Before handling the board touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- **Use an anti-static pad:** When configuring the IMB-Q670, place it on an anti-static pad. This reduces the possibility of ESD damaging the IMB-Q670.
- **Only handle the edges of the PCB:-:** When handling the PCB, hold the PCB by the edges.

### 4.2 Installation Considerations

---



#### NOTE:

The following installation notices and installation considerations should be read and understood before installation. All installation notices must be strictly adhered to. Failing to adhere to these precautions may lead to severe damage and injury to the person performing the installation.

---

**WARNING:**

The installation instructions described in this manual should be carefully followed in order to prevent damage to the components and injury to the user.

Before and during the installation please **DO** the following:

- Read the user manual:
  - The user manual provides a complete description of the IMB-Q670 installation instructions and configuration options.
- Wear an electrostatic discharge cuff (ESD):
  - Electronic components are easily damaged by ESD. Wearing an ESD cuff removes ESD from the body and helps prevent ESD damage.
- Place the IMB-Q670 on an antistatic pad:
  - When installing or configuring the motherboard, place it on an antistatic pad. This helps to prevent potential ESD damage.
- Turn all power to the IMB-Q670 off:
  - When working with the IMB-Q670, make sure that it is disconnected from all power supplies and that no electricity is being fed into the system.

Before and during the installation of the IMB-Q670 **DO NOT**:

- Remove any of the stickers on the PCB board. These stickers are required for warranty validation.
- Use the product before verifying all the cables and power connectors are properly connected.
- Allow screws to come in contact with the PCB circuit, connector pins, or its components.

## IMB-Q670 Micro-ATX Motherboard

### 4.2.1 Socket LGA1155 CPU Installation



#### NOTE:

To enable Hyper-Threading, the CPU and chipset must both support it.

---




#### WARNING:

CPUs are expensive and sensitive components. When installing the CPU please be careful not to damage it in anyway. Make sure the CPU is installed properly and ensure the correct cooling kit is properly installed.

---

The LGA1155 socket is shown in **Figure 4-1**.



**Figure 4-1: Intel LGA1155 Socket**

To install the CPU, follow the steps below.

---




#### WARNING:

DO NOT touch the pins at the bottom of the CPU. When handling the CPU, only hold it on the sides.


---

**Step 1:** Remove the protective cover. The black protective cover can be removed by pulling up on the tab labeled "Remove". See **Figure 4-2**.



**Figure 4-2: Remove Protective Cover**

**Step 2:** Open the socket. Disengage the load lever by pressing the lever down and slightly outward to clear the retention tab. Fully open the lever, then open the load plate. See **Figure 4-3**.




**Figure 4-3: CPU Socket Load Plate**

**Step 3:** Inspect the CPU socket. Make sure there are no bent pins and make sure the socket contacts are free of foreign material. If any debris is found, remove it with compressed air.

## IMB-Q670 Micro-ATX Motherboard

- Step 4:** Orientate the CPU properly. The contact array should be facing the CPU socket.
- Step 5:** Correctly position the CPU. Match the Pin 1 mark with the cut edge on the CPU socket.
- Step 6:** Align the CPU pins. Locate pin 1 and the two orientation notches on the CPU. Carefully match the two orientation notches on the CPU with the socket alignment keys.
- Step 7:** Insert the CPU. Gently insert the CPU into the socket. If the CPU pins are properly aligned, the CPU should slide into the CPU socket smoothly. See **Figure 4-4**.



**Figure 4-4: Insert the Socket LGA1155 CPU**

- Step 8:** Close the CPU socket. Close the load plate and engage the load lever by pushing it back to its original position. There will be some resistance, but will not require extreme pressure.
- Step 9:** Connect the 12 V power to the board. Connect the 12 V power from the power supply to the board.

## 4.2.2 Socket LGA1155 Cooling Kit Installation

---



### WARNING:

DO NOT use the original Intel® heat sink and fan. A proprietary one is recommended.

---



Figure 4-5: Cooling Kits (CF-1156A-RS and CF-1156B-RS)

The cooling kit can be bought from IEI. The cooling kit has a heatsink and fan.

---



### WARNING:

Do not wipe off (accidentally or otherwise) the pre-sprayed layer of thermal paste on the bottom of the heat sink. The thermal paste between the CPU and the heat sink is important for optimum heat dissipation.

---

To install the cooling kit, follow the instructions below.


**Step 1:** Place the cooling kit onto the socket LGA1155 CPU. Make sure the CPU cable can be properly routed when the cooling kit is installed.

**Step 2:** Properly align the cooling kit. Make sure the four spring screw fasteners can pass through the pre-drilled holes on the PCB.



## IMB-Q670 Micro-ATX Motherboard

- Step 3: Mount the cooling kit.** Gently place the cooling kit on top of the CPU. Make sure the four threaded screws on the corners of the cooling kit properly pass through the predrilled holes on the bottom of the PCB.
- Step 4: Secure the cooling kit.** From the solder side of the PCB, align the support bracket to the screw threads on heat sink that were inserted through the PCB holes. (See **Figure 4-6**)




**Figure 4-6: Securing the Heat sink to the IMB-Q670**

- Step 5: Tighten the screws.** Use a screwdriver to tighten the four screws. Tighten each nut a few turns at a time and do not over-tighten the screws.
- Step 6: Connect the fan cable.** Connect the cooling kit fan cable to the fan connector on the IMB-Q670. Carefully route the cable and avoid heat generating chips and fan blades.

### 4.2.3 DIMM Installation

To install a DIMM, please follow the steps below and refer to **Figure 4-7**.



**Figure 4-7: DIMM Installation**


- Step 1: Open the DIMM socket handles.** Open the two handles outwards as far as they can. See **Figure 4-7**.
- Step 2: Align the DIMM with the socket.** Align the DIMM so the notch on the memory lines up with the notch on the memory socket. See **Figure 4-7**.
- Step 3: Insert the DIMM.** Once aligned, press down until the DIMM is properly seated. Clip the two handles into place. See **Figure 4-7**.
- Step 4: Removing a DIMM.** To remove a DIMM, push both handles outward. The memory module is ejected by a mechanism in the socket.

## 4.3 Jumper Settings



### NOTE:

A jumper is a metal bridge used to close an electrical circuit. It consists of two or three metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To CLOSE/SHORT a jumper means connecting the pins of the jumper with the plastic clip and to OPEN a jumper means removing the plastic clip from a jumper.



The hardware jumpers must be set before installation. Jumpers are shown in **Table 4-1**.

Description	Label	Type
AT/ATX Auto power setting jumper (by active hardware)	JATX_AT1	2-pin header
Clear CMOS jumper	J_CMOS2	3-pin header
ME Debug connector	J_FLASH1	3-pin header
USB power select jumper	USB_PWR1	3-pin header
Wake-on LAN	WOL_SEL1	3-pin header

**Table 4-1: Jumpers**


### 4.3.1 AT/ATX Power Mode Jumper (by active hardware)

- Jumper Label:** JATX\_AT1
- Jumper Type:** 2-pin header
- Jumper Settings:** See **Table 4-2**
- Jumper Location:** See **Figure 4-8**

The AT/ATX Power Select jumper specifies the systems power mode as AT or ATX.

Setting	Description
Open	AT power (Default)
Closed	ATX power

**Table 4-2: AT/ATX Power Mode Jumper Settings**



**Figure 4-8: AT/ATX Power Mode Jumper Location**

### 4.3.2 Clear CMOS Jumper

- Jumper Label:** J\_CMOS2
- Jumper Type:** 3-pin header
- Jumper Settings:** See Table 4-3
- Jumper Location:** See Figure 4-9

To reset the BIOS, move the jumper to the "Clear BIOS" position for 3 seconds or more, and then move back to the default position.

Setting	Description
1-2	Normal
2-3	Clear BIOS

**Table 4-3: Clear BIOS Jumper Settings**

## IMB-Q670 Micro-ATX Motherboard




Figure 4-9: Clear BIOS Jumper Location

### 4.3.3 ME Debug Connector

<b>CN Label:</b>	<b>J_FLASH1</b>
<b>CN Type:</b>	3-pin header
<b>CN Location:</b>	See <b>Figure 3-5</b>
<b>CN Pinouts:</b>	See <b>Table 3-6</b>

The ME Debug connector allows ME firmware overwrite protection.




Figure 4-10: ME Debug Connector Location

PIN NO.	DESCRIPTION
Short 1-2	Overwrite disable
Short 2-3	Overwrite enable


**Table 4-4: ME Debug Connector Pinouts**

#### 4.3.4 USB Power Select Jumper

- Jumper Label:** USB\_PWR1
- Jumper Type:** 3-pin header
- Jumper Settings:** See Table 4-5
- Jumper Location:** See Figure 4-11

The USB power connector allows the user to select the USB power setting.

Setting	Description
Short 1-2	5V
Short 2-3	5VSB

**Table 4-5: USB Power Select Jumper Settings**

**Figure 4-11: USB Power Select Jumper Location**

#### 4.3.5 Wake-on LAN Jumper

- CN Label:** WOL\_SEL1

## IMB-Q670 Micro-ATX Motherboard

- CN Type:** 3-pin header
- CN Location:** See **Figure 4-12**
- CN Pinouts:** See **Table 4-6**

The Wake-on LAN connector allows the user to enable or disable the Wake-on LAN (WOL) function.



**Figure 4-12: Wake-on LAN Connector Pinout Locations**

PIN NO.	DESCRIPTION
Short 1-2	Wakeup Enable (Default)
Short 2-3	Disable

**Table 4-6: Wake-on LAN Connector Pinouts**

## 4.4 Internal Peripheral Device Connections


This section outlines the installation of peripheral devices to the onboard connectors.

### 4.4.1 SATA Drive Connection

The IMB-Q670 is shipped with four SATA drive cables. To connect the SATA drives to the connectors, please follow the steps below.

**Step 1:** **Locate the connectors.** The locations of the SATA drive connectors are shown in **Chapter 3**.

**Step 2:** **Insert the cable connector.** Press the clip on the connector at the end of the SATA cable and insert the cable connector into the on-board SATA drive connector. See **Figure 4-13**.



**Figure 4-13: SATA Drive Cable Connection**

**Step 3:** **Connect the cable to the SATA disk.** Connect the connector on the other end of the cable to the connector at the back of the SATA drive. See **Figure 4-14**.

**Step 4:** **Connect the SATA power cable (optional).** Connect the SATA power connector to the back of the SATA drive. See **Figure 4-14**.



## IMB-Q670 Micro-ATX Motherboard



**Figure 4-14: SATA Power Drive Connection**

The SATA power cable can be bought from IEI. See Optional Items in Section 2.4.


## 4.5 External Peripheral Interface Connection

This section describes connecting devices to the external connectors on the IMB-Q670.

### 4.5.1 Audio Connector

The audio jacks on the external audio connector enable the IMB-Q670 to be connected to a stereo sound setup. Each jack supports both input and output. When connecting a device, the High Definition Audio utility will automatically detect input or output. The lime green (top) audio jack does not support input from a microphone. To install the audio devices, follow the steps below.

- Step 1: Identify the audio plugs.** The plugs on your home theater system or speakers may not match the colors on the rear panel.
- Step 2: Plug the audio plugs into the audio jacks.** Plug the audio plugs into the audio jacks. If the plugs on your speakers are different, an adapter will need to be used to plug them into the audio jacks.



**Figure 4-15: Audio Connector**

**Step 3: Check audio clarity.** Check that the sound is coming through the right speakers by adjusting the balance front to rear and left to right.

#### 4.5.2 LAN Connection

There are two external RJ-45 LAN connectors. The RJ-45 connectors enable connection to an external network. To connect a LAN cable with an RJ-45 connector, please follow the instructions below.

**Step 4: Locate the RJ-45 connectors.** The locations of the USB connectors are shown in **Chapter 4**.

**Step 5: Align the connectors.** Align the RJ-45 connector on the LAN cable with one of the RJ-45 connectors on the IMB-Q670. See **Figure 4-16**.

## IMB-Q670 Micro-ATX Motherboard




Figure 4-16: LAN Connection

**Step 6:** Insert the LAN cable RJ-45 connector. Once aligned, gently insert the LAN cable RJ-45 connector into the on-board RJ-45 connector.

### 4.5.3 Parallel Device Connection

The IMB-Q670 has a single female DB-25 connector on the external peripheral interface panel for parallel devices. Follow the steps below to connect a parallel device to the IMB-Q670.

**Step 1:** Locate the DB-25 connector. The location of the DB-25 connector is shown in Chapter 3.

**Step 2:** Insert the DB-25 connector. Insert the DB-25 connector of a parallel device into the DB-25 connector on the external peripheral interface. See Figure 4-17.




Figure 4-17: Parallel Device Connector

**Step 3:** **Secure the connector.** Secure the DB-25 connector to the external interface by tightening the two retention screws on either side of the connector.

#### 4.5.4 PS/2 Keyboard and Mouse Connection

The IMB-Q670 has a dual PS/2 connector on the external peripheral interface panel. The dual PS/2 connector is used to connect to a keyboard and mouse to the system. Follow the steps below to connect a keyboard and mouse to the IMB-Q670.

**Step 1:** **Locate the dual PS/2 connector.** The location of the dual PS/2 connector is shown in **Chapter 3**.

**Step 2:** **Insert the keyboard/mouse connector.** Insert a PS/2 keyboard or mouse connector into the appropriate PS/2 connector on the external peripheral interface connector. See **Figure 4-18**.

## IMB-Q670 Micro-ATX Motherboard





Figure 4-18: PS/2 Keyboard/Mouse Connector

### 4.5.5 Serial Device Connection

The IMB-Q670 has a single female DB-9 connector on the external peripheral interface panel for a serial device. Follow the steps below to connect a serial device to the IMB-Q670.

**Step 1:** **Locate the DB-9 connector.** The location of the DB-9 connector is shown in Chapter 3.

**Step 2:** **Insert the serial connector.** Insert the DB-9 connector of a serial device into the DB-9 connector on the external peripheral interface. See **Figure 4-19**.



**Figure 4-19: Serial Device Connector**

**Step 3: Secure the connector.** Secure the serial device connector to the external interface by tightening the two retention screws on either side of the connector.

#### 4.5.6 USB Connection (Dual Connector)

The external USB Series "A" receptacle connectors provide easier and quicker access to external USB devices. Follow the steps below to connect USB devices to the IMB-Q670.

**Step 1: Locate the USB Series "A" receptacle connectors.** The location of the USB Series "A" receptacle connectors are shown in **Chapter 3**.

**Step 2: Insert a USB Series "A" plug.** Insert the USB Series "A" plug of a device into the USB Series "A" receptacle on the external peripheral interface. See **Figure 4-20**.

## IMB-Q670 Micro-ATX Motherboard




Figure 4-20: USB Connector

### 4.5.7 VGA Monitor Connection

The IMB-Q670 has a single female DB-15 connector on the external peripheral interface panel. The DB-15 connector is connected to a CRT or VGA monitor. To connect a monitor to the IMB-Q670, please follow the instructions below.

- Step 1: Locate the female DB-15 connector.** The location of the female DB-15 connector is shown in **Chapter 3**.
- Step 2: Align the VGA connector.** Align the male DB-15 connector on the VGA screen cable with the female DB-15 connector on the external peripheral interface.
- Step 3: Insert the VGA connector** Once the connectors are properly aligned with the insert the male connector from the VGA screen into the female connector on the IMB-Q670. See **Figure 4-21**.




Figure 4-21: VGA Connector

**Step 4:** **Secure the connector.** Secure the DB-15 VGA connector from the VGA monitor to the external interface by tightening the two retention screws on either side of the connector.

## 4.6 Software Installation

All the drivers for the IMB-Q670 are on the CD that came with the system. To install the drivers, please follow the steps below.

**Step 1:** Insert the CD into a CD drive connected to the system.




### NOTE:

If the installation program doesn't start automatically:  
Click "Start->My Computer->CD Drive->autorun.exe"

**Step 2:** The driver main menu appears (**Figure 4-22**).




## IMB-Q670 Micro-ATX Motherboard



**Figure 4-22: Introduction Screen**

**Step 3:** Click IMB-Q670.

**Step 4:** A new screen with a list of available drivers appears (**Figure 4-23**).



**Figure 4-23: Available Drivers**

**Step 5:** Install all of the necessary drivers in this menu.

Chapter

5

# BIOS

---

## 5.1 Introduction

The BIOS is programmed onto the BIOS chip. The BIOS setup program allows changes to certain system settings. This chapter outlines the options that can be changed.

### 5.1.1 Starting Setup

The UEFI BIOS is activated when the computer is turned on. The setup program can be activated in one of two ways.

1. Press the **F2** or **DELETE** key as soon as the system is turned on or
2. Press the **F2** or **DELETE** key when the “**Press F2 to enter SETUP**” message appears on the screen.

If the message disappears before the **F2** or **DELETE** key is pressed, restart the computer and try again.

### 5.1.2 Using Setup

Use the arrow keys to highlight items, press **ENTER** to select, use the PageUp and PageDown keys to change entries, press **F1** for help and press **Esc** to quit. Navigation keys are shown in.

Key	Function
Up arrow	Move to previous item
Down arrow	Move to next item
Left arrow	Move to the item on the left hand side
Right arrow	Move to the item on the right hand side
+	Increase the numeric value or make changes
-	Decrease the numeric value or make changes
Page Up key	Increase the numeric value or make changes
Page Dn key	Decrease the numeric value or make changes

## IMB-Q670 Micro-ATX Motherboard

Key	Function
Esc key	Main Menu – Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
F1 key	General help, only for Status Page Setup Menu and Option Page Setup Menu
F9	Load optimized defaults
F10 key	Save changes and Exit BIOS

**Table 5-1: BIOS Navigation Keys**

### 5.1.3 Getting Help

When **F1** is pressed a small help window describing the appropriate keys to use and the possible selections for the highlighted item appears. To exit the Help Window press **Esc** or the **F1** key again.

### 5.1.4 Unable to Reboot after Configuration Changes

If the computer cannot boot after changes to the system configuration is made, CMOS defaults. Use the jumper described in Chapter 4.

### 5.1.5 BIOS Menu Bar


The **menu bar** on top of the BIOS screen has the following main items:

- Main – Changes the basic system configuration.
- Advanced – Changes the advanced system settings.
- Chipset – Changes the chipset settings.
- Boot – Changes the system boot configuration.
- Security – Sets User and Supervisor Passwords.
- Save & Exit – Selects exit options and loads default settings

The following sections completely describe the configuration options found in the menu items at the top of the BIOS screen and listed above.

## 5.2 Main

The **Main** BIOS menu (**BIOS Menu 1**) appears when the **BIOS Setup** program is entered. The **Main** menu gives an overview of the basic system information.



### BIOS Menu 1: Main

#### → System Overview

The **BIOS Information** lists a brief summary of the BIOS. The fields in **BIOS Information** cannot be changed. The items shown in the system overview include:

- **BIOS Vendor:** Installed BIOS vendor
- **Core Version:** Current BIOS version
- **Project Version:** the board version
- **Build Date:** Date the current BIOS version was made

#### → Memory Information

The **Memory Information** lists a brief summary of the on-board memory. The fields in **Memory Information** cannot be changed.

- **Total Memory:** Displays the auto-detected system memory size and type.

## IMB-Q670 Micro-ATX Motherboard

The System Overview field also has two user configurable fields:

→ **System Date [xx/xx/xx]**

Use the **System Date** option to set the system date. Manually enter the day, month and year.

→ **System Time [xx:xx:xx]**

Use the **System Time** option to set the system time. Manually enter the hours, minutes and seconds.

### 5.3 Advanced


Use the **Advanced** menu (**BIOS Menu 2**) to configure the CPU and peripheral devices through the following sub-menus:




#### **WARNING!**

Setting the wrong values in the sections below may cause the system to malfunction. Make sure that the settings made are compatible with the hardware.

---


**BIOS Menu 2: Advanced**
**5.3.1 ACPI Settings**

The **ACPI Settings** menu (**BIOS Menu 3**) configures the Advanced Configuration and Power Interface (ACPI) options.


**BIOS Menu 3: ACPI Configuration**



## IMB-Q670 Micro-ATX Motherboard

### → ACPI Sleep State [S1 (CPU Stop Clock)]

Use the **ACPI Sleep State** option to specify the sleep state the system enters when it is not being used.


#### → Suspend Disabled

→ **S1 (CPU Stop Clock)** **DEFAULT** The system enters S1(POS) sleep state. The system appears off. The CPU is stopped; RAM is refreshed; the system is running in a low power mode.

→ **S3 (Suspend to RAM)** The caches are flushed and the CPU is powered off. Power to the RAM is maintained. The computer returns slower to a working state, but more power is saved.

## 5.3.2 Trusted Computing

Use the **Trusted Computing** menu (**BIOS Menu 4**) to configure settings related to the Trusted Computing Group (TCG) Trusted Platform Module (TPM).



**BIOS Menu 4: TPM Configuration**



## IMB-Q670 Micro-ATX Motherboard

### 5.3.3.1 CPU Information

Use the **CPU Information** submenu (**BIOS Menu 6**) to view detailed CPU specifications and configure the CPU.

```

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.
  Advanced
CPU Configuration
Genuine Intel(R) CPU 0 @ 2.60GHz
CPU Signature                206a5
Microcode Patch              7
Max CPU Speed                2600 MHz
Min CPU Speed                1600 MHz
Processor Cores              2
Intel HT Technology          Not Supported
Intel VT-x Technology        Supported
Intel SMX Technology         Not supported

L1 Data Cache                32 kB x 2
L1 Code Cache                32 kB x 2
L2 Cache                     256 kB x 2
L3 Cache                     2048 kB

-----
<=>: Select Screen
↑ ↓: Select Item
Enter>Select
+ - Change Opt.
F1  General Help
F2  Previous Values
F3  Optimized Defaults
F4  Save & Exit
ESC Exit

Version 2.11.1210. Copyright (C) 2011 American Megatrends, Inc.

```

#### BIOS Menu 6: CPU Configuration

The CPU Configuration menu (**BIOS Menu 6**) lists the following CPU details:

- Processor Type: Lists the brand name of the CPU being used
- CPU Signature: Lists the CPU signature value.
- Microcode Patch: Lists the microcode patch being used.
- Max CPU Speed: Lists the maximum CPU processing speed.
- Min CPU Speed: Lists the minimum CPU processing speed.
- Processor Cores: Lists the number of the processor core
- Intel HT Technology: Indicates if Intel HT Technology is supported by the CPU.
- Intel VT-x Technology: Indicates if Intel VT-x Technology is supported by the CPU.
- Intel SMX Technology: Indicates if Intel SMX Technology is supported by the CPU.
- L1 Data Cache: Lists the amount of data storage space on the L1 cache.
- L1 Code Cache: Lists the amount of code storage space on the L1 cache.

- L2 Cache: Lists the amount of storage space on the L2 cache.
- L3 Cache: Lists the amount of storage space on the L3 cache.

### 5.3.4 SATA Configuration

Use the **SATA Configuration** menu (**BIOS Menu 7**) to change and/or set the configuration of the SATA devices installed in the system.

```

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.
  Advanced
SATA Configuration                                     (1) IDE Mode. (2) AHCI
                                                       Mode. (3) RAID Mode.
SATA Mode                                             [AHCI Mode]
SATA Port0                                           Not Present
  Staggered Spin-up                                  [Disabled]
  External SATA Port                                 [Disabled]
  Hot Plug                                           [Disabled]
SATA Port1                                           Not Present
  Staggered Spin-up                                  [Disabled]
  External SATA Port                                 [Disabled]
  Hot Plug                                           [Disabled]
SATA Port2                                           Not Present
  Staggered Spin-up                                  [Disabled]
  External SATA Port                                 [Disabled]
  Hot Plug                                           [Disabled]
SATA Port3                                           Not Present
  Staggered Spin-up                                  [Disabled]
  External SATA Port                                 [Disabled]
  Hot Plug                                           [Disabled]
SATA Port4                                           Not Present
  Staggered Spin-up                                  [Disabled]
  External SATA Port                                 [Disabled]
  Hot Plug                                           [Disabled]
SATA Port5                                           Not Present
  Staggered Spin-up                                  [Disabled]
  External SATA Port                                 [Disabled]
  Hot Plug                                           [Disabled]
-----
<->: Select Screen
↑ ↓: Select Item
EnterSelect
+ - Change Opt.
F1 General Help
F2 Previous Values
F3 Optimized Defaults
F4 Save & Exit
ESC Exit
Version 2.11.1210. Copyright (C) 2011 American Megatrends, Inc.
  
```

**BIOS Menu 7: SATA Configuration**

## IMB-Q670 Micro-ATX Motherboard

### → SATA Mode [AHCI Mode]

Use the **SATA Mode** option to configure SATA devices as normal IDE devices.

- **Disable**                      Disables SATA devices.
- **IDE Mode**                      Configures SATA devices as normal IDE device.
- **AHCI Mode**    **DEFAULT**    Configures SATA devices as AHCI device.
- **RAID Mode**                      Configures SATA devices as RAID device.

### → Staggered Spin-up [Disabled]

Staggered Spin-up allows the system to power up one drive at a time to prevent excess power consumption. Use the **Staggered Spin-up** option to enable or disable the staggered spin-up function.

- **Disabled**            **DEFAULT**    Disables staggered spin-up.
- **Enabled**                      Enables staggered spin-up.

### → External SATA Port

Use the **External SATA Port** option to enable or disable the external SATA port.

- **Disabled**            **DEFAULT**    Disables the external SATA port.
- **Enabled**                      Enables the external SATA port.


### → Hot Plug

Use the **Hot Plug** option to enable or disable the hot plug function.


- **Disabled**            **DEFAULT**    Disables the hot plug function.
- **Enabled**                      Enables the hot plug function.

## 5.3.5 Intel TXT(LT) Configuration

Use the **Intel TXT(LT) Configuration** menu to configure Intel Trusted Execution Technology support.


**BIOS Menu 8: Intel TXT(LT) Configuration**
**5.3.6 USB Configuration**

Use the **USB Configuration** menu (**BIOS Menu 9**) to read USB configuration information and configure the USB settings.


**BIOS Menu 9: USB Configuration**
**→ USB Devices**

The **USB Devices Enabled** field lists the USB devices that are enabled on the system

## IMB-Q670 Micro-ATX Motherboard

### → USB Support [Enabled]

Use the **USB Support** option to enable or disable USB support on the system.

- **Disabled**                      USB support disabled
- **Enabled**      **DEFAULT**      USB support enabled


### → Legacy USB Support [Enabled]

Use the **Legacy USB Support** BIOS option to enable USB mouse and USB keyboard support. Normally if this option is not enabled, any attached USB mouse or USB keyboard does not become available until a USB compatible operating system is fully booted with all USB drivers loaded. When this option is enabled, any attached USB mouse or USB keyboard can control the system even when there is no USB driver loaded onto the system.

- **Disabled**                      Legacy USB support disabled
- **Enabled**      **DEFAULT**      Legacy USB support enabled
- **Auto**                              Legacy USB support disabled if no USB devices are connected

### 5.3.7 Super IO Configuration

Use the **Super IO Configuration** menu (**BIOS Menu 10**) to set or change the configurations for the FDD controllers, parallel ports and serial ports.



#### BIOS Menu 10: Super IO Configuration

##### → ERP Function [Disabled]

Use the **ERP Function** BIOS option to enable or reduce power consumption in the S5 state. When enabled, the system can only be powered-up using the power button.


- **Disabled**      **DEFAULT**      ERP Function support disabled
- **Enabled**                      ERP Function support enabled



## IMB-Q670 Micro-ATX Motherboard

### 5.3.7.1 Serial Port n Configuration

Use the **Serial Port n Configuration** menu (**BIOS Menu 11**) to configure the serial port n.



#### BIOS Menu 11: Serial Port n Configuration Menu

#### 5.3.7.1.1 Serial Port 1 Configuration

##### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled** Disable the serial port
- **Enabled** **DEFAULT** Enable the serial port

##### → Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.
- **IO=3F8h;**  
**IRQ=4** Serial Port I/O port address is 3F8h and the interrupt address is IRQ4

- **IO=3F8h;**  
**IRQ=3, 4**                      Serial Port I/O port address is 3F8h and the interrupt address is IRQ3,4
- **IO=2F8h;**  
**IRQ=3, 4**                      Serial Port I/O port address is 2F8h and the interrupt address is IRQ3,4
- **IO=2C0h;**  
**IRQ=3, 4**                      Serial Port I/O port address is 2C0h and the interrupt address is IRQ3, 4
- **IO=2C8h;**  
**IRQ=3, 4**                      Serial Port I/O port address is 2C8h and the interrupt address is IRQ3, 4

**5.3.7.1.2 Serial Port 2 Configuration**

→ **Serial Port [Enabled]**

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled**                      Disable the serial port
- **Enabled**                      **DEFAULT**                      Enable the serial port

→ **Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- **Auto**                      **DEFAULT**                      The serial port IO port address and interrupt address are automatically detected.
- **IO=2F8h;**  
**IRQ=3**                      Serial Port I/O port address is 2F8h and the interrupt address is IRQ3
- **IO=3F8h;**  
**IRQ=3, 4**                      Serial Port I/O port address is 3F8h and the interrupt address is IRQ3, 4
- **IO=2F8h;**  
**IRQ=3, 4**                      Serial Port I/O port address is 2F8h and the interrupt address is IRQ3, 4
- **IO=2C0h;**  
**IRQ=3, 4**                      Serial Port I/O port address is 2C0h and the interrupt address is IRQ3, 4

## IMB-Q670 Micro-ATX Motherboard

- **IO=2C8h;**  
**IRQ=3, 4**                      Serial Port I/O port address is 2C8h and the interrupt address is IRQ3, 4

### → **Device Mode [RS485]**

Use the **Device Mode** option to enable or disable the serial port.

- **Normal**                      Sets the serial port mode to normal.
- **RS485            DEFAULT**            Enables serial port RS485 support.

### 5.3.7.1.3 Serial Port 3 Configuration

#### → **Serial Port [Enabled]**

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled**                      Disable the serial port
- **Enabled            DEFAULT**            Enable the serial port

#### → **Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- **Auto                    DEFAULT**            The serial port IO port address and interrupt address are automatically detected.
- **IO=3E8h;**  
**IRQ=10**                      Serial Port I/O port address is 3E8h and the interrupt address is IRQ10
- **IO=3E8h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 3E8h and the interrupt address is IRQ10, 11
- **IO=2E8h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 2E8h and the interrupt address is IRQ10, 11
- **IO=2D0h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 2D0h and the interrupt address is IRQ10, 11

- **IO=2D8h;**  
**IRQ=10, 11**      Serial Port I/O port address is 2D8h and the interrupt address is IRQ10, 11

#### 5.3.7.1.4 Serial Port 4 Configuration

##### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled**      Disable the serial port
- **Enabled**      **DEFAULT**      Enable the serial port

##### → Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- **Auto**      **DEFAULT**      The serial port IO port address and interrupt address are automatically detected.
- **IO=2E8h;**  
**IRQ=10**      Serial Port I/O port address is 2E8h and the interrupt address is IRQ10
- **IO=3E8h;**  
**IRQ=10, 11**      Serial Port I/O port address is 3E8h and the interrupt address is IRQ10, 11
- **IO=2E8h;**  
**IRQ=10, 11**      Serial Port I/O port address is 2E8h and the interrupt address is IRQ10, 11
- **IO=2D0h;**  
**IRQ=10, 11**      Serial Port I/O port address is 2D0h and the interrupt address is IRQ10, 11
- **IO=2D8h;**  
**IRQ=10, 11**      Serial Port I/O port address is 2D8h and the interrupt address is IRQ10, 11

## IMB-Q670 Micro-ATX Motherboard

### 5.3.7.1.5 Serial Port 5 Configuration

#### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled**                      Disable the serial port
- **Enabled**      **DEFAULT**      Enable the serial port

#### → Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- **Auto**              **DEFAULT**      The serial port IO port address and interrupt address are automatically detected.
- **IO=2C0h;**  
**IRQ=10**                      Serial Port I/O port address is 2C0h and the interrupt address is IRQ10
- **IO=2C0h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 2C0h and the interrupt address is IRQ10, 11
- **IO=2C8h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 2C8h and the interrupt address is IRQ10, 11
- **IO=2D0h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 2D0h and the interrupt address is IRQ10, 11
- **IO=2D8h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 2D8h and the interrupt address is IRQ10, 11
- **IO=2E0h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 2E0h and the interrupt address is IRQ10, 11

### 5.3.7.1.6 Serial Port 6 Configuration

#### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled**                      Disable the serial port
- ➔ **Enabled**            **DEFAULT**            Enable the serial port

➔ **Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto**                      **DEFAULT**            The serial port IO port address and interrupt address are automatically detected.
- ➔ **IO=2E0h;**  
**IRQ=10**                      Serial Port I/O port address is 2E0h and the interrupt address is IRQ10
- ➔ **IO=2C0h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 2C0h and the interrupt address is IRQ10, 11
- ➔ **IO=2C8h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 2C8h and the interrupt address is IRQ10, 11
- ➔ **IO=2D0h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 2D0h and the interrupt address is IRQ10, 11
- ➔ **IO=2D8h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 2D8h and the interrupt address is IRQ10, 11
- ➔ **IO=2E0h;**  
**IRQ=10, 11**                      Serial Port I/O port address is 2E0h and the interrupt address is IRQ10, 11

### 5.3.8 H/W Monitor

The H/W Monitor menu (**BIOS Menu 12**) contains the fan configuration submenus and displays operating temperature, fan speeds and system voltages.

## IMB-Q670 Micro-ATX Motherboard

```

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.
-----
Advanced
-----
PC Health Status
CPU Temperature           :+0 C
SYS Temperature          :-128 C
CPU FAN Speed            :651 RPM
SYS FAN Speed            :N/A
VCC3V                    :+3.2962 V
Vcc                      :+4.080 V
V_core                   :+1.168 V
+1.05V                   :+1.064 V
VDDR                     :+1.632 V
VSB3V                    :+3.440 V
VBAT                     :+3.040 V
5VSB                     :N/A

> FAN 1 Configuration
> FAN 2 Configuration

Smart FAN Configuration
-----
<->: Select Screen
↑ ↓: Select Item
EnterSelect
+ - Change Opt.
F1  General Help
F2  Previous Values
F3  Optimized Defaults
F4  Save & Exit
ESC Exit

Version 2.11.1210. Copyright (C) 2011 American Megatrends, Inc.

```

### BIOS Menu 12: H/W Monitor

#### → PC Health Status


The following system parameters and values are shown. The system parameters that are monitored are:

- System Temperatures:
  - CPU Temperature
  - System Temperature
- Fan Speeds:
  - CPU Fan Speed
  - System Fan Speed
- Voltages:
  - VCC3V
  - Vcore
  - Vcc
  - +1.05V
  - VDDR
  - VSB3V
  - VBAT

- 5VSB

### 5.3.8.1 FAN 1 Configuration

Use the **FAN 1 Configuration submenu (BIOS Menu 13)** to configure fan 1 temperature and speed settings.



#### BIOS Menu 13: FAN 1 Configuration

##### → CPU Smart Fan control [Auto by RPM]

Use the **CPU Smart Fan control** option to configure the CPU Smart Fan.

- **Auto by RPM**    **DEFAULT**    The fan adjusts its speed using Auto by RPM settings
- **Auto by Duty-Cycle**    The fan adjusts its speed using Auto by Duty-Cycle settings
- **Manual by RPM**    The fan spins at the speed set in Manual by RPM settings
- **Manual by Duty-Cycle**    The fan spins at the speed set in Manual by Duty Cycle settings



## IMB-Q670 Micro-ATX Motherboard

### → Target Temp. Sensor [CPU Temperature]

Use the **Target Temp. Sensor** option to set the target CPU temperature.

- |   |                            |                |  |
|---|----------------------------|----------------|--|
| → | <b>CPU Temperature</b>     | <b>DEFAULT</b> | Sets the target temperature sensor to the CPU temperature.             |
| → | <b>System Temperature1</b> |                | Sets the target temperature sensor to the System Temperature1 setting. |
| → | <b>System Temperature2</b> |                | Sets the target temperature sensor to the System Temperature2 setting. |

### → Temperature Bound n

Use the + or – key to change the fan **Temperature Bound n** value. Enter a decimal number between 0 and 127.

### → Segment n Speed (%)


Use the + or – key to change the fan **Segment n Speed** value in percentage. Enter a decimal number between 0 and 100.

### → Full Speed Count

Use the + or – key to change the fan **Full Speed Count** value. Enter a decimal number between 500 and 15000.

## 5.3.8.2 FAN 2 Configuration

Use the **FAN 2 Configuration submenu (BIOS Menu 14)** to configure fan 2 temperature and speed settings.


**BIOS Menu 14: FAN 2 Configuration**
**→ CPU Smart Fan control [Auto by Duty-Cycle]**

Use the **CPU Smart Fan control** option to configure the CPU Smart Fan.

- **Auto by RPM**                      The fan adjusts its speed using Auto by RPM settings
- **Auto            by    DEFAULT**    The fan adjusts its speed using Auto by Duty-Cycle settings
- **Manual            by**                      The fan spins at the speed set in Manual by RPM settings
- **Manual            by**                      The fan spins at the speed set in Manual by Duty Cycle settings

**→ Target Temp. Sensor [CPU Temperature]**

Use the **Target Temp. Sensor** option to set the target CPU temperature.

- **CPU                      DEFAULT**    Sets the target temperature sensor to the CPU temperature.

## IMB-Q670 Micro-ATX Motherboard

- ➔ **System Temperature1** Sets the target temperature sensor to the System Temperature1 setting.
- ➔ **System Temperature2** Sets the target temperature sensor to the System Temperature2 setting.

### ➔ **Temperature Bound n**

Use the + or – key to change the fan **Temperature Bound n** value. Enter a decimal number between 0 and 127.

### ➔ **Segment 1 Speed (PWM)**

Use the + or – key to change the fan **Segment 1 Speed** value in Pulse Width Modulation (PWM). Enter a decimal number between 0 and 100.

## 5.3.9 Secondary Super IO Configuration

The **Secondary Super IO Configuration (BIOS Menu 15)** displays IO chip type and the submenus for configuring the external SATA ports 7, 8, 9, and 10.

```

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Secondary Super IO Configuration

Super IO Chip          Fintek F81216
> Serial Port 7 Configuration
> Serial Port 8 Configuration
> Serial Port 9 Configuration
> Serial Port 10 Configuration

<=>: Select Screen
↑ ↓: Select Item
Enter>Select
+ - Change Opt.
F1  General Help
F2  Previous Values
F3  Optimized Defaults
F4  Save & Exit
ESC Exit

Version 2.11.1210. Copyright (C) 2011 American Megatrends, Inc.
  
```

**BIOS Menu 15: Secondary Super IO Configuration**

### 5.3.9.1 Serial Port 7 Configuration

#### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled**                      Disable the serial port
- **Enabled**      **DEFAULT**      Enable the serial port

#### → Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- **Auto**              **DEFAULT**      The serial port IO port address and interrupt address are automatically detected.
- **IO=2C0h;**  
**IRQ=5**                      Serial Port I/O port address is 2C0h and the interrupt address is IRQ5
- **IO=2C0h;**  
**IRQ=5**                      Serial Port I/O port address is 2C0h and the interrupt address is IRQ5
- **IO=2C8h;**  
**IRQ=5**                      Serial Port I/O port address is 2C8h and the interrupt address is IRQ5
- **IO=2B0h;**  
**IRQ=5**                      Serial Port I/O port address is 2B0h and the interrupt address is IRQ5
- **IO=2B8h;**  
**IRQ=5**                      Serial Port I/O port address is 2B8h and the interrupt address is IRQ5

#### → Device Mode [Normal]

Use the **Device Mode** option to change the serial port mode.

- **Normal**              **DEFAULT**      Enables the serial port to function in normal mode.
- **IRDA**                      Enables the serial port to function in IRDA mode.

## IMB-Q670 Micro-ATX Motherboard

### 5.3.9.2 Serial Port 8 Configuration

#### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled**                      Disable the serial port
- **Enabled**      **DEFAULT**      Enable the serial port

#### → Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- **Auto**              **DEFAULT**      The serial port IO port address and interrupt address are automatically detected.
- **IO=2C8h;**  
**IRQ=5**                      Serial Port I/O port address is 2C8h and the interrupt address is IRQ5
- **IO=2C0h;**  
**IRQ=5**                      Serial Port I/O port address is 2C0h and the interrupt address is IRQ5
- **IO=2C8h;**  
**IRQ=5**                      Serial Port I/O port address is 2C8h and the interrupt address is IRQ5
- **IO=2B0h;**  
**IRQ=5**                      Serial Port I/O port address is 2B0h and the interrupt address is IRQ5
- **IO=2B8h;**  
**IRQ=5**                      Serial Port I/O port address is 2B8h and the interrupt address is IRQ5

### 5.3.9.3 Serial Port 9 Configuration

#### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled**                      Disable the serial port
- **Enabled**      **DEFAULT**      Enable the serial port

**→ Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- |                             |                |   |
|-----------------------------|----------------|---|
| <b>→ Auto</b>               | <b>DEFAULT</b> | The serial port IO port address and interrupt address are automatically detected. |
| <b>→ IO=2B0h;<br/>IRQ=5</b> |                | Serial Port I/O port address is 2B0h and the interrupt address is IRQ5            |
| <b>→ IO=2C0h;<br/>IRQ=5</b> |                | Serial Port I/O port address is 2C0h and the interrupt address is IRQ5            |
| <b>→ IO=2C8h;<br/>IRQ=5</b> |                | Serial Port I/O port address is 2C8h and the interrupt address is IRQ5            |
| <b>→ IO=2B0h;<br/>IRQ=5</b> |                | Serial Port I/O port address is 2B0h and the interrupt address is IRQ5            |
| <b>→ IO=2B8h;<br/>IRQ=5</b> |                | Serial Port I/O port address is 2B8h and the interrupt address is IRQ5            |

**5.3.9.4 Serial Port 10 Configuration****→ Serial Port [Enabled]**

Use the **Serial Port** option to enable or disable the serial port.

- |                   |                |                         |
|-------------------|----------------|-------------------------|
| <b>→ Disabled</b> |                | Disable the serial port |
| <b>→ Enabled</b>  | <b>DEFAULT</b> | Enable the serial port  |

**→ Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- |               |                |   |
|---------------|----------------|---|
| <b>→ Auto</b> | <b>DEFAULT</b> | The serial port IO port address and interrupt address are automatically detected. |
|---------------|----------------|---|

## IMB-Q670 Micro-ATX Motherboard

- **IO=2B8h;**  
**IRQ=5**                      Serial Port I/O port address is 2B8h and the interrupt address is IRQ5
- **IO=2C0h;**  
**IRQ=5**                      Serial Port I/O port address is 2C0h and the interrupt address is IRQ5
- **IO=2C8h;**  
**IRQ=5**                      Serial Port I/O port address is 2C8h and the interrupt address is IRQ5
- **IO=2B0h;**  
**IRQ=5**                      Serial Port I/O port address is 2B0h and the interrupt address is IRQ5
- **IO=2B8h;**  
**IRQ=5**                      Serial Port I/O port address is 2B8h and the interrupt address is IRQ5

### 5.3.10 Serial Port Console Redirection

The **Serial Port Console Redirection** menu (**BIOS Menu 16**) allows the console redirection options to be configured. Console redirection allows users to maintain a system remotely by re-directing keyboard input and text output through the serial port.


**BIOS Menu 16: Serial Port Console Redirection**
**➔ Console Redirection [Enabled]**

Use **Console Redirection** option to enable or disable the console redirection function.



## IMB-Q670 Micro-ATX Motherboard

- ➔ **Disabled** Disabled the console redirection function
- ➔ **Enabled** **DEFAULT** Enabled the console redirection function

### ➔ **Terminal Type [VT-100+]**

Use the **Terminal Type** option to specify the remote terminal type.

- ➔ **VT100** The target terminal type is VT100
- ➔ **VT100+** **DEFAULT** The target terminal type is VT100+
- ➔ **VT-UTF8** The target terminal type is VT-UTF8
- ➔ **ANSI** The target terminal type is ANSI

### ➔ **Bits per second [115200]**

Use the **Bits per second** option to specify the serial port transmission speed. The speed must match the other side. Long or noisy lines may require lower speeds.

- ➔ **9600** Sets the serial port transmission speed at 9600.
- ➔ **19200** Sets the serial port transmission speed at 19200.
- ➔ **38400** Sets the serial port transmission speed at 38400.
- ➔ **57600** Sets the serial port transmission speed at 57600.
- ➔ **115200** **DEFAULT** Sets the serial port transmission speed at 115200.

## 5.4 Chipset

Use the **Chipset** menu (**BIOS Menu 17**) to access the Northbridge, Southbridge, Integrated Graphics, and ME Subsystem configuration menus.



### **WARNING!**

Setting the wrong values for the Chipset BIOS selections in the Chipset BIOS menu may cause the system to malfunction.

---

```
Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.
Main   Advanced  Chipset  Boot   Security  Save & Exit
-----
> North Bridge
> Host Bridge
> South Bridge
> ME Subsystem

North Bridge Parameters
-----
<=>: Select Screen
↑↓: Select Item
EnterSelect
+ - Change Opt.
F1  General Help
F2  Previous Values
F3  Optimized Defaults
F4  Save & Exit
ESC Exit


Version 2.11.1210. Copyright (C) 2011 American Megatrends, Inc.
```

**BIOS Menu 17: Chipset**

## IMB-Q670 Micro-ATX Motherboard

### 5.4.1 Northbridge Configuration

Use the **Northbridge Chipset Configuration** menu (**BIOS Menu 18**) to configure the Northbridge chipset.



#### BIOS Menu 18:Northbridge Chipset Configuration

##### → Initiate Graphic Adapter [PEG/IGD]

Use the **Initiate Graphic Adapter** option to select the graphics controller used as the primary boot device. Select either an integrated graphics controller (IGD) or a combination of PCI graphics controller, a PCI express (PEG) controller or an IGD. Configuration options are listed below:

- IGD
- PCI/IGD
- PCI/PEG
- PEG/IGD      DEFAULT
- PEG/PCI

## → IGD Memory [64 M]

Use the **IGD Memory** option to specify the amount of system memory that can be used by the Internal graphics device.

- |   |                |   |
|---|----------------|---|
| → | <b>Disable</b> |   |
| → | <b>32 M</b>    | 32 MB of memory used by internal graphics device                |
| → | <b>64 M</b>    | <b>DEFAULT</b> 64 MB of memory used by internal graphics device |
| → | <b>96 M</b>    | 96 MB of memory used by internal graphics device                |
| → | <b>128 M</b>   | 128 MB of memory used by internal graphics device               |
| → | <b>160 M</b>   | 160 MB of memory used by internal graphics device               |
| → | <b>192 M</b>   | 192 MB of memory used by internal graphics device               |
| → | <b>224 M</b>   | 224 MB of memory used by internal graphics device               |
| → | <b>256 M</b>   | 256 MB of memory used by internal graphics device               |
| → | <b>288 M</b>   | 288 MB of memory used by internal graphics device               |
| → | <b>320 M</b>   | 320 MB of memory used by internal graphics device               |
| → | <b>352 M</b>   | 352 MB of memory used by internal graphics device               |
| → | <b>384 M</b>   | 384 MB of memory used by internal graphics device               |
| → | <b>416 M</b>   | 416 MB of memory used by internal graphics device               |
| → | <b>448 M</b>   | 448 MB of memory used by internal graphics device               |

## IMB-Q670 Micro-ATX Motherboard

- ➔ **480 M** 480 MB of memory used by internal graphics device
- ➔ **512 M** 512 MB of memory used by internal graphics device
- ➔ **1024 M** 1024 MB of memory used by internal graphics device

### ➔ **PCI Express Port [Enabled]**

Use the **PCI Express Port** option to enable or disable the PCI Express port.

- ➔ **Disabled** Disables the PCI Express port.
- ➔ **Enabled** **DEFAULT** Enables the PCI Express port.


### ➔ **VT-d [Disabled]**

Use the **VT-d** option to enable or disable VT-d support.

- ➔ **Disabled** **DEFAULT** Disables VT-d support.
- ➔ **Enabled** Enables VT-d support.

## 5.4.2 Southbridge Configuration

Use the **Southbridge Configuration** menu (**BIOS Menu 19**) to configure the Southbridge chipset.



### BIOS Menu 19: Southbridge Chipset Configuration

#### → GbE Controller [Enabled]

Use the **GbE Controller** option to enable or disable the GbE controller. Before disabling the GbE controller, the AMT function must be disabled.

- **Disabled**                      The onboard GbE controller is disabled
- **Enabled**      **DEFAULT**      The onboard GbE controller is enabled

#### → GbE PXE Boot [Disabled]

Use the **GbE PXE Boot** option to enable or disable the boot option for GbE devices.

- **Disabled**      **DEFAULT**      Disables the GbE PXE Boot option
- **Enabled**                              Enables the GbE PXE Boot option

## IMB-Q670 Micro-ATX Motherboard

### → Wake on LAN from S5 [Enabled]

Use the **Wake on LAN from S5** option to enable or disable GbE control PME in S5.

- **Disabled**                      Disables Wake on LAN from S5 option
- **Enabled**    **DEFAULT**      Enables Wake on LAN from S5 option

### → Resume on PCIe Wake [Enabled]

Use the **Resume on PCIe Wake** option to enable or disable resuming from the PCIe wake message and WAKE# signal.

- **Disabled**                      Disables Resume on PCIe Wake option
- **Enabled**    **DEFAULT**      Enables Resume on PCIe Wake option

### → Resume on PCI PME [Enabled]

Use the **Resume on PCI PME** option to enable or disable resuming from PCI PME# signal.

- **Disabled**                      Disables Resume on PCI PME option
- **Enabled**    **DEFAULT**      Enables Resume on PCI PME option

### → Resume on Ring [Enabled]

Use the **Resume on Ring** option to enable or disable resuming from RI# signal.

- **Disabled**                      Disables Resume on Ring option
- **Enabled**    **DEFAULT**      Enables Resume on Ring option

### → Resume on PS/2 [Enabled]

Use the **Resume on PS/2** option to enable or disable resuming from PS/2 activation.

- **Disabled**                      Disables Resume on PS/2 option
- **Enabled**    **DEFAULT**      Enables Resume on PS/2 option

**→ Azalia HD Audio [Enabled]**

Use the **Azalia HD Audio** option to enable or disable the High Definition Audio controller.

- Disabled**                      The onboard High Definition Audio controller is disabled
- Enabled**    **DEFAULT**      The onboard High Definition Audio controller is detected automatically and enabled

**→ Azalia internal HDMI codec [Disabled]**

Use the **Azalia internal HDMI codec** option to enable or disable the internal HDMI codec for High Definition Audio.

- Disabled**    **DEFAULT**      Disables the internal HDMI codec for High Definition Audio
- Enabled**                      Enables the internal HDMI codec for High Definition Audio

**→ PCIe x4 Slot1 [Enabled]**

Use the **PCIe x4 Slot1** option to enable or disable the PCI Express x4 Slot1.

- Disabled**                      Disables the PCIe x4 Slot1
- Enabled**    **DEFAULT**      Enables the PCIe x4 Slot1

**→ PCIe LAN Controller [Enabled]**

Use the **PCIe LAN Controller** option to enable or disable the PCI Express LAN controller.

- Disabled**                      The onboard PCIe LAN controller is disabled
- Enabled**    **DEFAULT**      The onboard PCIe LAN controller is enabled

**→ PCIe LAN PXE Boot [Enabled]**

Use the **PCIe LAN PXE Boot** option to enable or disable the boot option for the PCIe LAN PXE.

- Disabled**                      Disables PCIe LAN PXE Boot option



## IMB-Q670 Micro-ATX Motherboard

➔ **Enabled** **DEFAULT** Enables PCIe LAN PXE Boot option

### ➔ **PCIe USB3.0 Controller [Enabled]**

Use the **PCIe USB3.0 Controller** option to enable or disable the PCI Express USB 3.0 controller.

➔ **Disabled** The onboard USB 3.0 controller is disabled

➔ **Enabled** **DEFAULT** The onboard USB 3.0 controller is enabled

### ➔ **PCIe x4 Slot2 [Enabled]**


Use the **PCIe x4 Slot2** option to enable or disable the PCI Express x4 Slot2. This slot supports x1 mode only.

➔ **Disabled** Disables the PCIe x4 Slot2

➔ **Enabled** **DEFAULT** Enables the PCIe x4 Slot2

## 5.4.3 Integrated Graphics

Use the **Integrated Graphics** menu (**BIOS Menu 20**) to configure the video device connected to the system.



**BIOS Menu 20: Integrated Graphics**

**→ DVMT Mode Select [DVMT Mode]**

Use the **DVMT Mode Select** option to select the Intel Dynamic Video Memory Technology (DVMT) operating mode.

- Fixed Mode**                      A fixed portion of graphics memory is reserved as graphics memory.
- DVMT Mode    DEFAULT**      Graphics memory is dynamically allocated according to the system and graphics needs.

**→ DVMT/FIXED Memory [Maximum]**

Use the **DVMT/FIXED Memory** option to specify the maximum amount of memory that can be allocated as graphics memory. Configuration options are listed below.

- 128 MB
- 256 MB
- Maximum              **DEFAULT**

**→ IGD - Boot Type [AUTO]**


Use the **IGD - Boot Type** option to select the display device used by the system when it boots. For dual display support, select “Auto.” Configuration options are listed below.

- AUTO                      **DEFAULT**
- CRT
- DVI
- HDMI

**5.4.4 ME Subsystem**

Use the **ME Subsystem** menu (**BIOS Menu 21**) to configure the Intel® Management Engine (ME) configuration options.

## IMB-Q670 Micro-ATX Motherboard



### BIOS Menu 21: ME Subsystem


#### → MEBx Mode [Normal]

Use the **MEBx Mode** option to configure MEBx Mode options.

- **Normal**    **DEFAULT**    Enables normal mode
- **Hidden**                    Enables hidden Ctrl+P function  
Ctrl + P
- **Enter**                        Enables user to enter MEBx setup  
MEBx  
Setup

#### 5.4.4.1 AMT Configuration

The **AMT Configuration** submenu (**BIOS Menu 22**) allows advanced power management options to be configured.



### BIOS Menu 22: AMT Configuration

#### → AMT [Enabled]

Use **AMT** option to enable or disable the Intel® AMT function.

- **Disabled** Intel® AMT is disabled
- **Enabled** **DEFAULT** Intel® AMT is enabled

#### → Unconfigure AMT/ME [Disabled]


Use the **Unconfigure AMT/ME** option to perform AMT/ME unconfigure without password operation.

- **Disabled** **DEFAULT** Disable AMT/ME unconfigure
- **Enabled** Enable AMT/ME unconfigure

## IMB-Q670 Micro-ATX Motherboard

### 5.5 Boot

Use the **Boot** menu (**BIOS Menu 23**) to configure system boot options.



#### BIOS Menu 23: Boot

##### → Bootup NumLock State [On]

Use the **Bootup NumLock State** BIOS option to specify if the number lock setting must be modified during boot up.

- **On**      **DEFAULT**      Allows the Number Lock on the keyboard to be enabled automatically when the computer system boots up. This allows the immediate use of the 10-key numeric keypad located on the right side of the keyboard. To confirm this, the Number Lock LED light on the keyboard is lit.
- **Off**      Does not enable the keyboard Number Lock automatically. To use the 10-keys on the keyboard, press the Number Lock key located on the upper left-hand corner of the 10-key pad. The Number Lock LED on the keyboard lights up when the Number Lock is engaged.

**→ Quiet Boot [Enabled]**

Use the **Quiet Boot** BIOS option to select the screen display when the system boots.

- **Disabled**                      Normal POST messages displayed
- **Enabled**      **DEFAULT**      OEM Logo displayed instead of POST messages


**→ Option ROM Messages [Keep Current]**

Use the **Option ROM Messages** option to set the Option ROM display mode.

- **Force BIOS**                      Sets display mode to force BIOS.
- **Keep Current**      **DEFAULT**      Sets display mode to current.

## 5.6 Security

Use the **Security** menu (**BIOS Menu 24**) to set system and user passwords.


**BIOS Menu 24: Security**
**→ Administrator Password**

Use the **Administrator Password** to set or change a administrator password.

## IMB-Q670 Micro-ATX Motherboard

### → User Password

Use the **User Password** to set or change a user password.

## 5.7 Exit

Use the **Exit** menu (**BIOS Menu 25**) to load default BIOS values, optimal failsafe values and to save configuration changes.

```

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.
Main   Advanced   Chipset   Boot   Security   Save & Exit

Save Changes and Reset
Discard Changes and Reset

Restore Defaults
Save as User Defaults
Restore User Defaults

-----
←→: Select Screen
↑ ↓: Select Item
Enter>Select
+ - Change Opt.
F1  General Help
F2  Previous Values
F3  Optimized Defaults
F4  Save & Exit
ESC Exit

Version 2.11.1210. Copyright (C) 2011 American Megatrends, Inc.

```

### BIOS Menu 25:Exit

#### → Save Changes and Reset

Use the **Save Changes and Reset** option to save the changes made to the BIOS options and reset the system.

#### → Discard Changes and Reset

Use the **Discard Changes and Reset** option to exit the system without saving the changes made to the BIOS configuration setup program.

→ **Restore Defaults**

Use the **Restore Defaults** option to load the optimal default values for each of the parameters on the Setup menus. **F3 key can be used for this operation.**

→ **Save as User Defaults**

Use the **Save as User Defaults** option to save the changes done so far as user defaults.

→ **Restore User Defaults**

Use the **Restore User Defaults** option to restore the user defaults to all the setup options.



Appendix

A

# BIOS Options

---

Below is a list of BIOS configuration options in the BIOS chapter.

<b>System Overview</b> .....	<b>74</b>
<b>Memory Information</b> .....	<b>74</b>
<b>System Date [xx/xx/xx]</b> .....	<b>75</b>
<b>System Time [xx:xx:xx]</b> .....	<b>75</b>
<b>ACPI Sleep State [S1 (CPU Stop Clock)]</b> .....	<b>77</b>
<b>TPM Support [Disable]</b> .....	<b>78</b>
<b>Intel® Virtualization Technology [Disabled]</b> .....	<b>78</b>
<b>SATA Mode [AHCI Mode]</b> .....	<b>81</b>
<b>Staggered Spin-up [Disabled]</b> .....	<b>81</b>
<b>External SATA Port</b> .....	<b>81</b>
<b>Hot Plug</b> .....	<b>81</b>
<b>USB Devices</b> .....	<b>82</b>
<b>USB Support [Enabled]</b> .....	<b>83</b>
<b>Legacy USB Support [Enabled]</b> .....	<b>83</b>
<b>ERP Function [Disabled]</b> .....	<b>84</b>
<b>Serial Port [Enabled]</b> .....	<b>85</b>
<b>Change Settings [Auto]</b> .....	<b>85</b>
<b>Serial Port [Enabled]</b> .....	<b>86</b>
<b>Change Settings [Auto]</b> .....	<b>86</b>
<b>Device Mode [RS485]</b> .....	<b>87</b>
<b>Serial Port [Enabled]</b> .....	<b>87</b>
<b>Change Settings [Auto]</b> .....	<b>87</b>
<b>Serial Port [Enabled]</b> .....	<b>88</b>
<b>Change Settings [Auto]</b> .....	<b>88</b>
<b>Serial Port [Enabled]</b> .....	<b>89</b>
<b>Change Settings [Auto]</b> .....	<b>89</b>
<b>Serial Port [Enabled]</b> .....	<b>89</b>
<b>Change Settings [Auto]</b> .....	<b>90</b>
<b>PC Health Status</b> .....	<b>91</b>
<b>CPU Smart Fan control [Auto by RPM]</b> .....	<b>92</b>
<b>Target Temp. Sensor [CPU Temperature]</b> .....	<b>93</b>
<b>Temperature Bound n</b> .....	<b>93</b>
<b>Segment n Speed (%)</b> .....	<b>93</b>

## IMB-Q670 Micro-ATX Motherboard

Full Speed Count .....	93
CPU Smart Fan control [Auto by Duty-Cycle].....	94
Target Temp. Sensor [CPU Temperature] .....	94
Temperature Bound n.....	95
Segment 1 Speed (PWM).....	95
Serial Port [Enabled].....	96
Change Settings [Auto] .....	96
Device Mode [Normal] .....	96
Serial Port [Enabled].....	97
Change Settings [Auto] .....	97
Serial Port [Enabled].....	97
Change Settings [Auto] .....	98
Serial Port [Enabled].....	98
Change Settings [Auto] .....	98
Console Redirection [Enabled].....	100
Terminal Type [VT-100+] .....	101
Bits per second [115200].....	101
Initiate Graphic Adapter [PEG/IGD].....	103
IGD Memory [64 M] .....	104
PCI Express Port [Enabled] .....	105
VT-d [Disabled].....	105
GbE Controller [Enabled].....	106
GbE PXE Boot [Disabled].....	106
Wake on LAN from S5 [Enabled].....	107
Resume on PCIe Wake [Enabled].....	107
Resume on PCI PME [Enabled] .....	107
Resume on Ring [Enabled] .....	107
Resume on PS/2 [Enabled] .....	107
Azalia HD Audio [Enabled].....	108
Azalia internal HDMI codec [Disabled] .....	108
PCIe x4 Slot1 [Enabled].....	108
PCIe LAN Controller [Enabled].....	108
PCIe LAN PXE Boot [Enabled].....	108
PCIe USB3.0 Controller [Enabled].....	109
PCIe x4 Slot2 [Enabled].....	109

DVMT Mode Select [DVMT Mode].....	110
DVMT/FIXED Memory [Maximum] .....	110
IGD - Boot Type [AUTO] .....	110
MEBx Mode [Normal].....	111
AMT [Enabled].....	112
Unconfigure AMT/ME [Disabled] .....	112
Bootup NumLock State [On].....	113
Quiet Boot [Enabled] .....	114
Option ROM Messages [Keep Current] .....	114
Administrator Password .....	114
User Password .....	115
Save Changes and Reset .....	115
Discard Changes and Reset .....	115
Restore Defaults .....	116
Save as User Defaults .....	116
Restore User Defaults .....	116

Appendix

**B**

# Terminology

---

<b>AC '97</b>	Audio Codec 97 (AC'97) refers to a codec standard developed by Intel® in 1997.
<b>ACPI</b>	Advanced Configuration and Power Interface (ACPI) is an OS-directed configuration, power management, and thermal management interface.
<b>AHCI</b>	Advanced Host Controller Interface (AHCI) is a SATA Host controller register-level interface.
<b>ATA</b>	The Advanced Technology Attachment (ATA) interface connects storage devices including hard disks and CD-ROM drives to a computer.
<b>ARMD</b>	An ATAPI Removable Media Device (ARMD) is any ATAPI device that supports removable media, besides CD and DVD drives.
<b>ASKIR</b>	Amplitude Shift Keyed Infrared (ASKIR) is a form of modulation that represents a digital signal by varying the amplitude (“volume”) of the signal. A low amplitude signal represents a binary 0, while a high amplitude signal represents a binary 1.
<b>BIOS</b>	The Basic Input/Output System (BIOS) is firmware that is first run when the computer is turned on and can be configured by the end user
<b>CODEC</b>	The Compressor-Decompressor (CODEC) encodes and decodes digital audio data on the system.
<b>CMOS</b>	Complimentary metal-oxide-conductor is an integrated circuit used in chips like static RAM and microprocessors.
<b>COM</b>	COM refers to serial ports. Serial ports offer serial communication to expansion devices. The serial port on a personal computer is usually a male DB-9 connector.
<b>DAC</b>	The Digital-to-Analog Converter (DAC) converts digital signals to analog signals.
<b>DDR</b>	Double Data Rate refers to a data bus transferring data on both the rising and falling edges of the clock signal.
<b>DMA</b>	Direct Memory Access (DMA) enables some peripheral devices to bypass the system processor and communicate directly with the system memory.

## IMB-Q670 Micro-ATX Motherboard

<b>DIMM</b>	Dual Inline Memory Modules are a type of RAM that offer a 64-bit data bus and have separate electrical contacts on each side of the module.
<b>DIO</b>	The digital inputs and digital outputs are general control signals that control the on/off circuit of external devices or TTL devices. Data can be read or written to the selected address to enable the DIO functions.
<b>EHCI</b>	The Enhanced Host Controller Interface (EHCI) specification is a register-level interface description for USB 2.0 Host Controllers.
<b>EIDE</b>	Enhanced IDE (EIDE) is a newer IDE interface standard that has data transfer rates between 4.0 MBps and 16.6 MBps.
<b>EIST</b>	Enhanced Intel® SpeedStep Technology (EIST) allows users to modify the power consumption levels and processor performance through application software. The application software changes the bus-to-core frequency ratio and the processor core voltage.
<b>FSB</b>	The Front Side Bus (FSB) is the bi-directional communication channel between the processor and the Northbridge chipset.
<b>GbE</b>	Gigabit Ethernet (GbE) is an Ethernet version that transfers data at 1.0 Gbps and complies with the IEEE 802.3-2005 standard.
<b>GPIO</b>	General purpose input
<b>HDD</b>	Hard disk drive (HDD) is a type of magnetic, non-volatile computer storage device that stores digitally encoded data.
<b>ICH</b>	The Input/Output Control Hub (ICH) is an Intel® Southbridge chipset.
<b>IrDA</b>	Infrared Data Association (IrDA) specify infrared data transmission protocols used to enable electronic devices to wirelessly communicate with each other.
<b>L1 Cache</b>	The Level 1 Cache (L1 Cache) is a small memory cache built into the system processor.
<b>L2 Cache</b>	The Level 2 Cache (L2 Cache) is an external processor memory cache.
<b>LCD</b>	Liquid crystal display (LCD) is a flat, low-power display device that consists of two polarizing plates with a liquid crystal panel in between.

<b>LVDS</b>	Low-voltage differential signaling (LVDS) is a dual-wire, high-speed differential electrical signaling system commonly used to connect LCD displays to a computer.
<b>POST</b>	The Power-on Self Test (POST) is the pre-boot actions the system performs when the system is turned-on.
<b>RAM</b>	Random Access Memory (RAM) is volatile memory that loses data when power is lost. RAM has very fast data transfer rates compared to other storage like hard drives.
<b>SATA</b>	Serial ATA (SATA) is a serial communications bus designed for data transfers between storage devices and the computer chipsets. The SATA bus has transfer speeds up to 1.5 Gbps and the SATA II bus has data transfer speeds of up to 3.0 Gbps.
<b>S.M.A.R.T</b>	Self Monitoring Analysis and Reporting Technology (S.M.A.R.T) refers to automatic status checking technology implemented on hard disk drives.
<b>UART</b>	Universal Asynchronous Receiver-transmitter (UART) is responsible for asynchronous communications on the system and manages the system's serial communication (COM) ports.
<b>UHCI</b>	The Universal Host Controller Interface (UHCI) specification is a register-level interface description for USB 1.1 Host Controllers.
<b>USB</b>	The Universal Serial Bus (USB) is an external bus standard for interfacing devices. USB 1.1 supports 12Mbps data transfer rates and USB 2.0 supports 480Mbps data transfer rates.
<b>VGA</b>	The Video Graphics Array (VGA) is a graphics display system developed by IBM.



Appendix

C

# Digital I/O Interface

---

## C.1 Introduction

The DIO connector on the IMB-Q670 is interfaced to GPIO ports on the Super I/O chipset. The DIO has both 4-bit digital inputs and 4-bit digital outputs. The digital inputs and digital outputs are generally control signals that control the on/off circuit of external devices or TTL devices. Data can be read or written to the selected address to enable the DIO functions.



### NOTE:

For further information, please refer to the datasheet for the Super I/O chipset.

## C.2 DIO Connector Pinouts

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GND	2	+5V
3	D_IN0	4	D_OUT0
5	D_IN1	6	D_OUT1
7	D_IN2	8	D_OUT2
9	D_IN3	10	D_OUT3
11	D_8IN0	12	D_8OUT0
13	D_8IN1	14	D_8OUT1
15	D_8IN2	16	D_8OUT2
17	D_8IN3	18	D_8OUT3

**Table 5-2: Digital I/O Connector Pinouts**

## C.3 Assembly Language Samples

### C.3.1 Enable the DIO Input Function

The BIOS interrupt call INT 15H controls the digital I/O. An assembly program to enable digital I/O input functions is listed below.

## IMB-Q670 Micro-ATX Motherboard

<b>MOV</b>	<b>AX, 6F08H</b>	Sets the digital port as input
<b>INT</b>	<b>15H</b>	Initiates the INT 15H BIOS call

### C.3.2 Enable the DIO Output Function

The BIOS interrupt call INT 15H controls the digital I/O. An assembly program to enable digital I/O output functions is listed below.

<b>MOV</b>	<b>AX, 6F09H</b>	Sets the digital port as output
<b>MOV</b>	<b>BL, 09H</b>	
<b>INT</b>	<b>15H</b>	Initiates the INT 15H BIOS call

Appendix

D

# Watchdog Timer

---

## IMB-Q670 Micro-ATX Motherboard



### NOTE:

The following discussion applies to DOS environment. Contact IEI support or visit the IEI website for specific drivers for other operating systems.

The Watchdog Timer is provided to ensure that standalone systems can always recover from catastrophic conditions that cause the CPU to crash. This condition may have occurred by external EMIs or a software bug. When the CPU stops working correctly, Watchdog Timer either performs a hardware reset (cold boot) or a Non-Maskable Interrupt (NMI) to bring the system back to a known state.

A BIOS function call (INT 15H) is used to control the Watchdog Timer.

INT 15H:

AH – 6FH Sub-function:	
AL – 2:	Sets the Watchdog Timer's period.
BL:	Time-out value (Its unit-second is dependent on the item "Watchdog Timer unit select" in CMOS setup).

**Table D-1: AH-6FH Sub-function**

Call sub-function 2 to set the time-out period of Watchdog Timer first. If the time-out value is not zero, the Watchdog Timer starts counting down. When the timer value reaches zero, the system resets. To ensure that this reset condition does not occur, calling sub-function 2 must periodically refresh the Watchdog Timer. However, the watchdog timer is disabled if the time-out value is set to zero.

A tolerance of at least 10% must be maintained to avoid unknown routines within the operating system (DOS), such as disk I/O that can be very time-consuming.

**NOTE:**

When exiting a program it is necessary to disable the Watchdog Timer, otherwise the system resets.

**EXAMPLE PROGRAM:**

```
; INITIAL TIMER PERIOD COUNTER
```

```
;
```

```
W_LOOP:
```

```
;
```

```
    MOV     AX, 6F02H      ;setting the time-out value  
    MOV     BL, 30        ;time-out value is 48 seconds  
    INT     15H
```

```
;
```

```
; ADD THE APPLICATION PROGRAM HERE
```

```
;
```

```
    CMP     EXIT_AP, 1    ;is the application over?  
    JNE     W_LOOP       ;No, restart the application
```

```
    MOV     AX, 6F02H    ;disable Watchdog Timer  
    MOV     BL, 0       ;  
    INT     15H
```

```
;
```

```
; EXIT ;
```

Appendix

E

# Compatibility

---

**NOTE:**

The compatible items described here have been tested by the IEI R&D team and found to be compatible with the IMB-Q670

## E.1 Compatible Operating Systems

The following operating systems have been successfully run on the IMB-Q670.

- Microsoft Windows XP
- Microsoft Windows 7 Ultimate
- Microsoft Windows Vista Ultimate
- Linux Fedora 14

## E.2 Compatible Processors

The following Intel® Socket 1155 processors have been successfully tested on the IMB-Q670

CPU	Model
Intel® Core™ Quad/Dual core processor series	i7/i5/i3

**Table E-1: Compatible Processors**



Appendix

F

# Hazardous Materials Disclosure

---

## **F.1 Hazardous Materials Disclosure Table for IPB Products Certified as RoHS Compliant Under 2002/95/EC Without Mercury**

The details provided in this appendix are to ensure that the product is compliant with the Peoples Republic of China (China) RoHS standards. The table below acknowledges the presences of small quantities of certain materials in the product, and is applicable to China RoHS only.

A label will be placed on each product to indicate the estimated “Environmentally Friendly Use Period” (EFUP). This is an estimate of the number of years that these substances would “not leak out or undergo abrupt change.” This product may contain replaceable sub-assemblies/components which have a shorter EFUP such as batteries and lamps. These components will be separately marked.

Please refer to the table on the next page.

## IMB-Q670 Micro-ATX Motherboard

Part Name	Toxic or Hazardous Substances and Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (CR(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
<b>Housing</b>	X	O	O	O	O	X
<b>Display</b>	X	O	O	O	O	X
<b>Printed Circuit Board</b>	X	O	O	O	O	X
<b>Metal Fasteners</b>	X	O	O	O	O	O
<b>Cable Assembly</b>	X	O	O	O	O	X
<b>Fan Assembly</b>	X	O	O	O	O	X
<b>Power Supply Assemblies</b>	X	O	O	O	O	X
<b>Battery</b>	O	O	O	O	O	O

O: This toxic or hazardous substance is contained in all of the homogeneous materials for the part is below the limit requirement in SJ/T11363-2006

X: This toxic or hazardous substance is contained in at least one of the homogeneous materials for this part is above the limit requirement in SJ/T11363-2006

此附件旨在确保本产品符合中国 RoHS 标准。以下表格标示此产品中某有毒物质的含量符合中国 RoHS 标准规定的限量要求。

本产品上会附有“环境友好使用期限”的标签，此期限是估算这些物质“不会有泄漏或突变”的年限。本产品可能包含有较短的环境友好使用期限的可替换元件，像是电池或灯管，这些元件将会单独标示出来。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (CR(VI))	多溴联苯 (PBB)	多溴二苯 醚 (PBDE)
壳体	X	O	O	O	O	X
显示	X	O	O	O	O	X
印刷电路板	X	O	O	O	O	X
金属螺帽	X	O	O	O	O	O
电缆组装	X	O	O	O	O	X
风扇组装	X	O	O	O	O	X
电力供应组装	X	O	O	O	O	X
电池	O	O	O	O	O	O

O: 表示该有毒有害物质在该部件所有物质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。  
X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。