




IEI Technology Corp.



**MODEL:
NANO-945GSE**

**45 nm Intel® Atom™ Processor EPIC SBC Supports
2 GB DDR2 Memory, VGA, Dual LVDS, Dual PCIe GbE,
CF Type II, Dual SATA, PCI-104 and PCIe Mini**

User Manual

Rev. 2.00 – 24 August, 2011



Revision

Date	Version	Changes
24 August, 2011	2.00	Updated LAN card from Realtek RTL111CP to Realtek RTL111E Updated Section 4.7.6. SATA Drive Connection
26 March, 2009	1.01	Added LVDS2 connector pinouts Changed model name
25 September, 2008	1.00	Initial release

Copyright

COPYRIGHT NOTICE

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

TRADEMARKS

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Manual Conventions



WARNING!

Warnings appear where overlooked details may cause damage to the equipment or result in personal injury. Warnings should be taken seriously. Warnings are easy to recognize. The word “warning” is written as “**WARNING**,” both capitalized and bold and is followed by text. The text is the warning message. A warning message is shown below:



WARNING:

This is an example of a warning message. Failure to adhere to warning messages may result in permanent damage to the NANO-945GSE or personal injury to the user. Please take warning messages seriously.



CAUTION!

Cautionary messages should also be heeded to help reduce the chance of losing data or damaging the NANO-945GSE. Cautions are easy to recognize. The word “caution” is written as “**CAUTION**,” both capitalized and bold and is followed. The italicized text is the cautionary message. A caution message is shown below:



CAUTION:

This is an example of a caution message. Failure to adhere to cautions messages may result in permanent damage to the NANO-945GSE. Please take caution messages seriously.

NANO-945GSE EPIC Motherboard

A black triangle containing a yellow checkmark.

NOTE:

These messages inform the reader of essential but non-critical information. These messages should be read carefully as any directions or instructions contained therein can help avoid making mistakes. Notes are easy to recognize. The word “note” is written as “**NOTE**,” both capitalized and bold and is followed by text. The text is the cautionary message. A note message is shown below:

A black triangle containing a yellow checkmark.

NOTE:

This is an example of a note message. Notes should always be read. Notes contain critical information about the NANO-945GSE. Please take note messages seriously.

Packing List



NOTE:

If any of the components listed in the checklist below are missing, please do not proceed with the installation. Contact the IEI reseller or vendor you purchased the NANO-945GSE from or contact an IEI sales representative directly. To contact an IEI sales representative, please send an email to sales@iei.com.tw.

The items listed below should all be included in the NANO-945GSE package.

- 1 x NANO-945GSE Single Board Computer
- 2 x RS-232 cable (P/N: 32200-000049-RS)
- 2 x SATA Cable (P/N: 32000-062800-RS)
- 1 x KB/MS Cable (P/N: 32000-000138-RS)
- 1 x Power Cable (P/N: 32100-087100-RS)
- 1 x Mini Jumper
- 1 x Utility CD
- 1 x QIG (Quick Installation Guide)

Images of the above items are shown in **Chapter 3**.

Table of Contents

1	INTRODUCTION.....	18
1.1	OVERVIEW.....	19
1.2	CONNECTORS	19
1.3	BOARD DIMENSIONS	22
1.3.1	<i>External Interface Panel Dimensions</i>	<i>24</i>
1.4	DATA FLOW	25
1.5	TECHNICAL SPECIFICATIONS	26
2	UNPACKING	29
2.1	ANTI-STATIC PRECAUTIONS	30
2.2	UNPACKING PRECAUTIONS.....	30
2.3	UNPACKING CHECKLIST	31
2.3.1	<i>Package Contents.....</i>	<i>31</i>
2.3.2	<i>Optional Items.....</i>	<i>32</i>
3	CONNECTORS	34
3.1	PERIPHERAL INTERFACE CONNECTORS.....	35
3.1.1	<i>NANO-945GSE Layout</i>	<i>35</i>
3.2	PERIPHERAL INTERFACE CONNECTORS.....	36
3.2.1	<i>External Interface Panel Connectors.....</i>	<i>37</i>
3.3	INTERNAL PERIPHERAL CONNECTORS	38
3.3.1	<i>5V Power Connector.....</i>	<i>38</i>
3.3.2	<i>AT Power Connector.....</i>	<i>39</i>
3.3.3	<i>ATX Power Supply Enable Connector</i>	<i>40</i>
3.3.4	<i>Audio Connector (9-pin).....</i>	<i>41</i>
3.3.5	<i>Backlight Inverter Connector</i>	<i>42</i>
3.3.6	<i>CompactFlash® Socket.....</i>	<i>43</i>
3.3.7	<i>Digital Input/Output (DIO) Connector.....</i>	<i>45</i>
3.3.8	<i>Fan Connector (+12V, 3-pin)</i>	<i>46</i>
3.3.9	<i>Front Panel Connector (8-pin)</i>	<i>47</i>
3.3.10	<i>IDE Connector (44-pin).....</i>	<i>48</i>

- 3.3.11 *Infrared Interface Connector (5-pin)* 49
- 3.3.12 *Keyboard/Mouse Connector* 50
- 3.3.13 *LVDS LCD Connector* 51
- 3.3.14 *Parallel Port Connector* 53
- 3.3.15 *PCIe Mini Card Slot* 54
- 3.3.16 *PCI-104 Slot*..... 56
- 3.3.17 *SATA Drive Connectors* 59
- 3.3.18 *Serial Port Connectors (COM 3 and COM4)*..... 60
- 3.3.19 *Serial Port Connector (COM 2)(RS-232, RS-422 or RS-485)*..... 61
- 3.3.20 *TV Out Connector* 62
- 3.3.21 *USB Connectors (Internal)* 62
- 3.4 **EXTERNAL PERIPHERAL INTERFACE CONNECTOR PANEL** 63
 - 3.4.1 *Keyboard/Mouse Connector* 64
 - 3.4.2 *LAN Connectors*..... 65
 - 3.4.3 *Serial Port Connector (COM1)* 66
 - 3.4.4 *USB Connectors*..... 67
 - 3.4.5 *VGA Connector* 67
- 4 INSTALLATION** **69**
 - 4.1 **ANTI-STATIC PRECAUTIONS** 70
 - 4.2 **INSTALLATION CONSIDERATIONS**..... 71
 - 4.2.1 *Installation Notices* 71
 - 4.2.2 *Installation Checklist* 72
 - 4.3 **UNPACKING**..... 73
 - 4.4 **SO-DIMM AND CF CARD INSTALLATION** 73
 - 4.4.1 *SO-DIMM Installation* 73
 - 4.4.2 *CF Card Installation*..... 74
 - 4.5 **JUMPER SETTINGS** 75
 - 4.5.1 *AT Power Select Jumper Settings*..... 76
 - 4.5.2 *CF Card Setup* 77
 - 4.5.3 *Clear CMOS Jumper*..... 78
 - 4.5.4 *COM 2 Function Select Jumper*..... 79
 - 4.5.5 *LVDS1 Panel Resolution Jumper*..... 80
 - 4.5.6 *LVDS Voltage Selection*..... 82
 - 4.5.7 *PCI-104 Voltage Setup*..... 83

NANO-945GSE EPIC Motherboard

4.6 CHASSIS INSTALLATION.....	84
4.6.1 Airflow.....	84
4.6.2 Motherboard Installation.....	85
4.7 INTERNAL PERIPHERAL DEVICE CONNECTIONS.....	85
4.7.1 Peripheral Device Cables.....	85
4.7.2 AT Power Connection.....	86
4.7.3 5.1 Channel Audio Kit Installation.....	88
4.7.4 7.1 Channel Audio Kit Installation.....	90
4.7.5 ATA Flat Cable Connection.....	91
4.7.6 SATA Drive Connection.....	92
4.7.7 Single RS-232 Cable (w/o Bracket).....	95
4.7.8 USB Cable (Dual Port without Bracket).....	96
4.7.9 Parallel Port Cable without Bracket.....	97
4.7.10 Dual RS-422/485 Cables.....	98
4.8 EXTERNAL PERIPHERAL INTERFACE CONNECTION.....	99
4.8.1 LAN Connection (Single Connector).....	100
4.8.2 PS/2 Y-Cable Connection.....	100
4.8.3 Serial Device Connection.....	101
4.8.4 USB Connection (Dual Connector).....	102
4.8.5 VGA Monitor Connection.....	103
5 BIOS SCREENS.....	105
5.1 INTRODUCTION.....	106
5.1.1 Starting Setup.....	106
5.1.2 Using Setup.....	106
5.1.3 Getting Help.....	107
5.1.4 Unable to Reboot After Configuration Changes.....	107
5.1.5 BIOS Menu Bar.....	107
5.2 MAIN.....	108
5.3 ADVANCED.....	109
5.3.1 CPU Configuration.....	110
5.3.2 IDE Configuration.....	111
5.3.2.1 IDE Master, IDE Slave.....	113
5.3.3 Super IO Configuration.....	119
5.3.4 Hardware Health Configuration.....	123

5.3.5 Power Configuration.....	127
5.3.5.1 ACPI configuration	128
5.3.5.2 APM Configuration.....	129
5.3.6 Remote Configuration	132
5.3.7 USB Configuration.....	136
5.4 PCI/PNP.....	138
5.5 BOOT.....	141
5.5.1 Boot Settings Configuration.....	141
5.5.2 Boot Device Priority	144
5.6 SECURITY.....	145
5.7 CHIPSET	146
5.7.1 North Bridge Chipset Configuration	147
5.7.2 SouthBridge Configuration.....	150
5.8 EXIT	151
6 SOFTWARE DRIVERS	153
6.1 AVAILABLE SOFTWARE DRIVERS	154
6.2 STARTING THE DRIVER PROGRAM	154
6.3 CHIPSET DRIVER INSTALLATION.....	156
6.4 VGA DRIVER INSTALLATION.....	161
6.5 LAN DRIVER INSTALLATION	166
6.6 AUDIO DRIVER INSTALLATION	168
6.6.1 HD Audio Installation.....	169
6.6.2 AC'97 Driver Installation	172
A BIOS MENU OPTIONS.....	176
B TERMINOLOGY	180
C DIO INTERFACE.....	185
C.1 DIO INTERFACE INTRODUCTION	186
C.2 DIO CONNECTOR PINOUTS.....	186
C.3 ASSEMBLY LANGUAGE SAMPLES.....	187
C.3.1 Enable the DIO Input Function.....	187
C.3.2 Enable the DIO Output Function	187
D WATCHDOG TIMER	188

NANO-945GSE EPIC Motherboard

E	ADDRESS MAPPING	191
	E.1 I/O ADDRESS MAP	192
	E.2 IRQ ADDRESS MAP	194
	E.3 MEMORY ADDRESS MAP	195
F	HAZARDOUS MATERIALS DISCLOSURE	196
	F.1 HAZARDOUS MATERIAL DISCLOSURE TABLE FOR IPB PRODUCTS CERTIFIED AS ROHS COMPLIANT UNDER 2002/95/EC WITHOUT MERCURY	197

List of Figures

Figure 1-1: NANO-945GSE	19
Figure 1-2: NANO-945GSE Overview [Front View]	20
Figure 1-3: NANO-945GSE Overview [Solder Side]	21
Figure 1-4: NANO-945GSE Dimensions (mm)	23
Figure 1-5: External Interface Panel Dimensions (mm).....	24
Figure 1-6: Data Flow Block Diagram.....	25
Figure 3-1: Connector and Jumper Locations [Front Side].....	35
Figure 3-2: Connector and Jumper Locations [Solder Side].....	36
Figure 3-3: 5V Power Connector Pinouts	39
Figure 3-4: AT Power Connector Location	40
Figure 3-5: ATX Power Supply Enable Connector Location.....	41
Figure 3-6: Audio Connector Location (9-pin)	42
Figure 3-7: Panel Backlight Connector Pinout Locations.....	43
Figure 3-8: CF Card Socket Location	44
Figure 3-9: DIO Connector Connector Locations	45
Figure 3-10: +12V Fan Connector Location.....	46
Figure 3-11: Front Panel Connector Pinout Locations (8-pin)	47
Figure 3-12: Secondary IDE Device Connector Locations.....	48
Figure 3-13: Infrared Connector Pinout Locations	50
Figure 3-14: Keyboard/Mouse Connector Location.....	51
Figure 3-15: LVDS LCD Connector Pinout Locations	52
Figure 3-16: Parallel Port Connector Location.....	54
Figure 3-17: PCIe Mini Card Slot Location	55
Figure 3-18: PCI-104 Slot Location.....	57
Figure 3-19: SATA Drive Connector Locations	59
Figure 3-20: COM Connector Pinout Locations	60
Figure 3-21: RS-232/422/485 Serial Port Connector Location	61
Figure 3-22: TV Connector Pinout Locations.....	62

NANO-945GSE EPIC Motherboard

Figure 3-23: USB Connector Pinout Locations	63
Figure 3-24: NANO-945GSE External Peripheral Interface Connector	64
Figure 3-25: PS/2 Pinout and Configuration.....	64
Figure 3-26: RJ-45 Ethernet Connector	65
Figure 3-27: COM1 Pinout Locations	66
Figure 3-28: VGA Connector	68
Figure 4-1: SO-DIMM Installation.....	73
Figure 4-2: CF Card Installation.....	75
Figure 4-3: Jumper Locations.....	75
Figure 4-4: AT Power Select Jumper Location	77
Figure 4-5: CF Card Setup Jumper Location.....	78
Figure 4-6: Clear CMOS Jumper	79
Figure 4-7: COM 2 Function Select Jumper Location	80
Figure 4-8:LVDS Panel Resolution Jumper Pinout Locations	81
Figure 4-9: LVDS Voltage Selection Jumper Pinout Locations.....	83
Figure 4-10: PCI-104 Voltage Setup Jumper Pinout Locations	84
Figure 4-11: Power Cable to Motherboard Connection.....	87
Figure 4-12: Connect Power Cable to Power Supply	88
Figure 4-13: 5.1 Channel Audio Kit.....	89
Figure 4-14: 7.1 Channel Audio Kit.....	91
Figure 4-15: IDE Cable Connection	92
Figure 4-16: SATA Drive Cable Connection	93
Figure 4-17: SATA Power Drive Connection	94
Figure 4-18: Single RS-232 Cable Installation.....	95
Figure 4-19: Dual USB Cable Connection.....	96
Figure 4-20: LPT Cable Connection	97
Figure 4-21: Connect the LPT Device.....	98
Figure 4-22: Dual Serial Port Connector Cable Connection	99
Figure 4-23: LAN Connection.....	100
Figure 4-24: PS/2 Keyboard/Mouse Connector	101
Figure 4-25: Serial Device Connector	102
Figure 4-26: USB Connector	103

Figure 4-27: VGA Connector	104
Figure 6-1: Start Up Screen.....	155
Figure 6-2: Select Operating System	155
Figure 6-3: Drivers.....	156
Figure 6-4: Chipset Driver Screen	157
Figure 6-5: Chipset Driver Welcome Screen	157
Figure 6-6: Chipset Driver License Agreement.....	158
Figure 6-7: Chipset Driver Read Me File	159
Figure 6-8: Chipset Driver Setup Operations	160
Figure 6-9: Chipset Driver Installation Finish Screen	161
Figure 6-10: VGA Driver Read Me File.....	162
Figure 6-11: VGA Driver Setup Files Extracted.....	162
Figure 6-12: VGA Driver Welcome Screen.....	163
Figure 6-13: VGA Driver License Agreement	164
Figure 6-14: VGA Driver Read Me File.....	164
Figure 6-15: VGA Driver Setup Operations	165
Figure 6-16: VGA Driver Installation Finish Screen.....	165
Figure 6-17: LAN Driver Welcome Screen	166
Figure 6-18: LAN Driver Welcome Screen	167
Figure 6-19: LAN Driver Installation	167
Figure 6-20: LAN Driver Installation Complete	168
Figure 6-21: Audio Driver Options.....	169
Figure 6-22: Extract HD Audio Driver Installation Files	170
Figure 6-23: HD Audio Driver Welcome Screen	171
Figure 6-24: System Update.....	172
Figure 6-25: AC'97 Driver Installation File Extraction	173
Figure 6-26: AC'97 Driver Installation Welcome Screen	173
Figure 6-27: AC'97 Driver Installation Verification.....	174
Figure 6-28: AC'97 Driver Installation	174
Figure 6-29: AC'97 Driver Installation Complete.....	175

List of Tables

Table 1-1: Technical Specifications	28
Table 3-1: Peripheral Interface Connectors.....	37
Table 3-2: Rear Panel Connectors.....	38
Table 3-3: 5V Power Connector Pinouts	39
Table 3-4: AT Power Connector Pinouts	40
Table 3-5: ATX Power Supply Enable Connector Pinouts	41
Table 3-6: Audio Connector Pinouts (9-pin).....	42
Table 3-7: Panel Backlight Connector Pinouts	43
Table 3-8: CF Card Socket Pinouts	45
Table 3-9: DIO Connector Connector Pinouts.....	46
Table 3-10: +12V Fan Connector Pinouts	47
Table 3-11: Front Panel Connector Pinouts (8-pin)	48
Table 3-12: Secondary IDE Connector Pinouts.....	49
Table 3-13: Infrared Connector Pinouts.....	50
Table 3-14: Keyboard/Mouse Connector Pinouts	51
Table 3-15: LVDS LCD Port Connector Pinouts (LVDS1).....	52
Table 3-16: LVDS LCD Port Connector Pinouts (LVDS2).....	53
Table 3-17: Parallel Port Connector Pinouts	54
Table 3-18: PCIe Mini Card Slot Pinouts	56
Table 3-19: PCI-104 Slot Connector Pinouts	58
Table 3-20: SATA Drive Connector Pinouts	59
Table 3-21: COM Connector Pinouts.....	60
Table 3-22: RS-232/RS-485 Serial Port Connector Pinouts.....	61
Table 3-23: TV Port Connector Pinouts	62
Table 3-24: USB Port Connector Pinouts	63
Table 3-25: Keyboard Connector Pinouts	64
Table 3-26: LAN Pinouts	65
Table 3-27: RJ-45 Ethernet Connector LEDs.....	66



Table 3-28: RS-232 Serial Port (COM 1) Pinouts66

Table 3-29: USB Port Pinouts67

Table 3-30: VGA Connector Pinouts68

Table 4-1: Jumpers.....76

Table 4-2: AT Power Select Jumper Settings77

Table 4-3: CF Card Setup Jumper Settings78

Table 4-4: Clear CMOS Jumper Settings79

Table 4-5: COM 2 Function Select Jumper Settings.....80

Table 4-6: LVDS Panel Resolution Jumper Settings81

Table 4-7: LVDS Voltage Selection Jumper Settings82

Table 4-8: PCI-104 Voltage Setup Jumper Settings.....83

Table 4-9: IEI Provided Cables.....85

Table 5-1: BIOS Navigation Keys..... 107

List of BIOS Menus

Menu 1: Main.....	108
Menu 2: Advanced.....	110
Menu 3: CPU Configuration	111
Menu 4: IDE Configuration	112
Menu 5: IDE Master and IDE Slave Configuration	114
Menu 6: Super IO Configuration	119
Menu 7: Hardware Health Configuration	124
Menu 8: Power Configuration	128
Menu 9: ACPI Configuration	129
Menu 10:Advanced Power Management Configuration.....	130
Menu 11: Remote Access Configuration [Advanced]	133
Menu 12: USB Configuration	137
Menu 13: PCI/PnP Configuration.....	139
Menu 14: Boot.....	141
Menu 15: Boot Settings Configuration.....	142
Menu 16: Boot Device Priority Settings	144
Menu 17: Security.....	145
Menu 18: Chipset.....	146
Menu 19:North Bridge Chipset Configuration.....	147
Menu 20:SouthBridge Chipset Configuration	150
Menu 21:Exit	151



Chapter

1

Introduction

NANO-945GSE EPIC Motherboard

1.1 Overview




Figure 1-1: NANO-945GSE

The NANO-945GSE EPIC motherboards are embedded 45 nm Intel® Atom™ processor platforms. The Intel® Atom™ processor N270 embedded on the NANO-945GSE has a 1.60 GHz clock speed, a 533 MHz FSB and a 512 KB L2 cache. The NANO-945GSE also supports one 200-pin 533 MHz 2.0 GB (max.) DDR2 SDRAM SO-DIMM. The standard model comes with a single 18-bit dual-channel LVDS connector and the NANO-945GSELVDS model comes with an additional 24-bit dual channel LVDS connector. The NANO-945GSE also comes with two PCI Express (PCIe) Gigabit Ethernet (GbE) connectors, a PCI-104 expansion slot and a PCIe mini slot on the solder side.

1.2 Connectors

The NANO-945GSE has a wide variety of peripheral interface connectors. **Figure 1-2** is a labeled photo of the peripheral interface connectors on the NANO-945GSE.

NANO-945GSE EPIC Motherboard




Figure 1-3: NANO-945GSE Overview [Solder Side]

The NANO-945GSE has the following connectors on-board:

- 1 x +12V power source connector
- 1 x 5V power connector
- 1 x Audio connector
- 1 x ATX power control connector
- 2 x Backlight inverter connectors
- 1 x CompactFlash® socket
- 1 x Digital input/output (DIO) connector
- 1 x Fan connector
- 1 x Front panel connector
- 1 x IDE disk drive connectors (44-pin)
- 1 x Infrared interface (IrDA) connector
- 1 x Keyboard connector
- 2 x LVDS connectors
- 1 x Parallel port connector
- 1 x PCI-104 slot
- 1 x PCIe Mini Card slot

- 2 x Serial ATA (SATA) drive connectors
- 2 x RS-232 serial port connectors
- 1 x RS-232/422/485 serial port connector
- 1 x TV Out connector
- 2 x USB 2.0 connectors (supports four USB 2.0 devices)

The NANO-945GSE has the following external peripheral interface connectors on the board rear panel.

- 2 x Ethernet connectors
- 1 x PS/2 connector
- 1 x Serial port connector
- 2 x USB connectors
- 1 x VGA connector

The NANO-945GSE has the following on-board jumpers:

- AT Power Mode Setting
- Clear CMOS
- CF card setup
- LVDS1 Voltage Selection
- LVDS1 and LVDS2 Panel Resolution Selection
- LVDS2 Voltage Selection
- COM2 Port Mode setting
- PC104+ VIO Selector

1.3 Board Dimensions

The dimensions of the board are listed below:

- **Length:** 165 mm
- **Width:** 115 mm

NANO-945GSE EPIC Motherboard




Figure 1-4: NANO-945GSE Dimensions (mm)

1.3.1 External Interface Panel Dimensions

External peripheral interface connector panel dimensions are shown in **Figure 1-5**.




Figure 1-5: External Interface Panel Dimensions (mm)

NANO-945GSE EPIC Motherboard

1.4 Data Flow

Figure 1-6 shows the data flow between the two on-board chipsets and other components installed on the motherboard and described in the following sections of this chapter.




Figure 1-6: Data Flow Block Diagram

1.5 Technical Specifications

NANO-945GSE technical specifications are listed in **Table 1-1**. See **Chapter 2** for details.

Specification	NANO-945GSE
Form Factor	EPIC
System CPU	45 nm 1.6 GHz Intel® Atom™ N270
Front Side Bus (FSB)	533 MHz
System Chipset	Northbridge: Intel® 945GSE Southbridge: Intel® ICH7M
Memory	One 200-pin SO-DIMM socket supports one 533 MHz 2.0 GB (max.) DDR2 SDRAM SO-DIMM
CompactFlash®	One CompactFlash® Type II socket
Super I/O	ITE IT8718
Display	Intel® Graphics Media Accelerator 950 VGA integrated in Intel® 945GSE HDTV with 1080i maximum resolution supported Dual LVDS support 18-bit dual channel LVDS integrated in Intel® 945GSE NANO-942GSELVDS2: 18/24-bit dual-channel supported with Chrontel CH7308B
BIOS	AMI BIOS label
Audio	5.1 channel audio kit with Realtek ALC655 AC'97 codec 7.1 channel HD audio kit with Realtek ALC883 codec supports dual audio streams

NANO-945GSE EPIC Motherboard

LAN	Two Realtek RTL8111E GbE controllers with ASF 2.0 support
COM	Three RS-232 serial ports One RS-232/422/485 serial port
USB2.0	Six USB 2.0 devices supported: <ul style="list-style-type: none"> ■ Four by onboard pin-headers ■ Two by external connectors
Hard Drives	One 44-pin IDE connector connects to two Ultra ATA33/66/100 devices
SATA	Two 1.5 Gbps SATA drives supported
Keyboard/mouse	One external PS/2 connector
Parallel Port	One 26-pin parallel port connector
Expansion	One PCI-104 expansion slot (PCI bus) One PCIe mini card (PCIe bus)
Digital I/O	One 8-bit digital input/output connector; 4-bit input/4-bit output through the ITE IT8718 super I/O
Watchdog Timer	Software programmable 1-255 sec. through the ITE IT8718 super I/O
Infrared	One infrared connector through the ITE IT8718 super I/O. Supports: <ul style="list-style-type: none"> ■ Serial Infrared (SIR) ■ Amplitude Shift Keyed IR (ASKIR)
Power Supply	12V only, ATX and AT power supported
Power Consumption	12V @ 1.53 A (1.6 GHz Intel® Atom™ one 2.0 GB DDR2 SO-DIMM)
Temperature	0°C – 60°C (32°F - 140°F)

Humidity (operating)	5%~95% non-condensing
Dimensions (LxW)	115mm x 165mm
Weight (GW/NW)	700g/350g

Table 1-1: Technical Specifications

Chapter

2

Unpacking

2.1 Anti-static Precautions



WARNING!

Failure to take ESD precautions during the installation of the NANO-945GSE may result in permanent damage to the NANO-945GSE and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the NANO-945GSE. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the NANO-945GSE, or any other electrical component is handled, the following anti-static precautions are strictly adhered to.

- **Wear an anti-static wristband:** - Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- **Self-grounding:**- Before handling the board touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- **Use an anti-static pad:** When configuring the NANO-945GSE, place it on an anti-static pad. This reduces the possibility of ESD damaging the NANO-945GSE.
- **Only handle the edges of the PCB:** When handling the PCB, hold the PCB by the edges.

2.2 Unpacking Precautions

When the NANO-945GSE is unpacked, please do the following:

- Follow the anti-static precautions outlined in **Section 2.1**.
- Make sure the packing box is facing upwards so the NANO-945GSE does not fall out of the box.
- Make sure all the components shown in **Section 2.3** are present.

NANO-945GSE EPIC Motherboard

2.3 Unpacking Checklist











NOTE:

If any of the components listed in the checklist below are missing, do not proceed with the installation. Contact the IEI reseller or vendor the NANO-945GSE was purchased from or contact an IEI sales representative directly by sending an email to sales@iei.com.tw.

2.3.1 Package Contents







The NANO-945GSE is shipped with the following components:

Quantity	Item and Part Number	Image
1	NANO-945GSE	
2	SATA cable (P/N: 32000-062800-RS)	
1	KB/MS PS/2 Y-cable (P/N: 32000-000138-RS)	
1	AT 12V Cable (P/N: 32100-087100-RS)	
2	1 COM (wo bracket) (P/N: 32200-000049-RS)	





1	Mini jumper pack (2.0mm) (P/N:33100-000033-RS)	
1	Utility CD	
1	Quick Installation Guide	

2.3.2 Optional Items

The NANO-945GSE is shipped with the following components:

Item and Part Number	Image
Dual USB cable (wo bracket) (P/N: 32000-044300-RS)	
LPT cable (wo bracket) (P/N: 32200-015100-RS)	
RS-232/422/485 cable (P/N: 32200-026500-RS)	
ATX cable (P/N: 32100-043403)	
HDTV output cable (P/N: 32000-083701-RS)	
HDD cable (P/N: 32200-000009-RS)	

NANO-945GSE EPIC Motherboard

<p>IDE-cable (P/N: 32200-008800)</p>	
<p>SATA power cable (P/N: 32100-088600-RS)</p>	
<p>Audio kit_ 5.1 Channel (P/N: AC-KIT08R-R10)</p>	
<p>Audio kit_ 7.1 Channel (P/N: AC-KIT-883HD-R10)</p>	



Chapter

3

Connectors

NANO-945GSE EPIC Motherboard

3.1 Peripheral Interface Connectors

3.1.1 NANO-945GSE Layout

Figure 3-1 shows the on-board peripheral connectors, rear panel peripheral connectors and on-board jumpers.




Figure 3-1: Connector and Jumper Locations [Front Side]

Figure 3-2 shows the solder side of the NANO-945GSE.




Figure 3-2: Connector and Jumper Locations [Solder Side]

3.2 Peripheral Interface Connectors

Table 3-1 shows a list of the peripheral interface connectors on the NANO-945GSE. Detailed descriptions of these connectors can be found below.

Connector	Type	Label
+12V power source connector	4-pin ATX	CN1 and CN2
5V power connector	2-pin wafer	CN3
Audio connector	9-pin header	J_AUDIO1
ATX power control connector	3-pin wafer	ATXCTL1
Backlight inverter connectors	5-pin wafer	INVERTER2
Backlight inverter connectors	5-pin wafer	INVERTER1
CompactFlash® socket	50-pin CF socket	CF1
Digital input/output (DIO) connector	10-pin header	DIO1

NANO-945GSE EPIC Motherboard

Fan connector	3-pin wafer	CPU_FAN1
Front panel connector	8-pin header	F_PANEL1
IDE disk drive connectors (44-pin)	44-pin box header	IDE1
Infrared interface (IrDA) connector	5-pin header	IR1
Keyboard connector	6-pin wafer	KB1
LVDS connector	30-pin crimp	LVDS2
LVDS connector	30-pin crimp	LVDS1
Parallel port connector	26-pin header	LPT1
PCI-104 slot	120-pin socket	PC104_PLUS1
PCIe Mini Card slot	PCIe Mini Slot	CN4
Serial ATA (SATA) drive connectors	7-pin SATA	SATA1
Serial ATA (SATA) drive connectors	7-pin SATA	SATA2
RS-232 serial port connector	10-pin header	COM3
RS-232 serial port connector	10-pin header	COM4
RS-232/422/485 serial port connector	14-pin header	COM2
TV Out connector	6-pin header	TV1
USB 2.0 connector	8-pin header	USB01
USB 2.0 connector	8-pin header	USB23

Table 3-1: Peripheral Interface Connectors

3.2.1 External Interface Panel Connectors

Table 3-2 lists the rear panel connectors on the NANO-945GSE. Detailed descriptions of these connectors can be found in **Section 3.4** on **page 63**.

Connector	Type	Label
Ethernet connector	RJ-45	LAN1
Ethernet connector	RJ-45	LAN2
Keyboard/mouse	PS/2	KB_MS1
RS-232 serial port connector	Male DB-9	COM1
Dual USB port	USB port	USB
VGA port connector	15-pin female	VGA1

Table 3-2: Rear Panel Connectors

3.3 Internal Peripheral Connectors

Internal peripheral connectors are found on the motherboard and are only accessible when the motherboard is outside of the chassis. This section has complete descriptions of all the internal, peripheral connectors on the NANO-945GSE.

3.3.1 5V Power Connector

- CN Label:** CN3
- CN Type:** 2-pin wafer (1x3)
- CN Location:** See Figure 3-3
- CN Pinouts:** See Table 3-3

The 5V Power Connector provides +5V power output.

NANO-945GSE EPIC Motherboard




Figure 3-3: 5V Power Connector Pinouts


PIN NO.	DESCRIPTION
1	VCC
2	GND

Table 3-3: 5V Power Connector Pinouts

3.3.2 AT Power Connector

- CN Label:** CN1 & CN2
- CN Type:** 4-pin AT power connector (1x4)
- CN Location:** See **Figure 3-4**
- CN Pinouts:** See **Table 3-4**

The 4-pin +12V AT power connector is connected directly to an AT power supply.


Figure 3-4: AT Power Connector Location

PIN NO.	DESCRIPTION
1	GND
2	GND
3	+ 12V
4	+ 12V

Table 3-4: AT Power Connector Pinouts

3.3.3 ATX Power Supply Enable Connector

- CN Label:** ATXCTL1
- CN Type:** 3-pin wafer (1x3)
- CN Location:** See **Figure 3-5**
- CN Pinouts:** See **Table 3-5**

The ATX power supply enable connector enables the NANO-945GSE to be connected to an ATX power supply. In default mode, the NANO-945GSE can only use an AT power supply. To enable an ATX power supply the AT Power Select jumper must also be configured. Please refer to Chapter 3 for more details.

NANO-945GSE EPIC Motherboard




Figure 3-5: ATX Power Supply Enable Connector Location


PIN NO.	DESCRIPTION
1	GND
2	PS-ON
3	+5V Standby

Table 3-5: ATX Power Supply Enable Connector Pinouts

3.3.4 Audio Connector (9-pin)

- CN Label:** J_AUDIO1
- CN Type:** 9-pin header (2x5)
- CN Location:** See Figure 3-6
- CN Pinouts:** See Table 3-6

The 9-pin audio connector is connected to external audio devices including speakers and microphones for the input and output of audio signals to and from the system.


Figure 3-6: Audio Connector Location (9-pin)

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	SYNC	2	BITCLK
3	SDOUT	4	PCBEEP
5	SDIN	6	RST#
7	VCC	8	GND
9	+12V		

Table 3-6: Audio Connector Pinouts (9-pin)

3.3.5 Backlight Inverter Connector

CN Label: INVERTER1 and INVERTER2

CN Type: 5-pin wafer (1x5)

CN Location: See **Figure 3-7**

CN Pinouts: See **Table 3-7**

The backlight inverter connectors provide the backlights on the LCD display connected to the NANO-945GSE with +12V of power.

NANO-945GSE EPIC Motherboard




Figure 3-7: Panel Backlight Connector Pinout Locations


PIN NO.	DESCRIPTION
1	LCD Backlight Control
2	GROUND
3	+12V
4	GROUND
5	BACKLIGHT Enable

Table 3-7: Panel Backlight Connector Pinouts

3.3.6 CompactFlash® Socket

- CN Label:** CF1 (solder side)
- CN Type:** 50-pin header (2x25)
- CN Location:** See Figure 3-8
- CN Pinouts:** See Table 3-8

A CF Type I or Type II memory card is inserted to the CF socket on the solder side of the NANO-945GSE.


Figure 3-8: CF Card Socket Location

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GROUND	26	VCC-IN CHECK1
2	DATA 3	27	DATA 11
3	DATA 4	28	DATA 12
4	DATA 5	29	DATA 13
5	DATA 6	30	DATA 14
6	DATA 7	31	DATA 15
7	HDC_CS0#	32	HDC_CS1
8	N/C	33	N/C
9	GROUND	34	IOR#
10	N/C	35	IOW#
11	N/C	36	VCC_COM
12	N/C	37	IRQ15
13	VCC_COM	38	VCC_COM
14	N/C	39	CSEL
15	N/C	40	N/C

NANO-945GSE EPIC Motherboard

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
16	N/C	41	HDD_RESET
17	N/C	42	IORDY
18	SA2	43	SDREQ
19	SA1	44	SDACK#
20	SA0	45	HDD_ACTIVE#
21	DATA 0	46	66DET
22	DATA 1	47	DATA 8
23	DATA 2	48	DATA 9
24	N/C	49	DATA 10
25	VCC-IN CHECK2	50	GROUND

Table 3-8: CF Card Socket Pinouts

3.3.7 Digital Input/Output (DIO) Connector

- CN Label:** DIO1
- CN Type:** 10-pin header (2x5)
- CN Location:** See Figure 3-9
- CN Pinouts:** See Table 3-9

The digital input/output connector is managed through a Super I/O chip. The DIO connector pins are user programmable.




Figure 3-9: DIO Connector Connector Locations

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GND	2	VCC
3	Output 3	4	Output 2
5	Output 1	6	Output 0
7	Input 3	8	Input 2
9	Input 1	10	Input 0

Table 3-9: DIO Connector Connector Pinouts

3.3.8 Fan Connector (+12V, 3-pin)

- CN Label:** CPU_FAN1
- CN Type:** 3-pin header
- CN Location:** See Figure 3-10
- CN Pinouts:** See Table 3-10

The cooling fan connector provides a 12V, 500mA current to the cooling fan. The connector has a "rotation" pin to get rotation signals from fans and notify the system so the system BIOS can recognize the fan speed. Please note that only specified fans can issue the rotation signals.




Figure 3-10: +12V Fan Connector Location

NANO-945GSE EPIC Motherboard

PIN NO.	DESCRIPTION
1	GND
2	+12V
3	Fan Speed Detect

Table 3-10: +12V Fan Connector Pinouts

3.3.9 Front Panel Connector (8-pin)

CN Label:	F_PANEL1
CN Type:	8-pin header (2x4)
CN Location:	See Figure 3-11
CN Pinouts:	See Table 3-11

The front panel connector connects to external switches and indicators to monitor and controls the motherboard. These indicators and switches include:

- Power button
- Reset
- Power LED
- HDD LED




Figure 3-11: Front Panel Connector Pinout Locations (8-pin)


FUNCTION	PIN	DESCRIPTION	FUNCTION	PIN	DESCRIPTION
Power Button	1	PWR_BTN	Power LED	2	VCC5
	3	GND		4	GND
HDD LED	5	HDD_LED+	Reset	6	SYSRST-
	7	HDD_LED-		8	GND

Table 3-11: Front Panel Connector Pinouts (8-pin)

3.3.10 IDE Connector (44-pin)

- CN Label:** IDE1
- CN Type:** 44-pin header (2x22)
- CN Location:** See Figure 3-12
- CN Pinouts:** See Table 3-12

One 44-pin IDE device connector on the NANO-945GSE supports connectivity to two hard disk drives.


Figure 3-12: Secondary IDE Device Connector Locations

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1		22	
2		23	
3		24	
4		25	
5		26	
6		27	
7		28	
8		29	
9		30	
10		31	
11		32	
12		33	
13		34	
14		35	
15		36	
16		37	
17		38	
18		39	
19		40	
20		41	
21		42	
22		43	
23		44	

NANO-945GSE EPIC Motherboard

1	RESET#	2	GROUND
3	DATA 7	4	DATA 8
5	DATA 6	6	DATA 9
7	DATA 5	8	DATA 10
9	DATA 4	10	DATA 11
11	DATA 3	12	DATA 12
13	DATA 2	14	DATA 13
15	DATA 1	16	DATA 14
17	DATA 0	18	DATA 15
19	GROUND	20	N/C
21	IDE DRQ	22	GROUND
23	IOW#	24	GROUND
25	IOR#	26	GROUND
27	IDE CHRDY	28	GROUND
29	IDE DACK	30	GROUND-DEFAULT
31	INTERRUPT	32	N/C
33	SA1	34	N/C
35	SA0	36	SA2
37	HDC CS0#	38	HDC CS1#
39	HDD ACTIVE#	40	GROUND
41	VCC	42	VCC
43	GROUND	44	N/C

Table 3-12: Secondary IDE Connector Pinouts

3.3.11 Infrared Interface Connector (5-pin)

- CN Label:** IR1
- CN Type:** 5-pin header (1x5)
- CN Location:** See Figure 3-13
- CN Pinouts:** See Table 3-13

The infrared interface connector supports both Serial Infrared (SIR) and Amplitude Shift Key Infrared (ASKIR) interfaces.




Figure 3-13: Infrared Connector Pinout Locations

PIN NO.	DESCRIPTION
1	VCC
2	NC
3	IR-RX
4	GND
5	IR-TX

Table 3-13: Infrared Connector Pinouts

3.3.12 Keyboard/Mouse Connector

- CN Label:** KB1
- CN Type:** 6-pin header (1x6)
- CN Location:** See **Figure 3-14**
- CN Pinouts:** See **Table 3-14**

The keyboard and mouse connector can be connected to a standard PS/2 cable or PS/2 Y-cable to add keyboard and mouse functionality to the system.

NANO-945GSE EPIC Motherboard




Figure 3-14: Keyboard/Mouse Connector Location

PIN NO.	DESCRIPTION
1	+5V KB DATA
2	MS DATA
3	MS CLK
4	KB DATA
5	KB CLK
6	GROUND

Table 3-14: Keyboard/Mouse Connector Pinouts

3.3.13 LVDS LCD Connector

- CN Label:** LVDS1 and LVDS2
- CN Type:** 30-pin crimp (2x10)
- CN Location:** See Figure 3-15
- CN Pinouts:** See Table 3-15 and Figure 4-16

The 30-pin LVDS LCD connectors can be connected to single channel or dual channel, 24-bit or 36-bit LVDS panel.




Figure 3-15: LVDS LCD Connector Pinout Locations

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GND1	2	GND2
3	A_Y0	4	A_Y0#
5	A_Y1	6	A_Y1#
7	A_Y2	8	A_Y2#
9	A_CK	10	A_CK#
11	NC	12	NC
13	GND3	14	GND4
15	B_Y0	16	B_Y0#
17	B_Y1	18	B_Y1#
19	B_Y2	20	B_Y2#
21	B_CK	22	B_CK#
23	NC	24	NC
25	GND5	26	GND6
27	VCC_LCD	28	VCC_LCD
29	VCC_LCD	30	VCC_LCD

Table 3-15: LVDS LCD Port Connector Pinouts (LVDS1)

NANO-945GSE EPIC Motherboard


PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GND1	2	GND2
3	A_Y0	4	A_Y0#
5	A_Y1	6	A_Y1#
7	A_Y2	8	A_Y2#
9	A_CK	10	A_CK#
11	A_Y3	12	A_Y3#
13	GND3	14	GND4
15	B_Y0	16	B_Y0#
17	B_Y1	18	B_Y1#
19	B_Y2	20	B_Y2#
21	B_CK	22	B_CK#
23	B_Y3	24	B_Y3#
25	GND5	26	GND6
27	VCC_LCD	28	VCC_LCD
29	VCC_LCD	30	VCC_LCD

Table 3-16: LVDS LCD Port Connector Pinouts (LVDS2)

3.3.14 Parallel Port Connector

- CN Label:** LPT1
- CN Type:** 26-pin header
- CN Location:** See **Figure 3-16**
- CN Pinouts:** See **Table 3-17**

The 26-pin parallel port connector connects to a parallel port connector interface or some other parallel port device such as a printer.


Figure 3-16: Parallel Port Connector Location

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	STROBE#	2	DATA 0
3	DATA 1	4	DATA 2
5	DATA 3	6	DATA 4
7	DATA 5	8	DATA 6
9	DATA 7	10	ACKNOWLEDGE
11	BUSY	12	PAPER EMPTY
13	PRINTER SELECT	14	AUTO FORM FEED #
15	ERROR#	16	INITIALIZE
17	PRINTER SELECT LN#	18	GROUND
19	GROUND	20	GROUND
21	GROUND	22	GROUND
23	GROUND	24	GROUND
25	GROUND	26	NC

Table 3-17: Parallel Port Connector Pinouts

3.3.15 PCIe Mini Card Slot

CN Label: CN4

NANO-945GSE EPIC Motherboard

CN Type: 52-pin Mini PCIe Card Slot

CN Location: See Figure 3-17

CN Pinouts: See Table 3-18

The PCIe mini card slot enables a PCIe mini card expansion module to be connected to the board. Cards supported include among others wireless LAN (WLAN) cards.




Figure 3-17: PCIe Mini Card Slot Location

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	PCIE_WAKE#	2	VCC3
3	N/C	4	GND
5	N/C	6	1.5V
7	CLKREQ#	8	LFRAME#
9	GND	10	LAD3
11	CLK-	12	LAD2
13	CLK+	14	LAD1
15	GND	16	LAD0
17	PCIRST#	18	GND
19	LPC	20	VCC3
21	GND	22	PCIRST#
23	PERN2	24	3VDual
25	PERP2	26	GND
27	GND	28	1.5V
29	GND	30	SMBCLK

31	PETN2	32	SMBDATA
33	PETP2	34	GND
35	GND	36	USB D-
37	N/C	38	USB D+
39	N/C	40	GND
41	N/C	42	N/C
43	N/C	44	RF_LINK#
45	N/C	46	BLUELED#
47	N/C	48	1.5V
49	N/C	50	GND
51	N/C	52	VCC3

Table 3-18: PCIe Mini Card Slot Pinouts

3.3.16 PCI-104 Slot

- CN Label:** PC104_PLUS1
- CN Type:** 120-pin PCI-104 slot
- CN Location:** See **Figure 3-18**
- CN Pinouts:** See **Table 3-19**

The PCI-104 slot enables a PCI-104 compatible expansion module to be connected to the board.

NANO-945GSE EPIC Motherboard




Figure 3-18: PCI-104 Slot Location

Pin No.	Column A	Column B	Column C	Column D
1	GND/5V	TBD1	5V	AD00
2	VI/O1	AD02	AD01	+5V
3	AD05	GND	AD04	AD03
4	C/BE0#	AD07	GND	AD06
5	GND	AD09	AD08	GND
6	AD11	VI/O2	AD10	M66EN

Pin No.	Column A	Column B	Column C	Column D
7	AD14	AD13	GND	AD12
8	+3.3V	C/BE1#	AD15	+3.3V
9	SERR#	GND	SBO#	PAR
10	GND	PERR#	+3.3V	SDONE
11	STOP#	+3.3V	LOCK#	GND
12	+3.3V	TRDY#	GND	DEVSEL#
13	FRAME#	GND	IRDY#	+3.3V
14	GND	AD16	+3.3V	C/BE2#
15	AD18	+3.3V	AD17	GND
16	AD21	AD20	GND	AD19
17	+3.3V	AD23	AD22	+3.3V
18	IDSEL0	GND	IDSEL1	IDSEL2
19	AD24	C/BE3#	VI/O1	IDSEL3
20	GND	AD26	AD25	GND
21	AD29	+5V	AD28	AD27
22	+5V	AD30	GND	AD31
23	REQ0#	GND	REQ1#	VI/O2
24	GND	REQ2#	+5V	GNT0#
25	GNT1#	VI/O3	GNT2#	GND
26	+5V	CLK0	GND	CLK1
27	CLK2	+5V	CLK3	GND
28	GND	INTD#	+5V	RST#
29	+12V	INTA#	INTB#	INTC#
30	-12V	TBD2	TBD	GND/3.3V

Table 3-19: PCI-104 Slot Connector Pinouts

NANO-945GSE EPIC Motherboard

3.3.17 SATA Drive Connectors

- CN Label:** SATA1, SATA2
- CN Type:** 7-pin SATA drive connectors
- CN Location:** See Figure 3-19
- CN Pinouts:** See Table 3-20

The four SATA drive connectors are each connected to a first generation SATA drive. First generation SATA drives transfer data at speeds as high as 150Mb/s. The SATA drives can be configured in a RAID configuration.




Figure 3-19: SATA Drive Connector Locations

PIN NO.	DESCRIPTION
1	GND
2	TX+
3	TX-
4	GND
5	RX-
6	RX+
7	GND

Table 3-20: SATA Drive Connector Pinouts

3.3.18 Serial Port Connectors (COM 3 and COM4)

- CN Label:** COM3 and COM4
- CN Type:** 10-pin header (2x5)
- CN Location:** See Figure 3-20
- CN Pinouts:** See Table 3-21

The 10-pin serial port connector provides a second RS-232 serial communications channel. The COM serial port connectors can be connected to external RS-232 serial port devices.




Figure 3-20: COM Connector Pinout Locations

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	Data Carrier Direct (DCD)	2	Data Set Ready (DSR)
3	Receive Data (RXD)	4	Request To Send (RTS)
5	Transmit Data (TXD)	6	Clear To Send (CTS)
7	Data Terminal Ready (DTR)	8	Ring Indicator (RI)
9	Ground (GND)	10	N/C

Table 3-21: COM Connector Pinouts

NANO-945GSE EPIC Motherboard

3.3.19 Serial Port Connector (COM 2)(RS-232, RS-422 or RS-485)

- CN Label:** COM2
- CN Type:** 14-pin header (2x7)
- CN Location:** See Figure 3-21
- CN Pinouts:** See Table 3-22

The 14-pin serial port connector connects to the COM2 serial communications channels. COM2 is a multi function channel. In default mode COM2 is an RS-232 serial communication channel but, with the COM2 function select jumper, can be configured as either an RS-422 or RS-485 serial communications channel.




Figure 3-21: RS-232/422/485 Serial Port Connector Location

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	NDCD	2	NDSR2
3	NRX	4	NRTS2
5	NTX	6	NCTS2
7	NDTR	8	NRI2
9	GND	10	GND
11	TXD485+	12	TXD485-
13	RXD485+	14	RXD485-

Table 3-22: RS-232/RS-485 Serial Port Connector Pinouts

3.3.20 TV Out Connector

- CN Label:** TV1
- CN Type:** 6-pin header (2x3)
- CN Location:** See Figure 3-22
- CN Pinouts:** See Table 3-23

The 2x3 pin TV out connector connects to a TV output by using an S-Video or RCA connector. The TV out connector makes displaying media data on a television easier.




Figure 3-22: TV Connector Pinout Locations

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GND	2	IOY
3	GND	4	IOC
5	GND	6	IOCOMP

Table 3-23: TV Port Connector Pinouts

3.3.21 USB Connectors (Internal)

- CN Label:** USB01 and USB23
- CN Type:** 8-pin header (2x4)
- CN Location:** See Figure 3-23
- CN Pinouts:** See Table 3-24

NANO-945GSE EPIC Motherboard

The 2x4 USB pin connectors each provide connectivity to two USB 1.1 or two USB 2.0 ports. Each USB connector can support two USB devices. Additional external USB ports are found on the rear panel. The USB ports are used for I/O bus expansion.




Figure 3-23: USB Connector Pinout Locations

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	VCC	2	GND
3	DATA-	4	DATA+
5	DATA+	6	DATA-
7	GND	8	VCC

Table 3-24: USB Port Connector Pinouts

3.4 External Peripheral Interface Connector Panel

Figure 3-24 shows the NANO-945GSE external peripheral interface connector (EPIC) panel. The NANO-945GSE EPIC panel consists of the following:

- 2 x RJ-45 LAN connectors
- 1 x PS/2 connectors
- 1 x Serial port connectors
- 2 x USB connectors
- 1 x VGA connector




Figure 3-24: NANO-945GSE External Peripheral Interface Connector

3.4.1 Keyboard/Mouse Connector

- CN Label: KB/MS
- CN Type: PS/2
- CN Location: See **Figure 3-24** (labeled 1)
- CN Pinouts: See Figure 3-25, Table 3-25

The NANO-945GSE keyboard and mouse connector is a standard PS/2 connector.




Figure 3-25: PS/2 Pinout and Configuration

PIN	DESCRIPTION
1	KB DATA
2	MS DATA
3	GND
4	VCC
5	KB CLOCK
6	MS CLOCK

Table 3-25: Keyboard Connector Pinouts

NANO-945GSE EPIC Motherboard

3.4.2 LAN Connectors

CN Label: LAN1 and LAN2

CN Type: RJ-45

CN Location: See Figure 3-24

CN Pinouts: See Table 3-26

The NANO-945GSE is equipped with two built-in RJ-45 Ethernet controllers. The controllers can connect to the LAN through two RJ-45 LAN connectors. There are two LEDs on the connector indicating the status of LAN. The pin assignments are listed in the following table:

PIN	DESCRIPTION	PIN	DESCRIPTION
1	MDIA3-	5	MDIA1+
2	MDIA3+	6	MDIA2+
3	MDIA2-	7	MDIA0-
4	MDIA1-	8	MDIA0+

Table 3-26: LAN Pinouts




Figure 3-26: RJ-45 Ethernet Connector

The RJ-45 Ethernet connector has two status LEDs, one green and one yellow. The green LED indicates activity on the port and the yellow LED indicates the port is linked. See **Table 3-27**.

STATUS	DESCRIPTION	STATUS	DESCRIPTION
GREEN	Activity	YELLOW	Linked


Table 3-27: RJ-45 Ethernet Connector LEDs

3.4.3 Serial Port Connector (COM1)

- CN Label:** COM1
- CN Type:** DB-9 connectors
- CN Location:** See Figure 3-24 (see 2)
- CN Pinouts:** See Table 3-28 and Figure 3-27

The 9-pin DB-9 serial port connectors are connected to RS-232 serial communications devices.

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	DCD	6	DSR
2	RX	7	RTS
3	TX	8	CTS
4	DTR	9	RI
5	GND		

Table 3-28: RS-232 Serial Port (COM 1) Pinouts

Figure 3-27: COM1 Pinout Locations

NANO-945GSE EPIC Motherboard

3.4.4 USB Connectors

- CN Label:** USB
- CN Type:** Dual USB port
- CN Location:** See Figure 3-24
- CN Pinouts:** See Table 3-29

The NANO-945GSE has two external USB 2.0 ports. The ports connect to both USB 2.0 and USB 1.1 devices.

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	VCC	5	VCC
2	DATA-	6	DATA-
3	DATA+	7	DATA+
4	GND	8	GND

Table 3-29: USB Port Pinouts

3.4.5 VGA Connector

- CN Label:** VGA1
- CN Type:** 15-pin Female
- CN Location:** See Figure 3-24
- CN Pinouts:** See Figure 3-28 and Table 3-30

The NANO-945GSE has a single 15-pin female connector for connectivity to standard display devices.




Figure 3-28: VGA Connector

PIN	DESCRIPTION	PIN	DESCRIPTION
1	RED	2	GREEN
3	BLUE	4	NC
5	GND	6	CRT_PLUG-
7	GND	8	GND
9	VCC	10	GND
11	NC	12	DDC DAT
13	HSYNC	14	VSYNC
15	DDCCLK		

Table 3-30: VGA Connector Pinouts

Chapter

4

Installation

4.1 Anti-static Precautions



WARNING:

Failure to take ESD precautions during the installation of the NANO-945GSE may result in permanent damage to the NANO-945GSE and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the NANO-945GSE. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the NANO-945GSE, or any other electrical component is handled, the following anti-static precautions are strictly adhered to.

- **Wear an anti-static wristband:** - Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- **Self-grounding:**- Before handling the board touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- **Use an anti-static pad:** When configuring the NANO-945GSE, place it on an anti-static pad. This reduces the possibility of ESD damaging the NANO-945GSE.
- **Only handle the edges of the PCB:-:** When handling the PCB, hold the PCB by the edges.

4.2 Installation Considerations



NOTE:

The following installation notices and installation considerations should be read and understood before the NANO-945GSE is installed. All installation notices pertaining to the installation of the NANO-945GSE should be strictly adhered to. Failing to adhere to these precautions may lead to severe damage of the NANO-945GSE and injury to the person installing the motherboard.

4.2.1 Installation Notices



WARNING:

The installation instructions described in this manual should be carefully followed in order to prevent damage to the NANO-945GSE, NANO-945GSE components and injury to the user.

Before and during the installation please **DO** the following:

- Read the user manual:
 - The user manual provides a complete description of the NANO-945GSE installation instructions and configuration options.
- Wear an electrostatic discharge cuff (ESD):
 - Electronic components are easily damaged by ESD. Wearing an ESD cuff removes ESD from the body and helps prevent ESD damage.
- Place the NANO-945GSE on an antistatic pad:
 - When installing or configuring the motherboard, place it on an antistatic pad. This helps to prevent potential ESD damage.
- Turn all power to the NANO-945GSE off:

- When working with the NANO-945GSE, make sure that it is disconnected from all power supplies and that no electricity is being fed into the system.

Before and during the installation of the NANO-945GSE **DO NOT:**

- Remove any of the stickers on the PCB board. These stickers are required for warranty validation.
- Use the product before verifying all the cables and power connectors are properly connected.
- Allow screws to come in contact with the PCB circuit, connector pins, or its components.

4.2.2 Installation Checklist

The following checklist is provided to ensure the NANO-945GSE is properly installed.

- All the items in the packing list are present
- A compatible memory module is properly inserted into the slot
- The CF Type I or CF Type II card is properly installed into the CF socket
- The jumpers have been properly configured
- The NANO-945GSE is inserted into a chassis with adequate ventilation
- The correct power supply is being used
- The following devices are properly connected
 - Primary and secondary IDE device
 - SATA drives
 - Power supply
 - USB cable
 - Serial port cable
- The following external peripheral devices are properly connected to the chassis:
 - VGA screen
 - Keyboard
 - Mouse
 - RS-232 serial communications device
 - USB devices

NANO-945GSE EPIC Motherboard

4.3 Unpacking

When the NANO-945GSE is unpacked, please check all the unpacking list items listed in Chapter 3 are indeed present. If any of the unpacking list items are not available please contact the NANO-945GSE vendor reseller/vendor where the NANO-945GSE was purchased or contact an IEI sales representative.

4.4 SO-DIMM and CF Card Installation

4.4.1 SO-DIMM Installation



WARNING:

Using incorrectly specified SO-DIMM may cause permanently damage the NANO-945GSE. Please make sure the purchased SO-DIMM complies with the memory specifications of the NANO-945GSE. SO-DIMM specifications compliant with the NANO-945GSE are listed in **Chapter 2**.

To install a SO-DIMM into a SO-DIMM socket, please follow the steps below and refer to **Figure 4-1**.




Figure 4-1: SO-DIMM Installation

Step 1: Locate the SO-DIMM socket. Place the NANO-945GSE on an anti-static pad with the solder side facing up.

- Step 2:** **Align the SO-DIMM with the socket.** The SO-DIMM must be oriented in such a way that the notch in the middle of the SO-DIMM must be aligned with the plastic bridge in the socket.
- Step 3:** **Insert the SO-DIMM.** Push the SO-DIMM chip into the socket at an angle. (See **Figure 4-1**)
- Step 4:** **Open the SO-DIMM socket arms.** Gently pull the arms of the SO-DIMM socket out and push the rear of the SO-DIMM down. (See **Figure 4-1**)
- Step 5:** **Secure the SO-DIMM.** Release the arms on the SO-DIMM socket. They clip into place and secure the SO-DIMM in the socket.

4.4.2 CF Card Installation



NOTE:

The NANO-945GSE can support both CF Type I cards and CF Type II cards. For the complete specifications of the supported CF cards please refer to **Chapter 2**.

To install the a CF card (Type 1 or Type 2) onto the NANO-945GSE, please follow the steps below:

- Step 1:** **Locate the CF card socket.** Place the NANO-945GSE on an anti-static pad with the solder side facing up. Locate the CF card.
- Step 2:** **Align the CF card.** Make sure the CF card is properly aligned with the CF socket.
- Step 3:** **Insert the CF card.** Gently insert the CF card into the socket making sure the socket pins are properly inserted into the socket. See **Figure 4-2**.

NANO-945GSE EPIC Motherboard




Figure 4-2: CF Card Installation

4.5 Jumper Settings



NOTE:

A jumper is a metal bridge used to close an electrical circuit. It consists of two or three metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To CLOSE/SHORT a jumper means connecting the pins of the jumper with the plastic clip and to OPEN a jumper means removing the plastic clip from a jumper.




Figure 4-3: Jumper Locations

Before the NANO-945GSE is installed in the system, the jumpers must be set in accordance with the desired configuration. The jumpers on the NANO-945GSE are listed in **Table 4-1**.

Description	Label	Type
AT Power Mode Setting	ATXCTL1	2-pin header
CF Card Setting	JCF1	2-pin header
Clear CMOS	J_CMOS1	3-pin header
COM2 Mode Setting	JP1	6-pin header
LVDS1 Panel Resolution	J_LCD_TYPE1	8-pin header
LVDS1 Voltage Select	J_VLVDS1	3-pin header
LVDS2 Voltage Select	J_VLVDS2	3-pin header
PCI-104 VIO Select	JP2	3-pin header

Table 4-1: Jumpers

4.5.1 AT Power Select Jumper Settings


NOTE:

The AT Power Select Jumper is the same as the ATX Enable connector.

- Jumper Label:** ATXCTI1
- Jumper Type:** 3-pin header
- Jumper Settings:** See **Table 4-2**
- Jumper Location:** See **Figure 4-4**

The AT Power Select jumper specifies the systems power mode as AT or ATX. Use a jumper cap to short pin 1 - pin 2 on the ATXCTL1 connector to enable the AT Power mode on the system. In the ATX mode use the PS_ON- and 5VSB cable. AT Power Select jumper settings are shown in **Table 4-2**.

NANO-945GSE EPIC Motherboard

AT Power Select	Description	
Short 1 – 2	Use AT power	Default
Open	Use ATX power	

Table 4-2: AT Power Select Jumper Settings

The location of the AT Power Select jumper is shown in Figure 4-4 below.

ATXCTL1




Figure 4-4: AT Power Select Jumper Location

4.5.2 CF Card Setup


Jumper Label:	JCF1
Jumper Type:	2-pin header
Jumper Settings:	See Table 4-3
Jumper Location:	See Figure 4-5

The CF Card Setup jumper sets the CF Type I card or CF Type II cards as either the slave device or the master device. CF Card Setup jumper settings are shown in Table 4-3.

CF Card Setup	Description	
Open	Slave	Default
Closed	Master	

Table 4-3: CF Card Setup Jumper Settings

The CF Card Setup jumper location is shown in Figure 4-5.


Figure 4-5: CF Card Setup Jumper Location

4.5.3 Clear CMOS Jumper

Jumper Label:	J_CMOS1
Jumper Type:	3-pin header
Jumper Settings:	See Table 4-4
Jumper Location:	See Figure 4-6

If the NANO-945GSE fails to boot due to improper BIOS settings, the clear CMOS jumper clears the CMOS data and resets the system BIOS information. To do this, use the jumper cap to close pins 2 and 3 for a few seconds then reinstall the jumper clip back to pins 1 and 2.

If the “CMOS Settings Wrong” message is displayed during the boot up process, the fault may be corrected by pressing the F1 to enter the CMOS Setup menu. Do one of the following:

- Enter the correct CMOS setting

NANO-945GSE EPIC Motherboard

- Load Optimal Defaults
- Load Failsafe Defaults.

After having done one of the above, save the changes and exit the CMOS Setup menu.

The clear CMOS jumper settings are shown in **Table 4-4**.

AT Power Select	Description	
Short 1 - 2	Keep CMOS Setup	Default
Short 2 - 3	Clear CMOS Setup	

Table 4-4: Clear CMOS Jumper Settings

The location of the clear CMOS jumper is shown in **Figure 4-6** below.




Figure 4-6: Clear CMOS Jumper

4.5.4 COM 2 Function Select Jumper

- Jumper Label:** JP1
- Jumper Type:** 6-pin header
- Jumper Settings:** See **Table 4-5**
- Jumper Location:** See **Figure 4-7**

The COM 2 Function Select jumper sets the communication protocol used by the second serial communications port (COM 2) as RS-232, RS-422 or RS-485. The COM 2 Function Select settings are shown in **Table 4-5**.

COM 2 Function Select	Description	
Short 1-2	RS-232	Default
Short 3-4	RS-422	
Short 5-6	RS-485	

Table 4-5: COM 2 Function Select Jumper Settings

The COM 2 Function Select jumper location is shown in **Figure 4-7**.




Figure 4-7: COM 2 Function Select Jumper Location

4.5.5 LVDS1 Panel Resolution Jumper

Jumper Label:	J_LCD_TYPE1
Jumper Type:	8-pin header
Jumper Settings:	See Table 4-6
Jumper Location:	See Figure 4-8

The LVDS1 Panel Resolution jumper allows the resolution of the LVDS screens connected to the LVDS1 connector to be configured. The LVDS1 Panel Resolution jumper settings are shown in Table 4-6.

NANO-945GSE EPIC Motherboard

DESCRIPTION (LVDS1)		
Pin 1-2	Pin 3-4	LVDS1
OFF	OFF	800 x 600 (18-bit)
ON	OFF	024 x 768 (18-bit)
OFF	ON	1280 x 1024 (36-bit)
ON	ON	1400 x 1050 (36-bit)
DESCRIPTION (LVDS2)		
Pin 5-6	Pin 7-8	LVDS2
OFF	OFF	1024 X 768 (18-bit)
ON	OFF	1024 X 768 (24-bit)
OFF	ON	1280X1024 (36-bit)
ON	ON	1280X1024 (48-bit)

Table 4-6: LVDS Panel Resolution Jumper Settings

The LVDS Panel Resolution jumper location. is shown in Figure 4-8.




Figure 4-8:LVDS Panel Resolution Jumper Pinout Locations

4.5.6 LVDS Voltage Selection



WARNING:

Permanent damage to the screen and NANO-945GSE may occur if the wrong voltage is selected with this jumper. Please refer to the user guide that came with the monitor to select the correct voltage.

Jumper Label:	J_VLVDS1 and J_VLVDS2
Jumper Type:	3-pin header
Jumper Settings:	See Table 4-7
Jumper Location:	See Figure 4-9

The **LVDS Voltage Selection** jumpers allow the LVDS screen voltages to be set. J_VLVDS1 sets the voltage connected to LVDS1 and J_VLVDS2 sets the voltage for the screen connected to LVDS2. The **LVDS Voltage Selection** jumper settings are shown in **Table 4-7**.

LCD Voltage Select	Description	
Short 1-2	+3.3V LVDS	
Short 2-3	+5V LVDS	Default

Table 4-7: LVDS Voltage Selection Jumper Settings

The LVDS Voltage Selection jumper location. is shown in **Figure 4-9**.

NANO-945GSE EPIC Motherboard




Figure 4-9: LVDS Voltage Selection Jumper Pinout Locations

4.5.7 PCI-104 Voltage Setup

Jumper Label:	JP2
Jumper Type:	3-pin header
Jumper Settings:	See Table 4-8
Jumper Location:	See Figure 5-10

The PCI-104 Voltage Setup jumper settings are shown in Table 4-7.



CAUTION:

The default for this jumper is “All Open” meaning the user must select the voltage to be used.

PCI-104 Voltage Setup	Description	
Short 1-2	+5V	
Short 2-3	+3.3V	

Table 4-8: PCI-104 Voltage Setup Jumper Settings

The PCI-104 Voltage Setup jumper location. is shown in Figure 4-9.




Figure 4-10: PCI-104 Voltage Setup Jumper Pinout Locations

4.6 Chassis Installation

4.6.1 Airflow



WARNING:

Airflow is critical to the cooling of the CPU and other onboard components. The chassis in which the NANO-945GSE must have air vents to allow cool air to move into the system and hot air to move out.

The NANO-945GSE must be installed in a chassis with ventilation holes on the sides allowing airflow to travel through the heat sink surface. In a system with an individual power supply unit, the cooling fan of a power supply can also help generate airflow through the board surface.

NANO-945GSE EPIC Motherboard



NOTE:

IEI has a wide range of backplanes available. Please contact your NANO-945GSE vendor, reseller or an IEI sales representative at sales@iei.com.tw or visit the IEI website (<http://www.ieworld.com.tw>) to find out more about the available chassis.

4.6.2 Motherboard Installation

To install the NANO-945GSE motherboard into the chassis please refer to the reference material that came with the chassis.

4.7 Internal Peripheral Device Connections

4.7.1 Peripheral Device Cables

The cables listed in **Table 4-9** are shipped with the NANO-945GSE.

Quantity	Type
1	Keyboard and Mouse cable
2	SATA drive cable
1	Power cable
1	RS-232 cable

Table 4-9: IEI Provided Cables

Some optional items that can be purchased separately and installed on the NANO-945GSE include:

- Dual port USB cable
- Parallel port cable
- RS-232/422/485 cable
- ATX power cable

- HDTV out cable
- 44-pin 2.5" IDE cable
- 44-pin 2.5"/3.5" IDE cable
- SATA power cable
- 5.1 channel audio kit
- 7.1 channel audio kit

4.7.2 AT Power Connection

Follow the instructions below to connect the NANO-945GSE to an AT power supply.



WARNING:

Disconnect the power supply power cord from its AC power source to prevent a sudden power surge to the NANO-945GSE.

Step 1: **Locate the power cable.** The power cable is shown in the packing list in **Chapter 3.**

Step 2: **Connect the Power Cable to the Motherboard.** Connect the 4-pin (2x2) Molex type power cable connector to the AT power connector on the motherboard. See Figure 4-11.

NANO-945GSE EPIC Motherboard




Figure 4-11: Power Cable to Motherboard Connection

Step 3: Connect Power Cable to Power Supply. Connect one of the 4-pin (1x4) Molex type power cable connectors to an AT power supply. See Figure 4-12.




Figure 4-12: Connect Power Cable to Power Supply

4.7.3 5.1 Channel Audio Kit Installation



NOTE:

This is an optional item that must be ordered separately. For further information please contact the nearest NOVA-9452 distributor, reseller or vendor or contact an iEi sales representative directly. Send any queries to sales@iei.com.tw.

The optional 5.1 channel audio kit connects to the 10-pin audio connector on the NOVA-9452. The audio kit consists of three audio jacks. One audio jack, Mic In, connects to a microphone. The remaining two audio jacks, Line-In and Line-Out, connect to two speakers. To install the audio kit, please refer to the steps below:

NANO-945GSE EPIC Motherboard

- Step 1: Connect the audio kit cable.** The audio kit is shipped with a cable that connects the audio kit to the NOVA-9452. Connect the cable to the connector on the back of the audio kit. Make sure the pins are properly aligned (i.e. pin 1 connects to pin 1).
- Step 2: Locate the audio connector.** The location of the 10-pin audio connector is shown in **Chapter 3**.
- Step 3: Align pin 1.** Align pin 1 on the on-board connector with pin 1 on the audio kit cable connector. Pin 1 on the audio kit cable connector is indicated with a white dot. See image below.




Figure 4-13: 5.1 Channel Audio Kit

- Step 4: Mount the audio kit onto the chassis.** Once the audio kit is connected to the NOVA-9452, secure the audio kit bracket to the system chassis.
- Step 5: Connect the audio devices.** Connect one speaker to the line-in audio jack, one speaker to the line-out audio jack and a microphone to the mic-in audio jack.
- Step 6: Install the driver.** If the 5.1 channel audio kit is used, the ALC655 Realtek codec driver must be installed. Refer to **Chapter 7** for driver installation instructions.

4.7.4 7.1 Channel Audio Kit Installation

**NOTE:**

This is an optional item that must be ordered separately. For further information please contact the nearest NOVA-9452 distributor, reseller or vendor or contact an iEi sales representative directly. Send any queries to sales@iei.com.tw.

The optional 7.1 channel audio kit connects to the 10-pin audio connector on the NOVA-9452. The audio kit consists of five audio jacks. One audio jack, Mic In, connects to a microphone. The remaining four audio jacks, Line-In, Front-Out, Rear-Out, and Center Subwoofer, connect to speakers. To install the audio kit, please refer to the steps below:

- Step 1: Connect the audio kit cable.** The audio kit is shipped with a cable that connects the audio kit to the NOVA-9452. Connect the cable to the connector on the back of the audio kit. Make sure the pins are properly aligned (i.e. pin 1 connects to pin 1).
- Step 2: Locate the audio connector.** The location of the 10-pin audio connector is shown in **Chapter 3**.
- Step 3: Align pin 1.** Align pin 1 on the on-board connector with pin 1 on the audio kit cable connector. Pin 1 on the audio kit cable connector is indicated with a white dot. See **Figure 4-14**.

NANO-945GSE EPIC Motherboard




Figure 4-14: 7.1 Channel Audio Kit

Step 4: Mount the audio kit onto the chassis. Once the audio kit is connected to the NOVA-9452, secure the audio kit bracket to the system chassis.

Step 5: Connect the audio devices. Connect one speaker to the line-in audio jack, one speaker to the line-out audio jack and a microphone to the mic-in audio jack.

Step 6: Install the driver. If the 7.1 channel audio kit is used, the ALC883 Realtek codec driver must be installed. Refer to **Chapter 7** for driver installation instructions.

4.7.5 ATA Flat Cable Connection

The ATA 66/100 flat cable connects to the NANO-945GSE to one or two IDE devices. To connect an IDE HDD to the NANO-945GSE please follow the instructions below.

Step 1: Locate the IDE connector. The location/s of the IDE device connector/s is/are shown in **Chapter 3**.

Step 2: Insert the connector. Connect the IDE cable connector to the onboard connector. See Figure 4-15. A key on the front of the cable connector ensures it

can only be inserted in one direction.




Figure 4-15: IDE Cable Connection

Step 3: **Connect the cable to an IDE device.** Connect the two connectors on the other side of the cable to one or two IDE devices. Make sure that pin 1 on the cable corresponds to pin 1 on the connector.

4.7.6 SATA Drive Connection

The NANO-945GSE is shipped with two SATA drive cables and one SATA drive power cable. To connect the SATA drives to the connectors, please follow the steps below.

Step 1: **Locate the connectors.** The locations of the SATA drive connectors are shown in **Chapter 3**.

Step 2: **Insert the cable connector.** Insert the cable connector into the on-board SATA drive connector until it clips into place. See Figure 4-16.

NANO-945GSE EPIC Motherboard





Figure 4-16: SATA Drive Cable Connection

- Step 3:** **Connect the cable to the SATA disk.** Connect the connector on the other end of the cable to the connector at the back of the SATA drive. See **Figure 4-17**.
- Step 4:** **Connect the SATA power cable.** Connect the SATA power connector to the back of the SATA drive. See **Figure 4-17**.




Figure 4-17: SATA Power Drive Connection

NANO-945GSE EPIC Motherboard

4.7.7 Single RS-232 Cable (w/o Bracket)

The single RS-232 cable consists of one serial port connector attached to a serial communications cable that is then attached to a D-sub 9 male connector. To install the single RS-232 cable, please follow the steps below.

Step 1: Locate the connector. The location of the RS-232 connector is shown in Chapter 3.

Step 2: Insert the cable connector. Insert the connector into the serial port box header. See Figure 4-18. A key on the front of the cable connectors ensures the connector can only be installed in one direction.




Figure 4-18: Single RS-232 Cable Installation

Step 3: Secure the bracket. The single RS-232 connector has two retention screws that must be secured to a chassis or bracket.

Step 4: Connect the serial device. Once the single RS-232 connector is connected to a chassis or bracket, a serial communications device can be connected to the system.

4.7.8 USB Cable (Dual Port without Bracket)

The NANO-945GSE is shipped with a dual port USB 2.0 cable. To connect the USB cable connector, please follow the steps below.

Step 1: Locate the connectors. The locations of the USB connectors are shown in Chapter 3.



WARNING:

If the USB pins are not properly aligned, the USB device can burn out.

Step 2: Align the connectors. The cable has two connectors. Correctly align pin 1 on each cable connector with pin 1 on the NANO-945GSE USB connector.

Step 3: Insert the cable connectors. Once the cable connectors are properly aligned with the USB connectors on the NANO-945GSE, connect the cable connectors to the on-board connectors. See **Figure 4-19**.




Figure 4-19: Dual USB Cable Connection

Step 4: Attach the USB connectors to the chassis. The USB 2.0 connectors each of two retention screw holes. To secure the connectors to the chassis please refer

NANO-945GSE EPIC Motherboard

to the installation instructions that came with the chassis.

4.7.9 Parallel Port Cable without Bracket

The optional parallel port (LPT) cable respectively connects the on-board LPT 26-pin box header to an external LPT device (like a printer). The cable comprises a 26-pin female header, to be connected to the on-board LPT box-header, on one side and on the other side a standard external LPT connector. To connect the LPT cable, please follow the steps below.

Step 1: Locate the connector. The LPT connector location is shown in **Chapter 4**.

Step 2: Align the connectors. Correctly align pin 1 on the cable connector with pin 1 on the PCIE-9452 LPT box-header connector. See Figure 4-20.

Step 3: Insert the cable connectors Once the cable connector is properly aligned with the 26-pin box-header connector on the PCIE-9452, connect the cable connector to the on-board connector. See **Figure 4-20**.




Figure 4-20: LPT Cable Connection

Step 4: Attach the LPT connector to the chassis. To secure the LPT interface connector to the chassis please refer to the installation instructions that came with the chassis.

Step 5: Connect LPT device. Once the LPT interface connector is connected to the chassis, the LPT device can be connected to the LPT interface connector. See

Figure 4-21




Figure 4-21: Connect the LPT Device

4.7.10 Dual RS-422/485 Cables

The NANO-945GSE is shipped with one RS-422/485 dual serial port connector cable. The dual serial port connector cable connects the serial port connectors on the cable to the RS-422/485 serial port connectors on the NANO-945GSE. Follow the steps below to connect the dual serial port connector cable.

Step 1: Locate the serial port connector. The location of the RS-422/485 serial port connector is shown in **Chapter 3**.

Step 2: Align the connectors. Correctly align pin 1 on the cable connector with pin 1 on the NANO-945GSE COM2 serial port connector.

Step 3: Insert the cable connectors Once the cable connector is properly aligned with the COM2 serial port connector on the NANO-945GSE, connect the cable connector to the on-board connectors. See Figure 4-22.

NANO-945GSE EPIC Motherboard




Figure 4-22: Dual Serial Port Connector Cable Connection

Step 4: Attach DB-9 serial port connectors to the chassis. The dual DB-9 serial port connectors can be inserted into dual preformed holes in the chassis. Once, inserted the DB-9 connectors should be secured to the chassis with retention screws.

4.8 External Peripheral Interface Connection

The following external peripheral devices can be connected to the external peripheral interface connectors.

- RJ-45 Ethernet cable connectors
- PS/2 devices
- Serial port devices
- USB devices
- VGA monitors

To install these devices, connect the corresponding cable connector from the actual device to the corresponding NANO-945GSE external peripheral interface connector making sure the pins are properly aligned.

4.8.1 LAN Connection (Single Connector)

There are two external RJ-45 LAN connectors. The RJ-45 connectors enable connection to an external network. To connect a LAN cable with an RJ-45 connector, please follow the instructions below.

Step 1: **Locate the RJ-45 connectors.** The locations of the USB connectors are shown in **Chapter 4**.

Step 2: **Align the connectors.** Align the RJ-45 connector on the LAN cable with one of the RJ-45 connectors on the NANO-945GSE. See **Figure 4-23**.




Figure 4-23: LAN Connection

Step 3: **Insert the LAN cable RJ-45 connector.** Once aligned, gently insert the LAN cable RJ-45 connector into the onboard RJ-45 connector.

4.8.2 PS/2 Y-Cable Connection

The NANO-945GSE has a PS/2 connector on the external peripheral interface panel. The dual PS/2 connector is connected to the PS/2 Y-cable that came with the NANO-945GSE. One of the PS/2 cables is connected to a keyboard and the other to a mouse to the system. Follow the steps below to connect a keyboard and mouse to the NANO-945GSE.

NANO-945GSE EPIC Motherboard

Step 1: Locate the dual PS/2 connector. The location of the PS/2 connector is shown in **Chapter 3**.

Step 2: Insert the keyboard/mouse connector. Insert the PS/2 connector on the end of the PS/2 y-cable into the external PS/2 connector. See **Figure 4-24**.




Figure 4-24: PS/2 Keyboard/Mouse Connector

Step 3: Connect the keyboard and mouse. Connect the keyboard and mouse to the appropriate connector. The keyboard and mouse connectors can be distinguished from each other by looking at the small graphic at the top of the connector.

4.8.3 Serial Device Connection

The NANO-945GSE has a single female DB-9 connector on the external peripheral interface panel for a serial device. Follow the steps below to connect a serial device to the NANO-945GSE.

Step 1: Locate the DB-9 connector. The location of the DB-9 connector is shown in

Chapter 3.

Step 2: Insert the serial connector. Insert the DB-9 connector of a serial device into the DB-9 connector on the external peripheral interface. See Figure 4-25.




Figure 4-25: Serial Device Connector

Step 3: Secure the connector. Secure the serial device connector to the external interface by tightening the two retention screws on either side of the connector....

4.8.4 USB Connection (Dual Connector)

The external USB Series "A" receptacle connectors provide easier and quicker access to external USB devices. Follow the steps below to connect USB devices to the NANO-945GSE.

Step 1: Locate the USB Series "A" receptacle connectors. The location of the USB Series "A" receptacle connectors are shown in **Chapter 3**.

Step 2: Insert a USB Series "A" plug. Insert the USB Series "A" plug of a device into the USB Series "A" receptacle on the external peripheral interface. See **Figure**

NANO-945GSE EPIC Motherboard

4-26.




Figure 4-26: USB Connector

4.8.5 VGA Monitor Connection

The NANO-945GSE has a single female DB-15 connector on the external peripheral interface panel. The DB-15 connector is connected to a CRT or VGA monitor. To connect a monitor to the NANO-945GSE, please follow the instructions below.

- Step 1:** **Locate the female DB-15 connector.** The location of the female DB-15 connector is shown in **Chapter 3**.
- Step 2:** **Align the VGA connector.** Align the male DB-15 connector on the VGA screen cable with the female DB-15 connector on the external peripheral interface.
- Step 3:** **Insert the VGA connector.** Once the connectors are properly aligned with the insert the male connector from the VGA screen into the female connector on the NANO-945GSE. See **Figure 4-27**.




Figure 4-27: VGA Connector

Secure the connector. Secure the DB-15 VGA connector from the VGA monitor to the external interface by tightening the two retention screws on either side of the connector.

Chapter

5

BIOS Screens

5.1 Introduction

A licensed copy of AMI BIOS is preprogrammed into the ROM BIOS. The BIOS setup program allows users to modify the basic system configuration. This chapter describes how to access the BIOS setup program and the configuration options that may be changed.

5.1.1 Starting Setup

The AMI BIOS is activated when the computer is turned on. The setup program can be activated in one of two ways.

1. Press the **DELETE** key as soon as the system is turned on or
2. Press the **DELETE** key when the “**Press Del to enter SETUP**” message appears on the screen. 0.

If the message disappears before the **DELETE** key is pressed, restart the computer and try again.

5.1.2 Using Setup

Use the arrow keys to highlight items, press **ENTER** to select, use the PageUp and PageDown keys to change entries, press **F1** for help and press **ESC** to quit. Navigation keys are shown in.

Key	Function
Up arrow	Move to previous item
Down arrow	Move to next item
Left arrow	Move to the item on the left hand side
Right arrow	Move to the item on the right hand side
Esc key	Main Menu – Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
Page Up key	Increase the numeric value or make changes
Page Dn key	Decrease the numeric value or make changes

NANO-945GSE EPIC Motherboard

F1 key	General help, only for Status Page Setup Menu and Option Page Setup Menu
F2 /F3 key	Change color from total 16 colors. F2 to select color forward.
F10 key	Save all the CMOS changes, only for Main Menu

Table 5-1: BIOS Navigation Keys

5.1.3 Getting Help

When **F1** is pressed a small help window describing the appropriate keys to use and the possible selections for the highlighted item appears. To exit the Help Window press **Esc** or the **F1** key again.

5.1.4 Unable to Reboot After Configuration Changes

If the computer cannot boot after changes to the system configuration is made, CMOS defaults. Use the jumper described in **Chapter 5**.

5.1.5 BIOS Menu Bar

The **menu bar** on top of the BIOS screen has the following main items:


- **Main** Changes the basic system configuration.
- **Advanced** Changes the advanced system settings.
- **PCIPnP** Changes the advanced PCI/PnP Settings
- **Boot** Changes the system boot configuration.
- **Security** Sets User and Supervisor Passwords.
- **Chipset** Changes the chipset settings.
- **Power** Changes power management settings.
- **Exit** Selects exit options and loads default settings

The following sections completely describe the configuration options found in the menu items at the top of the BIOS screen and listed above.

5.2 Main

The **Main** BIOS menu (**BIOS Menu 1**) appears when the **BIOS Setup** program is entered.

The **Main** menu gives an overview of the basic system information.



BIOS Menu 1: Main

→ System Overview

The **System Overview** lists a brief summary of different system components. The fields in

System Overview cannot be changed. The items shown in the system overview include:

- **AMI BIOS:** Displays auto-detected BIOS information
 - Version: Current BIOS version
 - Build Date: Date the current BIOS version was made
 - ID: Installed BIOS ID
- **Processor:** Displays auto-detected CPU specifications
 - Type: Names the currently installed processor
 - Speed: Lists the processor speed

NANO-945GSE EPIC Motherboard

- Count: The number of CPUs on the motherboard
- **System Memory:** Displays the auto-detected system memory.
- Size: Lists memory size

The **System Overview** field also has two user configurable fields:

→ **System Time [xx:xx:xx]**

Use the **System Time** option to set the system time. Manually enter the hours, minutes and seconds.

→ **System Date [xx/xx/xx]**

Use the **System Date** option to set the system date. Manually enter the day, month and year.

5.3 Advanced


Use the **Advanced** menu (**BIOS Menu 2**) to configure the CPU and peripheral devices through the following sub-menus:



WARNING:

Setting the wrong values in the sections below may cause the system to malfunction. Make sure that the settings made are compatible with the hardware.

- CPU Configuration (see Section 5.3.1)
- IDE Configuration (see Section 5.3.2)
- SuperIO Configuration (see Section 5.3.3)
- Hardware Health Configuration (see Section 5.3.4)
- Power Configuration (see Section 5.3.5)
- Remote Access Configuration (see Section 5.3.5.2)
- USB Configuration (see Section 5.3.7)




BIOS Menu 2: Advanced

5.3.1 CPU Configuration

Use the **CPU Configuration** menu (BIOS Menu 3) to view detailed CPU specifications and configure the CPU.

NANO-945GSE EPIC Motherboard




BIOS Menu 3: CPU Configuration

The CPU Configuration menu (BIOS Menu 3) lists the following CPU details:

- **Manufacturer:** Lists the name of the CPU manufacturer
- **Brand String:** Lists the brand name of the CPU being used
- **Frequency:** Lists the CPU processing speed
- **FSB Speed:** Lists the FSB speed
- **Cache L1:** Lists the CPU L1 cache size
- **Cache L2:** Lists the CPU L2 cache size

5.3.2 IDE Configuration

Use the **IDE Configuration** menu (**BIOS Menu 4**) to change and/or set the configuration of the IDE devices installed in the system.




BIOS Menu 4: IDE Configuration

→ ATA/IDE Configurations [Compatible]

Use the **ATA/IDE Configurations** option to configure the ATA/IDE controller.

- **Disabled** Disables the on-board ATA/IDE controller.
- **Compatible** Configures the on-board ATA/IDE controller to be in compatible mode. In this mode, a SATA channel will replace one of the IDE channels. This mode supports up to 4 storage devices.
- **Enhanced** **DEFAULT** Configures the on-board ATA/IDE controller to be in Enhanced mode. In this mode, IDE channels and SATA channels are separated. This mode supports up to 6 storage devices. Some legacy OS do not support this mode.



BIOS Menu 5: IDE Master and IDE Slave Configuration

→ Auto-Detected Drive Parameters

The “grayed-out” items in the left frame are IDE disk drive parameters automatically detected from the firmware of the selected IDE disk drive. The drive parameters are listed as follows:

- **Device:** Lists the device type (e.g. hard disk, CD-ROM etc.)
- **Type:** Indicates the type of devices a user can manually select
- **Vendor:** Lists the device manufacturer
- **Size:** List the storage capacity of the device.
- **LBA Mode:** Indicates whether the LBA (Logical Block Addressing) is a method of addressing data on a disk drive is supported or not.
- **Block Mode:** Block mode boosts IDE drive performance by increasing the amount of data transferred. Only 512 bytes of data can be transferred per

NANO-945GSE EPIC Motherboard

interrupt if block mode is not used. Block mode allows transfers of up to 64 KB per interrupt.

- **PIO Mode:** Indicates the PIO mode of the installed device.
- **Async DMA:** Indicates the highest Asynchronous DMA Mode that is supported.
- **Ultra DMA:** Indicates the highest Synchronous DMA Mode that is supported.
- **S.M.A.R.T.:** Indicates whether or not the Self-Monitoring Analysis and Reporting Technology protocol is supported.
- **32Bit Data Transfer:** Enables 32-bit data transfer.

→ Type [Auto]

Use the **Type** BIOS option select the type of device the AMIBIOS attempts to boot from after the Power-On Self-Test (POST) is complete.

→ **Not Installed** BIOS is prevented from searching for an IDE disk drive on the specified channel.

→ **Auto** **DEFAULT** The BIOS auto detects the IDE disk drive type attached to the specified channel. This setting should be used if an IDE hard disk drive is attached to the specified channel.

→ **CD/DVD** The CD/DVD option specifies that an IDE CD-ROM drive is attached to the specified IDE channel. The BIOS does not attempt to search for other types of IDE disk drives on the specified channel.

→ **ARMD** This option specifies an ATAPI Removable Media Device. These include, but are not limited to:

→ **ZIP**

→ **LS-120**

→ LBA/Large Mode [Auto]

Use the **LBA/Large Mode** option to disable or enable BIOS to auto detects LBA (Logical Block Addressing). LBA is a method of addressing data on a disk drive. In LBA mode, the maximum drive capacity is 137 GB.

→ Disabled BIOS is prevented from using the LBA mode control on the specified channel.

→ Auto **DEFAULT** BIOS auto detects the LBA mode control on the specified channel.

→ Block (Multi Sector Transfer) [Auto]

Use the **Block (Multi Sector Transfer)** to disable or enable BIOS to auto detect if the device supports multi-sector transfers.

→ Disabled BIOS is prevented from using Multi-Sector Transfer on the specified channel. The data to and from the device occurs one sector at a time.

→ Auto **DEFAULT** BIOS auto detects Multi-Sector Transfer support on the drive on the specified channel. If supported the data transfer to and from the device occurs multiple sectors at a time.

→ PIO Mode [Auto]

Use the **PIO Mode** option to select the IDE PIO (Programmable I/O) mode program timing cycles between the IDE drive and the programmable IDE controller. As the PIO mode increases, the cycle time decreases.

→ Auto **DEFAULT** BIOS auto detects the PIO mode. Use this value if the IDE disk drive support cannot be determined.

NANO-945GSE EPIC Motherboard

- 0 PIO mode 0 selected with a maximum transfer rate of 3.3MBps
- 1 PIO mode 1 selected with a maximum transfer rate of 5.2MBps
- 2 PIO mode 2 selected with a maximum transfer rate of 8.3MBps
- 3 PIO mode 3 selected with a maximum transfer rate of 11.1MBps
- 4 PIO mode 4 selected with a maximum transfer rate of 16.6MBps
(This setting generally works with all hard disk drives manufactured after 1999. For other disk drives, such as IDE CD-ROM drives, check the specifications of the drive.)

→ DMA Mode [Auto]

Use the **DMA Mode** BIOS selection to adjust the DMA mode options.

- **Auto** **DEFAULT** BIOS auto detects the DMA mode. Use this value if the IDE disk drive support cannot be determined.
- **SWDMA0** Single Word DMA mode 0 selected with a maximum data transfer rate of 2.1MBps
- **SWDMA1** Single Word DMA mode 1 selected with a maximum data transfer rate of 4.2MBps
- **SWDMA2** Single Word DMA mode 2 selected with a maximum data transfer rate of 8.3MBps
- **MWDMA0** Multi Word DMA mode 0 selected with a maximum data transfer rate of 4.2MBps
- **MWDMA1** Multi Word DMA mode 1 selected with a maximum data transfer rate of 13.3MBps
- **MWDMA2** Multi Word DMA mode 2 selected with a maximum data transfer rate of 16.6MBps

- **UDMA1** Ultra DMA mode 0 selected with a maximum data transfer rate of 16.6MBps
- **UDMA1** Ultra DMA mode 1 selected with a maximum data transfer rate of 25MBps
- **UDMA2** Ultra DMA mode 2 selected with a maximum data transfer rate of 33.3MBps
- **UDMA3** Ultra DMA mode 3 selected with a maximum data transfer rate of 44MBps (To use this mode, it is required that an 80-conductor ATA cable is used.)
- **UDMA4** Ultra DMA mode 4 selected with a maximum data transfer rate of 66.6MBps (To use this mode, it is required that an 80-conductor ATA cable is used.)
- **UDMA5** Ultra DMA mode 5 selected with a maximum data transfer rate of 99.9MBps (To use this mode, it is required that an 80-conductor ATA cable is used.)

→ **S.M.A.R.T [Auto]**

Use the **S.M.A.R.T** option to auto-detect, disable or enable Self-Monitoring Analysis and Reporting Technology (SMART) on the drive on the specified channel. **S.M.A.R.T** predicts impending drive failures. The **S.M.A.R.T** BIOS option enables or disables this function.

- **Auto** **DEFAULT** BIOS auto detects HDD SMART support.
- **Disabled** Prevents BIOS from using the HDD SMART feature.
- **Enabled** Allows BIOS to use the HDD SMART feature

→ **32Bit Data Transfer [Enabled]**


Use the **32Bit Data Transfer** BIOS option to enables or disable 32-bit data transfers.

NANO-945GSE EPIC Motherboard

- ➔ **Disabled** Prevents the BIOS from using 32-bit data transfers.
- ➔ **Enabled** **DEFAULT** Allows BIOS to use 32-bit data transfers on supported hard disk drives.

5.3.3 Super IO Configuration

Use the **Super IO Configuration** menu (**BIOS Menu 6**) to set or change the configurations for the FDD controllers, parallel ports and serial ports.



BIOS Menu 6: Super IO Configuration

- ➔ **Parallel Port Address [Disabled]**

Use the **Parallel Port Address** option to select the parallel port base address.

- ➔ **Disabled** **DEFAULT** No base address is assigned to the Parallel Port
- ➔ **378** Parallel Port I/O port address is 378

- 278 Parallel Port I/O port address is 278
- 3BC Parallel Port I/O port address is 3BC

→ **Parallel Port Mode [Normal]**

Use the **Parallel Port Mode** option to select the mode the parallel port operates in.

- **Normal** **DEFAULT** The normal parallel port mode is the standard mode for parallel port operation.
- **EPP** The parallel port operates in the enhanced parallel port mode (EPP). The EPP mode supports bi-directional communication between the system and the parallel port device and the transmission rates between the two are much faster than the Normal mode.
- **ECP+EPP** The parallel port operates in the extended capabilities port (ECP) mode. The ECP mode supports bi-directional communication between the system and the parallel port device and the transmission rates between the two are much faster than the Normal mode

The parallel port is also be compatible with EPP devices described above

→ **Parallel Port IRQ [IRQ7]**

Use the **Parallel Port IRQ** selection to set the parallel port interrupt address.

- **IRQ5** IRQ5 is assigned as the parallel port interrupt address
- **IRQ7** **DEFAULT** IRQ7 is assigned as the parallel port interrupt address

NANO-945GSE EPIC Motherboard

→ Serial Port1 Address [3F8/IRQ4]

Use the **Serial Port1 Address** option to select the Serial Port 1 base address.

- **Disabled** No base address is assigned to Serial Port 1
- **3F8/IRQ4** **DEFAULT** Serial Port 1 I/O port address is 3F8 and the interrupt address is IRQ4
- **3E8/IRQ4** Serial Port 1 I/O port address is 3E8 and the interrupt address is IRQ4
- **2E8/IRQ3** Serial Port 1 I/O port address is 2E8 and the interrupt address is IRQ3

→ Serial Port1 Mode [Normal]

Use the **Serial Port1 Mode** option to select the transmitting and receiving mode for the first serial port.

- **Normal** **DEFAULT** Serial Port 1 mode is normal
- **IrDA** Serial Port 1 mode is IrDA
- **ASK IR** Serial Port 1 mode is ASK IR

→ Serial Port2 Address [2F8/IRQ3]

Use the **Serial Port2 Address** option to select the Serial Port 2 base address.

- **Disabled** No base address is assigned to Serial Port 2
- **2F8/IRQ3** **DEFAULT** Serial Port 2 I/O port address is 3F8 and the interrupt address is IRQ3
- **3E8/IRQ4** Serial Port 2 I/O port address is 3E8 and the interrupt address is IRQ4

→ **2E8/IRQ3** Serial Port 2 I/O port address is 2E8 and the interrupt address is IRQ3

→ **Serial Port2 Mode [Normal]**

Use the **Serial Port2 Mode** option to select the Serial Port2 operational mode.

→ **Normal** **DEFAULT** Serial Port 2 mode is normal

→ **IrDA** Serial Port 2 mode is IrDA

→ **ASK IR** Serial Port 2 mode is ASK IR

→ **Serial Port3 Address [3E8]**

Use the **Serial Port3 Address** option to select the base addresses for serial port 3

→ **Disabled** No base address is assigned to serial port 3

→ **3E8** **DEFAULT** Serial port 3 I/O port address is 3E8

→ **2E8** Serial port 3 I/O port address is 2E8

→ **2F0** Serial port 3 I/O port address is 2F0

→ **2E0** Serial port 3 I/O port address is 2E0

→ **Serial Port3 IRQ [11]**

Use the **Serial Port3 IRQ** option to select the interrupt address for serial port 3.

→ **10** Serial port 3 IRQ address is 10

→ **11** **DEFAULT** Serial port 3 IRQ address is 11

→ **Serial Port4 Address [2E8]**

Use the **Serial Port4 IRQ** option to select the interrupt address for serial port 4.

NANO-945GSE EPIC Motherboard

- **Disabled** No base address is assigned to serial port 3
- **3E8** Serial port 4 I/O port address is 3E8
- **2E8** **DEFAULT** Serial port 4 I/O port address is 2E8
- **2F0** Serial port 4 I/O port address is 2F0
- **2E0** Serial port 4 I/O port address is 2E0


→ **Serial Port4 IRQ [10]**

Use the **Serial Port4 IRQ** option to select the interrupt address for serial port 4.

- **10** **DEFAULT** Serial port 4 IRQ address is 10
- **11** Serial port 4 IRQ address is 11

5.3.4 Hardware Health Configuration

The **Hardware Health Configuration** menu (**BIOS Menu 7**) shows the operating temperature, fan speeds and system voltages.



BIOS Menu 7: Hardware Health Configuration

→ CPU FAN Mode Setting [Full On Mode]

Use the **CPU FAN Mode Setting** option to configure the second fan.

- **Full On Mode** **DEFAULT** Fan is on all the time
- **Automatic mode** Fan is off when the temperature is low enough. Parameters must be set by the user.
- **PWM Manual mode** Pulse width modulation set manually

When the **CPU FAN Mode Setting** option is in the **Automatic Mode**, the following parameters can be set.

- CPU Temp. Limit of OFF
- CPU Temp. Limit of Start

NANO-945GSE EPIC Motherboard

- CPU Fan Start PWM
- Slope PWM 1

When the **CPU FAN Mode Setting** option is in the **PWM Manual Mode**, the following parameters can be set.

- CPU Fan PWM control

→ CPU Temp. Limit of OFF [000]



WARNING:

Setting this value too high may cause the fan to stop when the CPU is at a high temperature and therefore cause the system to be damaged.

The **CPU Temp. Limit of OFF** option can only be set if the **CPU FAN Mode Setting** option is set to **Automatic Mode**. Use the **CPU Temp. Limit of OFF** option to select the CPU temperature at which the cooling fan should automatically turn off. To select a value, select the **CPU Temp. Limit of OFF** option and enter a decimal number between 000 and 127. The temperature range is specified below.

- Minimum Value: 0°C
- Maximum Value: 127°C

→ CPU Temp. Limit of Start [020]



WARNING:

Setting this value too high may cause the fan to start only when the CPU is at a high temperature and therefore cause the system to be damaged.

The **CPU Temp. Limit of Start** option can only be set if the **CPU FAN Mode Setting** option is set to **Automatic Mode**. Use the **CPU Temp. Limit of Start** option to select the CPU temperature at which the cooling fan should automatically turn on. When the fan starts, it rotates using the starting pulse width modulation (PWM) specified in the **Fan 3 Start PWM** option below. To select a value, select the **CPU Temp. Limit of Start** option and enter a decimal number between 000 and 127. The temperature range is specified below.

- Minimum Value: 0°C
- Maximum Value: 127°C

→ **CPU Fan Start PWM [070]**

The **Fan 3 Start PWM** option can only be set if the **CPU FAN Mode Setting** option is set to **Automatic Mode**. Use the **Fan 3 Start PWM** option to select the PWM mode the fan starts to rotate with after the temperature specified in the **Temperature 3 Limit of Start** is exceeded. The Super I/O chipset supports 128 PWM modes. To select a value, select the **Fan 3 Start PWM** option and enter a decimal number between 000 and 127. The temperature range is specified below.

- PWM Minimum Mode: 0
- PWM Maximum Mode: 127

→ **Slope PWM [0.5 PWM]**

The **Slope PWM 1** option can only be set if the **CPU FAN Mode Setting** option is set to **Automatic Mode**. Use the **Slope PWM 1** option to select the linear rate at which the PWM mode increases with respect to an increase in temperature. A list of available options is shown below:

- 0 PWM
- 1 PWM
- 2 PWM
- 4 PWM
- 8 PWM

NANO-945GSE EPIC Motherboard


- 16 PWM
- 32 PWM
- 64 PWM

The following system parameters and values are shown. The system parameters that are monitored are:

- **System Temperatures:** The following system temperatures are monitored
 - CPU Temperature
 - System Temperature
- **Fan Speeds:** The CPU cooling fan speed is monitored.
 - CPU Fan Speed
- **Voltages:** The following system voltages are monitored
 - CPU Core
 - +1.05V
 - +3.30V
 - +12.0 V
 - +1.5V
 - +1.8V
 - 5VSB
 - VBAT

5.3.5 Power Configuration

The **Power Configuration** menu (BIOS Menu 8) configures the Advanced Configuration and Power Interface (ACPI) and Power Management (APM) options.




BIOS Menu 8: Power Configuration

5.3.5.1 ACPI configuration

The **ACPI Configuration** menu (**BIOS Menu 9**) configures the Advanced Configuration and Power Interface (ACPI).

NANO-945GSE EPIC Motherboard



BIOS Menu 9: ACPI Configuration


→ Suspend Mode [S1(POS)]

Use the **Suspend Mode** BIOS option to specify the sleep state the system enters when it is not being used.

- **S1 (POS) DEFAULT** System appears off. The CPU is stopped; RAM is refreshed; the system is running in a low power mode.
- **S3 (STR)** System appears off. The CPU has no power; RAM is in slow refresh; the power supply is in a reduced power mode.

5.3.5.2 APM Configuration

The **APM Configuration** menu (**BIOS Menu 10**) allows the advanced power management options to be configured.



BIOS Menu 10: Advanced Power Management Configuration

→ Restore on AC Power Loss [Last State]

Use the **Restore on AC Power Loss** BIOS option to specify what state the system returns to if there is a sudden loss of power to the system.

- **Power Off** The system remains turned off
- **Power On** The system turns on
- **Last State DEFAULT** The system returns to its previous state. If it was on, it turns itself on. If it was off, it remains off.

→ Power Button Mode [On/Off]

Use the **Power Button Mode** BIOS to specify how the power button functions.

- **On/Off DEFAULT** When the power button is pressed the system is either

NANO-945GSE EPIC Motherboard

turned on or off

- **Suspend** When the power button is pressed the system goes into suspend mode

→ **Resume on Keyboard/Mouse [Disabled]**

Use the **Resume on Keyboard/Mouse** BIOS option to enable activity on either the keyboard or mouse to rouse the system from a suspend or standby state. That is, the system is roused when the mouse is moved or a button on the keyboard is pressed.

- **Disabled** (Default) Wake event not generated by activity on the keyboard or mouse
- **Enabled** Wake event generated by activity on the keyboard or mouse

→ **Resume on Ring [Disabled]**

Use the **Resume on Ring** BIOS option to enable activity on the RI (ring in) modem line to rouse the system from a suspend or standby state. That is, the system will be roused by an incoming call on a modem.

- **Disabled** **DEFAULT** Wake event not generated by an incoming call
- **Enabled** Wake event generated by an incoming call

→ **Resume on PCI-Express WAKE# [Enabled]**

Use the **Resume PCI-Express WAKE#** BIOS option to enable activity on the PCI-Express WAKE# signal to rouse the system from a suspend or standby state.

- **Disabled** Wake event not generated by PCI-Express WAKE# signal activity
- **Enabled** **DEFAULT** Wake event generated by PCI-Express WAKE# signal

activity

→ **Resume On RTC Alarm [Disabled]**

Use the **Resume On RTC Alarm** option to specify the time the system should be roused from a suspended state.

→ **Disabled** **DEFAULT** The real time clock (RTC) cannot generate a wake event

→ **Enabled** If selected, the following appears with values that can be selected:

→ **RTC Alarm Date (Days)**


→ **System Time**

After setting the alarm, the computer turns itself on from a suspend state when the alarm goes off.

5.3.6 Remote Configuration

Use the **Remote Access Configuration** menu (**BIOS Menu 11**) to configure remote access parameters. The **Remote Access Configuration** is an AMIBIOS feature and allows a remote host running a terminal program to display and configure the BIOS settings.

NANO-945GSE EPIC Motherboard



BIOS Menu 11: Remote Access Configuration [Advanced]

→ Remote Access [Disabled]

Use the **Remote Access** option to enable or disable access to the remote functionalities of the system.

→ **Disabled** **DEFAULT** Remote access is disabled.

→ **Enabled** Remote access configuration options shown below appear:

- **Serial Port Number**
- **Serial Port Mode**
- **Flow Control**
- **Redirection after BIOS POST**

→ Terminal Type

→ VT-UTF8 Combo Key Support

These configuration options are discussed below.

→ Serial Port Number [COM1]

Use the **Serial Port Number** option allows to select the serial port used for remote access.

→ COM1 DEFAULT System is remotely accessed through COM1

→ COM2 System is remotely accessed through COM2

NOTE: Make sure the selected COM port is enabled through the Super I/O configuration menu.

→ Base Address, IRQ [2F8h,3]

The **Base Address, IRQ** option cannot be configured and only shows the interrupt address of the serial port listed above.

→ Serial Port Mode [115200 8,n,1]

Use the **Serial Port Mode** option to select baud rate through which the console redirection is made. The following configuration options are available

- 115200 8,n,1 DEFAULT
- 57600 8,n,1
- 38400 8,n,1
- 19200 8,n,1
- 09600 8,n,1



NOTE:

Identical baud rate setting must be set on the host (a management computer running a terminal software) and the slave

NANO-945GSE EPIC Motherboard

→ Flow Control [None]

Use the **Flow Control** option to report the flow control method for the console redirection application.

- **None** **DEFAULT** No control flow,
- **Hardware** Hardware is set as the console redirection
- **Software** Software is set as the console redirection

→ Redirection After BIOS POST [Always]

Use the **Redirection After BIOS POST** option to specify when console redirection should occur.

- **Disabled** The console is not redirected after POST
- **Boot Loader** Redirection is active during POST and during Boot Loader
- **Always** **DEFAULT** Redirection is always active (Some Oses may not work if set to Always)

→ Terminal Type [ANSI]

Use the **Terminal Type** BIOS option to specify the remote terminal type.

- **ANSI** **DEFAULT** The target terminal type is ANSI
- **VT100** The target terminal type is VT100
- **VT-UTF8** The target terminal type is VT-UTF8

→ VT-UTF8 Combo Key Support [Disabled]

Use the **VT-UFT8 Combo Key Support** option to enable additional keys that are not provided by VT100 for the PC 101 keyboard.

The VT100 Terminal Definition is the standard convention used to configure and conduct emergency management tasks with UNIX-based servers. VT100 does not support all keys on the standard PC 101-key layout, however. The VT-UTF8 convention makes available additional keys that are not provided by VT100 for the PC 101 keyboard.

- **Disabled** **DEFAULT** Disables the VT-UTF8 terminal keys
- **Enabled** Enables the VT-UTF8 combination key. Support for ANSI/VT100 terminals

→ **Sredir Memory Display Delay [Disabled]**


Use the **Sredir Memory Display Delay** option to select the delay before memory information is displayed. Configuration options are listed below

- No Delay **DEFAULT**
- Delay 1 sec
- Delay 2 sec
- Delay 4 sec

5.3.7 USB Configuration

Use the **USB Configuration** menu (**BIOS Menu 12**) to read USB configuration information and configure the USB settings.

NANO-945GSE EPIC Motherboard



BIOS Menu 12: USB Configuration

→ USB Functions [Enabled]

Use the **USB Function** option to enable or disable the USB controllers.

- **Disabled** USB controllers are enabled
- **Enabled** **DEFAULT** USB controllers are disabled

→ USB 2.0 Controller [Enabled]

The **USB 2.0 Controller** BIOS option enables or disables the USB 2.0 controller

- **Disabled** USB function disabled
- **Enabled** **DEFAULT** USB function enabled

→ USB2.0 Controller Mode [HiSpeed]

The **USB2.0 Controller Mode** BIOS option sets the speed of the USB2.0 controller.

- ➔ **FullSpeed** The controller is capable of operating at full speed
12 Mb/s
- ➔ **HiSpeed DEFAULT** The controller is capable of operating at high speed
480 Mb/s

➔ **Legacy USB Support [Enabled]**

Use the **Legacy USB Support** BIOS option to enable USB mouse and USB keyboard support.

Normally if this option is not enabled, any attached USB mouse or USB keyboard does not become available until a USB compatible operating system is fully booted with all USB drivers loaded. When this option is enabled, any attached USB mouse or USB keyboard can control the system even when there is no USB driver loaded onto the system.

- ➔ **Disabled** Legacy USB support disabled
- ➔ **Enabled DEFAULT** Legacy USB support enabled
- ➔ **Auto** Legacy USB support disabled if no USB devices are
connected


5.4 PCI/PnP

Use the PCI/PnP menu (BIOS Menu 13) to configure advanced PCI and PnP settings.



WARNING:

Setting wrong values for the BIOS selections in the PCIPnP BIOS menu may cause the system to malfunction.



BIOS Menu 13: PCI/PnP Configuration

→ IRQ# [Available]

Use the **IRQ#** address to specify what IRQs can be assigned to a particular peripheral device.

- **Available** **DEFAULT** The specified IRQ is available to be used by PCI/PnP devices
- **Reserved** The specified IRQ is reserved for use by Legacy ISA devices

Available IRQ addresses are:

- IRQ3
- IRQ4
- IRQ5
- IRQ7
- IRQ9

- IRQ10
- IRQ 11
- IRQ 14
- IRQ 15

→ **DMA Channel# [Available]**

Use the **DMA Channel#** option to assign a specific DMA channel to a particular PCI/PnP device.

- | | | | |
|---|------------------|----------------|--|
| → | Available | DEFAULT | The specified DMA is available to be used by PCI/PnP devices |
| → | Reserved | | The specified DMA is reserved for use by Legacy ISA devices |

Available DMA Channels are:

- DM Channel 0
- DM Channel 1
- DM Channel 3
- DM Channel 5
- DM Channel 6
- DM Channel 7


→ **Reserved Memory Size [Disabled]**

Use the **Reserved Memory Size** BIOS option to specify the amount of memory that should be reserved for legacy ISA devices.

- | | | | |
|---|-----------------|----------------|---|
| → | Disabled | DEFAULT | No memory block reserved for legacy ISA devices |
| → | 16K | | 16KB reserved for legacy ISA devices |
| → | 32K | | 32KB reserved for legacy ISA devices |
| → | 64K | | 54KB reserved for legacy ISA devices |

5.5 Boot


Use the Boot menu (BIOS Menu 14) to configure system boot options.



BIOS Menu 14: Boot

5.5.1 Boot Settings Configuration

Use the Boot Settings Configuration menu (BIOS Menu 14) to configure advanced system boot options.



BIOS Menu 15: Boot Settings Configuration

→ Quick Boot [Enabled]

Use the **Quick Boot** BIOS option to make the computer speed up the boot process.

- **Disabled** No POST procedures are skipped
- **Enabled** **DEFAULT** Some POST procedures are skipped to decrease the system boot time

→ Quiet Boot [Disabled]

Use the **Quiet Boot** BIOS option to select the screen display when the system boots.

- **Disabled** **DEFAULT** Normal POST messages displayed
- **Enabled** OEM Logo displayed instead of POST messages

→ AddOn ROM Display Mode [Force BIOS]

NANO-945GSE EPIC Motherboard

The **AddOn ROM Display Mode** option allows add-on ROM (read-only memory) messages to be displayed.

- ➔ **Force BIOS** **DEFAULT** Allows the computer system to force a third party BIOS to display during system boot.
- ➔ **Keep Current** Allows the computer system to display the information during system boot.

➔ **Bootup Num-Lock [Off]**

The **Bootup Num-Lock** BIOS option allows the Number Lock setting to be modified during boot up.

- ➔ **Off** **DEFAULT** Does not enable the keyboard Number Lock automatically. To use the 10-keys on the keyboard, press the Number Lock key located on the upper left-hand corner of the 10-key pad. The Number Lock LED on the keyboard lights up when the Number Lock is engaged.
- ➔ **On** Allows the Number Lock on the keyboard to be enabled automatically when the computer system boots up. This allows the immediate use of the 10-key numeric keypad located on the right side of the keyboard. To confirm this, the Number Lock LED light on the keyboard is lit.

➔ **Boot From LAN Support [Disabled]**

The **BOOT From LAN Support** option enables the system to be booted from a remote system.


- ➔ **Disabled** **DEFAULT** Cannot be booted from a remote system through the LAN

→ **Enabled** **DEFAULT** Can be booted from a remote system through the LAN

5.5.2 Boot Device Priority

Use the **Boot Device Priority** menu (**BIOS Menu 16**) to specify the boot sequence from the available devices. The following options are available:


- 1st Boot Device
- 2nd Boot Device
- 3rd Boot Device



BIOS Menu 16: Boot Device Priority Settings

5.6 Security

Use the Security menu (BIOS Menu 17) to set system and user passwords.



BIOS Menu 17: Security

→ Change Supervisor Password

Use the **Change Supervisor Password** to set or change a supervisor password. The default for this option is **Not Installed**. If a supervisor password must be installed, select this field and enter the password. After the password has been added, **Install** appears next to **Change Supervisor Password**.

→ Change User Password

Use the **Change User Password** to set or change a user password. The default for this option is **Not Installed**. If a user password must be installed, select this field and enter the

password. After the password has been added, **Install** appears next to **Change User Password**.


5.7 Chipset

Use the **Chipset** menu (**BIOS Menu 18**) to access the NorthBridge and SouthBridge configuration menus



WARNING!

Setting the wrong values for the Chipset BIOS selections in the Chipset BIOS menu may cause the system to malfunction.




BIOS Menu 18: Chipset

NANO-945GSE EPIC Motherboard

5.7.1 North Bridge Chipset Configuration

Use the **North Bridge Chipset Configuration** menu (BIOS Menu 18) to configure the Northbridge chipset settings.



BIOS Menu 19:North Bridge Chipset Configuration

→ Memory Hole [Disabled]

The **Memory Hole** reserves the memory space between 15MB and 16MB for ISA expansion cards that require a specified area of memory to work properly. If an older ISA expansion card is used, please refer to the documentation that came with the card to see if it is necessary to reserve the space.

- **Disabled** **DEFAULT** Memory is not reserved for ISA expansion cards
- **Enabled** Memory is reserved for ISA expansion cards

→ Internal Graphics Mode Select [Enable, 8MB]

The **Internal Graphic Mode Select** option determines the amount of system memory that can be used by the Internal graphics device.

- ➔ **Disable**
- ➔ **Enable, 1MB** 1MB of memory used by internal graphics device
- ➔ **Enable, 8MB** **DEFAULT** 8MB of memory used by internal graphics device

➔ **DVMT Mode Select [DVMT Mode]**

Use the **DVMT Mode Select** option to select the Intel Dynamic Video Memory Technology (DVMT) operating mode.

- ➔ **Fixed Mode** A fixed portion of graphics memory is reserved as graphics memory.
- ➔ **DVMT Mode** **DEFAULT** Graphics memory is dynamically allocated according to the system and graphics needs.
- ➔ **Combo Mode** A fixed portion of graphics memory is reserved as graphics memory. If more memory is needed, graphics memory is dynamically allocated according to the system and graphics needs.

➔ **DVMT/FIXED Memory**

Use the **DVMT/FIXED Memory** option to specify the maximum amount of memory that can be allocated as graphics memory. This option can only be configured for if **DVMT Mode** or **Fixed Mode** is selected in the **DVMT Mode Select** option. If **Combo Mode** is selected, the maximum amount of graphics memory is 128MB. Configuration options are listed below.

- 64MB
- 128MB **DEFAULT**
- Maximum DVMT

NANO-945GSE EPIC Motherboard

→ Boot Display Device [CRT]

The **Boot Display Device** BIOS option selects the display device the system uses when it boots. The available options are listed below:

- Auto **DEFAULT**
- CRT
- TV
- LFP
- LFP1

→ LVDS Panel Type

Use the **LVDS Panel Type** to determine the LCD panel resolution. Configuration options are listed below:

- 640 x 480 18b
- 800 x 480 18b
- 800 x 600 18b
- 1024 x 768 18b
- 1280 x 1024 36b
- 1400 x 1050 36b
- 1440 x 900 36b
- 1600 x 1200 36b
- by H/W

→ LCD Brightness Control

Use the **LCD Brightness Control** option to specify the brightness of the LCD panel as a percentage. Default setting is 100%

→ TV Standard

The **TV Standard** option specifies the TV type connected to the system.


→ **VBIOS-Default** **DEFAULT** TV type is set to VBIOS-Default

→ **NTSC** TV type is set to NTSC

- PAL TV type is set to PAL
- SECAM TV type is set to SECAM
- SMPTE240M TV type is set to SMPTE240M
- ITU-R television TV type is set to ITU-R television
- SMPTE260M TV type is set to SMPTE260M
- SMPTE295M TV type is set to SMPTE295M
- SMPTE296M TV type is set to SMPTE296M
- EIA-770.2 TV type is set to EIA-770.2
- EIA-770.3 TV type is set to EIA-770.3

5.7.2 SouthBridge Configuration

The **SouthBridge Configuration** menu (BIOS Menu 20) the southbridge chipset to be configured.



BIOS Menu 20:SouthBridge Chipset Configuration

NANO-945GSE EPIC Motherboard


→ Audio Controller [All Disabled]

The **Audio Controller** option enables or disables the audio controller.

- **Azalia** Audio controller configured as Azalia
- **AC'97 Audio Only** The on-board AC'97 audio controller is enabled.
- **All Disabled** **DEFAULT** The on-board audio controller is disabled.

5.8 Exit

Use the **Exit** menu (**BIOS Menu 21**) to load default BIOS values, optimal failsafe values and to save configuration changes.



BIOS Menu 21:Exit

→ **Save Changes and Exit**

Use the **Save Changes and Exit** option to save the changes made to the BIOS options and to exit the BIOS configuration setup program.

→ **Discard Changes and Exit**

Use the **Discard Changes and Exit** option to exit the BIOS configuration setup program without saving the changes made to the system.

→ **Discard Changes**

Use the **Discard Changes** option to discard the changes and remain in the BIOS configuration setup program.

→ **Load Optimal Defaults**

Use the **Load Optimal Defaults** option to load the optimal default values for each of the parameters on the Setup menus. **F9 key can be used for this operation.**

→ **Load Failsafe Defaults**

Use the **Load Failsafe Defaults** option to load failsafe default values for each of the parameters on the Setup menus. **F8 key can be used for this operation.**

Chapter

6

Software Drivers

6.1 Available Software Drivers



NOTE:

The content of the CD may vary throughout the life cycle of the product and is subject to change without prior notice. Visit the IEI website or contact technical support for the latest updates.

The following drivers can be installed on the system:

- Chipset
- VGA
- LAN
- Audio

Installation instructions are given below.

6.2 Starting the Driver Program

To access the driver installation programs, please do the following.

Step 1: Insert the CD-ROM that came with the system into a CD-ROM drive attached to the system.

Step 2: The screen in Figure 6-1 appears.

NANO-945GSE EPIC Motherboard



Figure 6-1: Start Up Screen

Step 3: Click **NANO-945GSE**.

Step 4: The screen in appears.




Figure 6-2: Select Operating System

Step 5: Select the operating system installed on the NANO-945GSE system. This

manual describes the installation for a **Windows XP** operating system.

Step 6: The list of drivers in Figure 6-3 appears.




Figure 6-3: Drivers

6.3 Chipset Driver Installation

To install the chipset driver, please do the following.

Step 1: Access the driver list shown in Figure 6-3. (See **Section 6.2**)

Step 2: Click “1-Chipset Driver”

Step 3: The setup files are extracted as shown in Figure 6-4.

NANO-945GSE EPIC Motherboard



Figure 6-4: Chipset Driver Screen

Step 4: When the setup files are completely extracted the **Welcome Screen** in Figure 6-5 appears.



Figure 6-5: Chipset Driver Welcome Screen

Step 5: Click **Next** to continue.

Step 6: The license agreement in Figure 6-6 appears.

Step 7: Read the **License Agreement**.

Step 8: Click the **Yes** icon to continue.



Figure 6-6: Chipset Driver License Agreement

Step 9: The Read Me file in Figure 6-7 appears.

Step 10: Click **Next** to continue.

NANO-945GSE EPIC Motherboard




Figure 6-7: Chipset Driver Read Me File

Step 11: Setup Operations are performed as shown in Figure 6-8.



Figure 6-8: Chipset Driver Setup Operations

Step 12: Once the **Setup Operations** are complete, click the **Next** icon to continue.

Step 13: The **Finish** screen appears.

Step 14: Select “**Yes, I want to restart the computer now**” and click the **Finish** icon.

See Figure 6-9.

NANO-945GSE EPIC Motherboard



Figure 6-9: Chipset Driver Installation Finish Screen

6.4 VGA Driver Installation

To install the VGA driver, please do the following.

- Step 1:** Access the driver list shown in Figure 6-3. (See **Section 6.2**)
- Step 2:** Click “**2-VGA**”
- Step 3:** The VGA Read Me file in Figure 6-10 appears.
- Step 4:** Click **Next** to continue.




Figure 6-10: VGA Driver Read Me File

Step 5: The installation files are extracted. See Figure 6-11.




Figure 6-11: VGA Driver Setup Files Extracted

Step 6: The **Welcome Screen** in Figure 6-12 appears.

NANO-945GSE EPIC Motherboard



Figure 6-12: VGA Driver Welcome Screen

- Step 7:** Click **Next** to continue.
- Step 8:** The license agreement in Figure 6-13 appears.
- Step 9:** Read the **License Agreement**.
- Step 10:** Click the **Yes** icon to continue.




Figure 6-13: VGA Driver License Agreement

Step 11: The Read Me file in Figure 6-14 appears.

Step 12: Click **Next** to continue.




Figure 6-14: VGA Driver Read Me File

Step 13: Setup Operations are performed as shown in Figure 6-15.

NANO-945GSE EPIC Motherboard




Figure 6-15: VGA Driver Setup Operations

Step 14: Once the **Setup Operations** are complete, click the **Next** icon to continue.

Step 15: The **Finish** screen appears.

Step 16: Select “**Yes, I want to restart the computer now**” and click the **Finish** icon.

See Figure 6-16.




Figure 6-16: VGA Driver Installation Finish Screen

6.5 LAN Driver Installation

To install the chipset driver, please do the following.

Step 1: Access the driver list shown in Figure 6-3. (See **Section 6.2**)

Step 2: Click “3-LAN”

Step 3: The **Welcome** screen in Figure 6-17 appears.




Figure 6-17: LAN Driver Welcome Screen

Step 4: Click **Next** to continue.

Step 5: The **Ready to Install** screen in Figure 6-18 appears.

Step 6: Click **Next** to proceed with the installation.

NANO-945GSE EPIC Motherboard




Figure 6-18: LAN Driver Welcome Screen

Step 7: The program begins to install.

Step 8: The installation progress can be monitored in the progress bar shown in Figure 6-19.




Figure 6-19: LAN Driver Installation

Step 9: When the driver installation is complete, the screen in Figure 6-20 appears.




Figure 6-20: LAN Driver Installation Complete

6.6 Audio Driver Installation

To install the chipset driver, please do the following.

Step 1: Access the driver list shown in Figure 6-3. (See **Section 6.2**)

Step 2: Click “4-Audio”

Step 3: The screen in Figure 6-21 appears.

NANO-945GSE EPIC Motherboard




Figure 6-21: Audio Driver Options

6.6.1 HD Audio Installation

To install the HD Audio driver, please do the following:

Step 1: Select "1-HDAudio" in Figure 6-21.

Step 2: Installation files are extracted as shown in Figure 6-22.




Figure 6-22: Extract HD Audio Driver Installation Files

Step 3: The **Welcome** screen in Figure 6-23 appears.

NANO-945GSE EPIC Motherboard




Figure 6-23: HD Audio Driver Welcome Screen

Step 4: Click **Next** to continue.

Step 5: The system updates. See Figure 6-24.




Figure 6-24: System Update

Step 6: Follow the installation instructions until the HD Audio driver installation is complete.

6.6.2 AC'97 Driver Installation

To install the AC'97 audio driver, please do the following:

Step 1: Select "2-AC'97" in Figure 6-21

Step 2: The installation files are extracted as shown in Figure 6-25.

NANO-945GSE EPIC Motherboard




Figure 6-25: AC'97 Driver Installation File Extraction

Step 3: The AC'97 Driver Installation screen in Figure 6-26 appears.

Step 4: Click **Next** to continue.




Figure 6-26: AC'97 Driver Installation Welcome Screen

Step 5: The Verification window in Figure 6-27 may appear.

Step 6: Click **“Continue Anyway.”**




Figure 6-27: AC'97 Driver Installation Verification

Step 7: The driver installation begins. See Figure 6-28.




Figure 6-28: AC'97 Driver Installation

Step 8: When the driver is installed, the driver installation finish screen in Figure 6-29 appears.

Step 9: Select "Yes, I wish to restart my computer now" And click **Finish**




Figure 6-29: AC'97 Driver Installation Complete

Step 10: The system reboots.

Appendix

A

BIOS Menu Options

NANO-945GSE EPIC Motherboard

System Overview	108
System Time [xx:xx:xx].....	109
System Date [xx/xx/xx].....	109
ATA/IDE Configurations [Compatible]	112
Legacy IDE Channels [PATA Pri, SATA Sec].....	113
IDE Master and IDE Slave	113
Auto-Detected Drive Parameters	114
Type [Auto].....	115
ZIP	115
LS-120	115
LBA/Large Mode [Auto]	116
Block (Multi Sector Transfer) [Auto].....	116
PIO Mode [Auto]	116
DMA Mode [Auto]	117
S.M.A.R.T [Auto]	118
32Bit Data Transfer [Enabled]	118
Parallel Port Address [Disabled].....	119
Parallel Port Mode [Normal]	120
Parallel Port IRQ [IRQ7]	120
Serial Port1 Address [3F8/IRQ4]	121
Serial Port1 Mode [Normal]	121
Serial Port2 Address [2F8/IRQ3]	121
Serial Port2 Mode [Normal]	122
Serial Port3 Address [3E8]	122
Serial Port3 IRQ [11].....	122
Serial Port4 Address [2E8]	122
Serial Port4 IRQ [10].....	123
CPU FAN Mode Setting [Full On Mode].....	124
CPU Temp. Limit of OFF [000].....	125
CPU Temp. Limit of Start [020].....	125

CPU Fan Start PWM [070]	126
Slope PWM [0.5 PWM]	126
Suspend Mode [S1(POS)]	129
Restore on AC Power Loss [Last State].....	130
Power Button Mode [On/Off]	130
Resume on Keyboard/Mouse [Disabled].....	131
Resume on Ring [Disabled].....	131
Resume on PCI-Express WAKE# [Enabled]	131
Resume On RTC Alarm [Disabled]	132
RTC Alarm Date (Days)	132
System Time	132
Remote Access [Disabled]	133
Serial Port Number	133
Serial Port Mode	133
Flow Control.....	133
Redirection after BIOS POST	133
Terminal Type	134
VT-UTF8 Combo Key Support.....	134
Serial Port Number [COM1]	134
Base Address, IRQ [2F8h,3]	134
Serial Port Mode [115200 8,n,1]	134
Flow Control [None]	135
Redirection After BIOS POST [Always].....	135
Terminal Type [ANSI]	135
VT-UTF8 Combo Key Support [Disabled]	135
Sredir Memory Display Delay [Disabled]	136
USB Functions [Enabled]	137
USB 2.0 Controller [Enabled]	137
USB2.0 Controller Mode [HiSpeed]	137
Legacy USB Support [Enabled]	138
IRQ# [Available]	139

NANO-945GSE EPIC Motherboard

DMA Channel# [Available]	140
Reserved Memory Size [Disabled]	140
Quick Boot [Enabled]	142
Quiet Boot [Disabled]	142
AddOn ROM Display Mode [Force BIOS]	142
Bootup Num-Lock [Off]	143
Boot From LAN Support [Disabled]	143
Change Supervisor Password	145
Change User Password	145
Memory Hole [Disabled]	147
Internal Graphics Mode Select [Enable, 8MB]	147
DVMT Mode Select [DVMT Mode]	148
DVMT/FIXED Memory	148
Boot Display Device [CRT]	149
LVDS Panel Type	149
LCD Brightness Control	149
TV Standard	149
Audio Controller [All Disabled]	151
Save Changes and Exit	152
Discard Changes and Exit	152
Discard Changes	152
Load Optimal Defaults	152
Load Failsafe Defaults	152



Appendix

B

Terminology

NANO-945GSE EPIC Motherboard

AC '97	Audio Codec 97 (AC'97) refers to a codec standard developed by Intel® in 1997.
ACPI	Advanced Configuration and Power Interface (ACPI) is an OS-directed configuration, power management, and thermal management interface.
AHCI	Advanced Host Controller Interface (AHCI) is a SATA Host controller register-level interface.
ATA	The Advanced Technology Attachment (ATA) interface connects storage devices including hard disks and CD-ROM drives to a computer.
APM	The Advanced Power Management (APM) application program interface (API) enables the inclusion of power management in the BIOS.
ARMD	An ATAPI Removable Media Device (ARMD) is any ATAPI device that supports removable media, besides CD and DVD drives.
ASKIR	Amplitude Shift Keyed Infrared (ASKIR) is a form of modulation that represents a digital signal by varying the amplitude (“volume”) of the signal. A low amplitude signal represents a binary 0, while a high amplitude signal represents a binary 1.
BIOS	The Basic Input/Output System (BIOS) is firmware that is first run when the computer is turned on and can be configured by the end user
CODEC	The Compressor-Decompressor (CODEC) encodes and decodes digital audio data on the system.
CMOS	Complimentary metal-oxide-conductor is a type of integrated circuit used in chips like static RAM and microprocessors.
COM	COM is used to refer to serial ports. Serial ports offer serial communication to expansion devices. The serial port on a personal

computer is usually a male DE-9 connector.

DAC	The Digital-to-Analog Converter (DAC) converts digital signals to analog signals.
DDR	Double Data Rate refers to a data bus transferring data on both the rising and falling edges of the clock signal.
DMA	Direct Memory Access (DMA) enables some peripheral devices to bypass the system processor and communicate directly with the system memory.
DIMM	Dual Inline Memory Modules are a type of RAM that offer a 64-bit data bus and have separate electrical contacts on each side of the module.
EHCI	The Enhanced Host Controller Interface (EHCI) specification is a register-level interface description for USB 2.0 Host Controllers.
FSB	The Front Side Bus (FSB) is the bi-directional communication channel between the processor and the Northbridge chipset.
GbE	Gigabit Ethernet (GbE) is an Ethernet version that transfers data at 1.0 Gbps and complies with the IEEE 802.3-2005 standard.
GPIO	General purpose input
IrDA	Infrared Data Association (IrDA) specify infrared data transmission protocols used to enable electronic devices to wirelessly communicate with each other.
L1 Cache	The Level 1 Cache (L1 Cache) is a small memory cache built into the system processor.
L2 Cache	The Level 2 Cache (L2 Cache) is an external processor memory cache.
LVDS	Low-voltage differential signaling (LVDS) is a dual-wire, high-speed differential electrical signaling system commonly used to connect LCD displays to a computer.

NANO-945GSE EPIC Motherboard

MAC	The Media Access Control (MAC) protocol enables several terminals or network nodes to communicate in a LAN, or other multipoint networks.
PCIe	PCI Express (PCIe) is a communications bus that uses dual data lines for full-duplex (two-way) serial (point-to-point) communications between the SBC components and/or expansion cards and the SBC chipsets. Each line has a 2.5 Gbps data transmission rate and a 250 MBps sustained data transfer rate.
POST	The Power-on Self Test (POST) is the pre-boot actions the system performs when the system is turned-on.
QVGA	Quarter Video Graphics Array (QVGA) refers to a display with a resolution of 320 x 240 pixels.
RAID	Redundant Array of Inexpensive Disks (RAID) refers to redundantly backing up data on multiple disks to ensure that if one disk fails, the data is not lost and can be restored from the remaining disks in the array.
RAM	Random Access Memory (RAM) is a form of storage used in computer. RAM is volatile memory, so it loses its data when power is lost. RAM has very fast data transfer rates compared to other storage like hard drives.
SATA	Serial ATA (SATA) is a serial communications bus designed for data transfers between storage devices and the computer chipsets. The SATA bus has transfer speeds up to 1.5 Gbps and the SATA II bus has data transfer speeds of up to 3.0 Gbps.
S.M.A.R.T	Self Monitoring Analysis and Reporting Technology (S.M.A.R.T) refers to automatic status checking technology implemented on hard disk drives.
UART	Universal Asynchronous Receiver-transmitter (UART) is responsible for

asynchronous communications on the system and manages the system's serial communication (COM) ports.

UHCI

The Universal Host Controller Interface (UHCI) specification is a register-level interface description for USB 1.1 Host Controllers.

USB

The Universal Serial Bus (USB) is an external bus standard for interfacing devices. USB 1.1 supports 12Mbps data transfer rates, while USB 2.0 supports 480Mbps data transfer rates.

VGA

The Video Graphics Array (VGA) is a graphics display system developed by IBM.

Appendix

C

DIO Interface

C.1 DIO Interface Introduction

The DIO connector on the NANO-945GSE is interfaced to GPIO ports on the ITE IT8718 Super I/O chipset. The DIO has both 4-bit digital inputs and 4-bit digital outputs. The digital inputs and digital outputs are generally control signals that control the on/off circuit of external devices or TTL devices. Data can be read or written to the selected address to enable the DIO functions.



NOTE:

For further information, please refer to the datasheet for the ITE IT8718 Super I/O chipset.

C.2 DIO Connector Pinouts

The following table describes how the DIO connector pins are connected to the Super I/O GPIO port.

Pin	Description	Super I/O Pin	Super I/O Pin Description
1	Ground	N/A	N/A
2	VCC	N/A	N/A
3	Output 3	GP23	General Purpose I/O Port 2 Bit 3
4	Output 2	GP22	General Purpose I/O Port 2 Bit 2
5	Output 1	GP21	General Purpose I/O Port 2 Bit 1
6	Output 0	GP20	General Purpose I/O Port 2 Bit 0
7	Input 3	GP33	General Purpose I/O 33
8	Input 2	GP32	General Purpose I/O 32
9	Input 1	GP31	General Purpose I/O 31
10	Input 0	GP30	General Purpose I/O 30

C.3 Assembly Language Samples

C.3.1 Enable the DIO Input Function

The BIOS interrupt call INT 15H controls the digital I/O. An assembly program to enable digital I/O input functions is listed below.

MOV	AX, 6F08H	Sets the digital port as input
INT	15H	Initiates the INT 15H BIOS call

C.3.2 Enable the DIO Output Function

The BIOS interrupt call INT 15H controls the digital I/O. An assembly program to enable digital I/O output functions is listed below.

MOV	AX, 6F09H	Sets the digital port as output
MOV	BL, 09H	
INT	15H	Initiates the INT 15H BIOS call



Appendix

D

Watchdog Timer



NOTE:

The following discussion applies to DOS environment. IEI support is contacted or the IEI website visited for specific drivers for more sophisticated operating systems, e.g., Windows and Linux.

The Watchdog Timer is provided to ensure that standalone systems can always recover from catastrophic conditions that cause the CPU to crash. This condition may have occurred by external EMI or a software bug. When the CPU stops working correctly, Watchdog Timer either performs a hardware reset (cold boot) or a Non-Maskable Interrupt (NMI) to bring the system back to a known state.

A BIOS function call (INT 15H) is used to control the Watchdog Timer:

INT 15H:

AH – 6FH Sub-function:	
AL – 2:	Sets the Watchdog Timer’s period.
BL:	Time-out value (Its unit-second is dependent on the item “Watchdog Timer unit select” in CMOS setup).

Table D-1: AH-6FH Sub-function

Call sub-function 2 to set the time-out period of Watchdog Timer first. If the time-out value is not zero, the Watchdog Timer starts counting down. While the timer value reaches zero, the system resets. To ensure that this reset condition does not occur, calling sub-function 2 must periodically refresh the Watchdog Timer. However, the Watchdog timer is disabled if the time-out value is set to zero.

A tolerance of at least 10% must be maintained to avoid unknown routines within the operating system (DOS), such as disk I/O that can be very time-consuming.



NOTE:

When exiting a program it is necessary to disable the Watchdog Timer, otherwise the system resets.

Example program:

; INITIAL TIMER PERIOD COUNTER

;

W_LOOP:

```

MOV    AX, 6F02H    ;setting the time-out value
MOV    BL, 30       ;time-out value is 48 seconds
INT    15H

```

;

; ADD THE APPLICATION PROGRAM HERE

;

```

CMP    EXIT_AP, 1   ;is the application over?
JNE    W_LOOP       ;No, restart the application

```

```

MOV    AX, 6F02H    ;disable Watchdog Timer
MOV    BL, 0        ;
INT    15H

```

;


; EXIT ;





























Appendix

E

Address Mapping

E.1 I/O Address Map

☐  Input/output (IO)

	[00000000 - 0000000F]	Direct memory access controller
	[00000000 - 00000CF7]	PCI bus
	[00000010 - 0000001F]	Motherboard resources
	[00000020 - 00000021]	Programmable interrupt controller
	[00000022 - 0000003F]	Motherboard resources
	[00000040 - 00000043]	System timer
	[00000044 - 0000005F]	Motherboard resources
	[00000061 - 00000061]	System speaker
	[00000063 - 00000063]	Motherboard resources
	[00000065 - 00000065]	Motherboard resources
	[00000067 - 0000006F]	Motherboard resources
	[00000070 - 00000071]	System CMOS/real time clock
	[00000072 - 0000007F]	Motherboard resources
	[00000080 - 00000080]	Motherboard resources
	[00000081 - 00000083]	Direct memory access controller
	[00000084 - 00000086]	Motherboard resources
	[00000087 - 00000087]	Direct memory access controller
	[00000088 - 00000088]	Motherboard resources
	[00000089 - 0000008B]	Direct memory access controller
	[0000008C - 0000008E]	Motherboard resources
	[0000008F - 0000008F]	Direct memory access controller
	[00000090 - 0000009F]	Motherboard resources
	[000000A0 - 000000A1]	Programmable interrupt controller
	[000000A2 - 000000BF]	Motherboard resources
	[000000C0 - 000000DF]	Direct memory access controller
	[000000E0 - 000000EF]	Motherboard resources
	[000000F0 - 000000FF]	Numeric data processor
	[00000170 - 00000177]	Secondary IDE Channel

NANO-945GSE EPIC Motherboard


































	[000001F0 - 000001F7]	Primary IDE Channel
	[00000274 - 00000277]	ISAPNP Read Data Port
	[00000279 - 00000279]	ISAPNP Read Data Port
	[000002E8 - 000002EF]	Communications Port (COM4)
	[000002F8 - 000002FF]	Communications Port (COM2)
	[00000376 - 00000376]	Secondary IDE Channel
	[00000378 - 0000037F]	Printer Port (LPT1)
	[000003B0 - 000003BB]	Mobile Intel(R) 945 Express Chipset Family
	[000003C0 - 000003DF]	Mobile Intel(R) 945 Express Chipset Family
	[000003E8 - 000003EF]	Communications Port (COM3)
	[000003F6 - 000003F6]	Primary IDE Channel
	[000003F8 - 000003FF]	Communications Port (COM1)
	[00000400 - 0000041F]	Intel(R) 82801G (ICH7 Family) SMBus Controller - 27DA
	[00000480 - 000004BF]	Motherboard resources
	[000004D0 - 000004D1]	Motherboard resources
	[00000800 - 0000087F]	Motherboard resources
	[00000A00 - 00000A0F]	Motherboard resources
	[00000A10 - 00000A1F]	Motherboard resources
	[00000A20 - 00000A2F]	Motherboard resources
	[00000A30 - 00000A3F]	Motherboard resources
	[00000A60 - 00000A6F]	Motherboard resources
	[00000A79 - 00000A79]	ISAPNP Read Data Port
	[00000D00 - 0000FFFF]	PCI bus
	[0000C480 - 0000C49F]	Intel(R) 82801G (ICH7 Family) USB Universal Host Controller - 27CB
	[0000C800 - 0000C81F]	Intel(R) 82801G (ICH7 Family) USB Universal Host Controller - 27CA
	[0000C880 - 0000C89F]	Intel(R) 82801G (ICH7 Family) USB Universal Host Controller - 27C9
	[0000CC00 - 0000CC1F]	Intel(R) 82801G (ICH7 Family) USB Universal Host Controller - 27C8
	[0000CC80 - 0000CC87]	Mobile Intel(R) 945 Express Chipset Family
	[0000D000 - 0000DFFF]	Intel(R) 82801G (ICH7 Family) PCI Express Root Port - 27D0
	[0000DC00 - 0000DCFF]	Realtek RTL8168C(P)/8111C(P) PCI-E Gigabit Ethernet NIC #2
	[0000E000 - 0000EFFF]	Intel(R) 82801G (ICH7 Family) PCI Express Root Port - 27D2
	[0000EC00 - 0000EFFF]	Realtek RTL8168C(P)/8111C(P) PCI-E Gigabit Ethernet NIC
	[0000FFA0 - 0000FFAF]	Intel(R) 82801GBM/GHM (ICH7-M Family) Serial ATA Storage Controller

Table E-1: IO Address Map

E.2 IRQ Address Map

 Interrupt request (IRQ)

(ISA) 0	System timer
(ISA) 3	Communications Port (COM2)
(ISA) 4	Communications Port (COM1)
(ISA) 8	System CMOS/real time clock
(ISA) 9	Microsoft ACPI-Compliant System
(ISA) 10	Communications Port (COM4)
(ISA) 11	Communications Port (COM3)
(ISA) 13	Numeric data processor
(ISA) 14	Primary IDE Channel
(ISA) 15	Secondary IDE Channel
(PCI) 5	Intel(R) 82801G (ICH7 Family) SMBus Controller - 27DA
(PCI) 16	Intel(R) 82801G (ICH7 Family) PCI Express Root Port - 27D0
(PCI) 16	Intel(R) 82801G (ICH7 Family) USB Universal Host Controller - 27CB
(PCI) 16	Mobile Intel(R) 945 Express Chipset Family
(PCI) 16	Realtek RTL8168C(P)/8111C(P) PCI-E Gigabit Ethernet NIC #2
(PCI) 17	Intel(R) 82801G (ICH7 Family) PCI Express Root Port - 27D2
(PCI) 17	Realtek RTL8168C(P)/8111C(P) PCI-E Gigabit Ethernet NIC
(PCI) 18	Intel(R) 82801G (ICH7 Family) USB Universal Host Controller - 27CA
(PCI) 19	Intel(R) 82801G (ICH7 Family) USB Universal Host Controller - 27C9
(PCI) 23	Intel(R) 82801G (ICH7 Family) USB Universal Host Controller - 27C8
(PCI) 23	Intel(R) 82801G (ICH7 Family) USB2 Enhanced Host Controller - 27CC

.....

Table E-2: IRQ Address Map

NANO-945GSE EPIC Motherboard

E.3 Memory Address Map

Memory	Address Range	Device
System board	[00000000 - 0009FFFF]	
Mobile Intel(R) 945 Express Chipset Family	[000A0000 - 000BFFFF]	
PCI bus	[000A0000 - 000BFFFF]	
System board	[000C0000 - 000CFFFF]	
PCI bus	[000D0000 - 000DFFFF]	
System board	[000E0000 - 000FFFFF]	
System board	[00100000 - 3F7FFFFF]	
PCI bus	[3F800000 - DFFFFFFF]	
Mobile Intel(R) 945 Express Chipset Family	[D0000000 - DFFFFFFF]	
Motherboard resources	[E0000000 - E3FFFFFF]	
PCI bus	[E4000000 - FED8FFFF]	
Intel(R) 82801G (ICH7 Family) PCI Express Root Port - 27D0	[FDE00000 - FDEFFFFFFF]	
Realtek RTL8168C(P)/8111C(P) PCI-E Gigabit Ethernet NIC #2	[FDEF0000 - FDEFFFFFFF]	
Intel(R) 82801G (ICH7 Family) PCI Express Root Port - 27D2	[FDF00000 - FDFFFFFFFF]	
Realtek RTL8168C(P)/8111C(P) PCI-E Gigabit Ethernet NIC	[FDF00000 - FDFFFFFFFF]	
Mobile Intel(R) 945 Express Chipset Family	[FE880000 - FE8FFFFFFF]	
Intel(R) 82801G (ICH7 Family) USB2 Enhanced Host Controller - 27CC	[FE93BC00 - FE93BFFF]	
Mobile Intel(R) 945 Express Chipset Family	[FE940000 - FE97FFFF]	
Mobile Intel(R) 945 Express Chipset Family	[FE980000 - FE9FFFFFFF]	
Intel(R) 82801G (ICH7 Family) PCI Express Root Port - 27D0	[FEA00000 - FEAFFFFF]	
Realtek RTL8168C(P)/8111C(P) PCI-E Gigabit Ethernet NIC #2	[FEAFF000 - FEAFFFFF]	
Intel(R) 82801G (ICH7 Family) PCI Express Root Port - 27D2	[FEB00000 - FEBFFFFFFF]	
Realtek RTL8168C(P)/8111C(P) PCI-E Gigabit Ethernet NIC	[FEB00000 - FEBFFFFFFF]	
Motherboard resources	[FEC00000 - FEC00FFF]	
System board	[FED13000 - FED19FFF]	
Motherboard resources	[FED1C000 - FED1FFFF]	
Motherboard resources	[FED20000 - FED3FFFF]	
Motherboard resources	[FED40000 - FED8FFFF]	
System board	[FED90000 - FFFFFFFF]	
Motherboard resources	[FEE00000 - FEE00FFF]	

Table E-3: Memory Address Map

Appendix

F

Hazardous Materials Disclosure

F.1 Hazardous Material Disclosure Table for IPB Products Certified as RoHS Compliant Under 2002/95/EC Without Mercury

The details provided in this appendix are to ensure that the product is compliant with the Peoples Republic of China (China) RoHS standards. The table below acknowledges the presences of small quantities of certain materials in the product, and is applicable to China RoHS only.

A label will be placed on each product to indicate the estimated “Environmentally Friendly Use Period” (EFUP). This is an estimate of the number of years that these substances would “not leak out or undergo abrupt change.” This product may contain replaceable sub-assemblies/components which have a shorter EFUP such as batteries and lamps. These components will be separately marked.

Please refer to the table on the next page.

Part Name	Toxic or Hazardous Substances and Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (CR(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Housing	X	O	O	O	O	X
Display	X	O	O	O	O	X
Printed Circuit Board	X	O	O	O	O	X
Metal Fasteners	X	O	O	O	O	O
Cable Assembly	X	O	O	O	O	X
Fan Assembly	X	O	O	O	O	X
Power Supply Assemblies	X	O	O	O	O	X
Battery	O	O	O	O	O	O

O: This toxic or hazardous substance is contained in all of the homogeneous materials for the part is below the limit requirement in SJ/T11363-2006

X: This toxic or hazardous substance is contained in at least one of the homogeneous materials for this part is above the limit requirement in SJ/T11363-2006

NANO-945GSE EPIC Motherboard

此附件旨在确保本产品符合中国 RoHS 标准。以下表格标示此产品中某有毒物质的含量符合中国 RoHS 标准规定的限量要求。

本产品上会附有“环境友好使用期限”的标签，此期限是估算这些物质“不会有泄漏或突变”的年限。本产品可能包含有较短的环境友好使用期限的可替换元件，像是电池或灯管，这些元件将会单独标示出来。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (CR(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
壳体	X	O	O	O	O	X
显示	X	O	O	O	O	X
印刷电路板	X	O	O	O	O	X
金属螺帽	X	O	O	O	O	O
电缆组装	X	O	O	O	O	X
风扇组装	X	O	O	O	O	X
电力供应组装	X	O	O	O	O	X
电池	O	O	O	O	O	O

O: 表示该有毒有害物质在该部件所有物质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。
X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。