


PE-9S-R40

9-Slot PICMG 1.3 PCIe to PCI Bridge Backplane User Manual Ver. 4.0

1. USB1, USB2: External 4 Port USB Connectors From the Mainboard



| PIN | DESCRIPTION | PIN | DESCRIPTION |
|-----|-------------|-----|-------------|
| 1 | USBVCC | 2 | GND |
| 3 | DATA- | 4 | DATA+ |
| 5 | DATA+ | 6 | DATA- |
| 7 | GND | 8 | USBVCC |

2. FAN1, FAN2, FAN3, FAN4: Fan Connector



| PIN | DESCRIPTION |
|-----|-------------|
| 1 | GND |
| 2 | +12V |
| 3 | NC |

3. ATXCTL1: Backplane to Mainboard ATX Power Control Connector



| PIN | DESCRIPTION |
|-----|-------------|
| 1 | GND |
| 2 | PSON# |
| 3 | 5VSB |

4. PWRBTN: External Power On Button



| PIN | DESCRIPTION |
|-----|-------------|
| 1 | GND |
| 2 | PWRBT# |

5. RESET: External Reset Button Connector



| PIN | DESCRIPTION |
|-----|-------------|
| 1 | GND |
| 2 | SHB_RST# |

6. PWRGD: External Power Good Connector




| PIN | DESCRIPTION |
|-----|-------------|
| 1 | GND |
| 2 | PWRGD |

7. SM-BUS: External System Management BUS Connector



| PIN | DESCRIPTION |
|-----|-------------|
| 1 | SMDAT |
| 2 | SMCLK |


8. CN1: PCIE X16 SDVO Control Signal Pin



| PIN | DESCRIPTION |
|-----|-------------|
| 1 | EXP_EN |
| 2 | SDVO_CLK |
| 3 | SDVO_DAT |

9. IOPWR: The I/O Power Connector indicators for controlling your CPU board.

| PIN NO. | DESCRIPTION | PIN NO. | DESCRIPTION |
|---------|-------------|---------|-------------|
| 1 | GND | 2 | -12V |
| 3 | +12V | 4 | GND |
| 5 | IPMB_DA | 6 | 5VSB |
| 7 | GND | 8 | GND |
| 9 | IPMB_CL | 10 | 5VSB |
| 11 | +5V | 12 | PWRGD |
| 13 | SMDAT | 14 | SHB_RST# |
| 15 | 5VSB | 16 | GND |
| 17 | SMCLK | 18 | PSON# |
| 19 | +3.3V | 20 | PWRBT# |




10. PCI routing table:

| SIGNAL | REQ# | GNT# | IDSEL | INTA# | INTB# | INTC# | INTD# |
|---------|-------|-------|-------|-------|-------|-------|-------|
| PIN No. | B18 | A17 | A26 | A6 | B7 | A7 | B8 |
| PCI1 | REQ0# | GNT0# | AD31 | B | C | D | A |
| PCI2 | REQ1# | GNT1# | AD30 | C | D | A | B |
| PCI3 | REQ2# | GNT2# | AD29 | D | A | B | C |

11. Notice:

- a. Recommend to use 6mm width spacer to install



- b. Torsion must less than 6lb-inch

